



BULLETIN 217B

ADJUSTMENTS AND LUBRICATION

MODEL 28

PAGE PRINTER SET

LP, LK, LB, LAC

**TELETYPE<sup>®</sup>**

**CORPORATION**


SUBSIDIARY OF *Western Electric Company* INC.

CHICAGO, ILLINOIS, U. S. A.

COPYRIGHT 1953 BY TELETYPE CORPORATION IN UNITED STATES.  
COPYRIGHT IN ALL COUNTRIES PARTICIPATING IN INTERNATIONAL  
CONVENTION AND PAN AMERICAN CONVENTIONS. ALL RIGHTS  
RESERVED INCLUDING RIGHTS OF TRANSLATIONS INTO ALL LANGUAGES.

Printed in U. S. A.

CHANGE 4




## LIST OF EFFECTIVE PAGES

MARCH, 1959

Page Number	Change In Effect	Page Number	Change In Effect
TITLE PAGE	CHANGE 4	3-19	CHANGE 3
A	CHANGE 4	3-20	CHANGE 2
B TO C	CHANGE 1	3-21 TO 3-22	CHANGE 1
D TO S	CHANGE 4	3-23	CHANGE 4
1-1 TO 1-100	CHANGE 4	3-24 TO 3-25	CHANGE 1
2-1 TO 2-46	CHANGE 4	3-26	CHANGE 4
3-1	CHANGE 4	3-27 TO 3-28	CHANGE 1
3-2	CHANGE 1	3-29	CHANGE 4
3-3 TO 3-4	CHANGE 4	3-30 TO 3-33	CHANGE 1
3-5 TO 3-6	CHANGE 1	3-34 TO 3-35	CHANGE 2
3-7 TO 3-8	CHANGE 2	3-36 TO 3-39	CHANGE 4
3-9 TO 3-11	CHANGE 1	3-40	CHANGE 2
3-12	CHANGE 2	3-41	CHANGE 4
3-13 TO 3-14	CHANGE 1	3-42 TO 3-46	CHANGE 2
3-15	CHANGE 2	3-47 TO 3-64	CHANGE 4
3-16 TO 3-17	CHANGE 1	4-1 TO 4-50	CHANGE 4
3-18	CHANGE 2		


THE ABOVE INDICATES THE EFFECTIVE PAGES AS OF THE DATE OF ISSUE.  
UPON RECEIPT OF CHANGE PAGES, INSERT THEM NUMERICALLY AND DISCARD  
ANY SUPERSEDED PAGES.

217B



SENDING AND RECEIVING SET

217B



RECEIVING ONLY SET

CHANGE 1.

C

## CONTENTS

## SECTION 1 - STANDARD FEATURES

Paragraph	Page
1. GENERAL . . . . .	1-1
2. KEYBOARD . . . . .	1-3
a. Adjustments:	
Ball wedgelock and ball track clearance . . . . .	1-11
Clutch shoe lever . . . . .	1-4
Clutch stop lever . . . . .	1-5
Code bar and code lever clearance . . . . .	1-7
Code bar bail . . . . .	1-9
Code bar bail and non-repeat lever clearance . . . . .	1-9
Code bar guide clearance . . . . .	1-3
Contact box contact clearance . . . . .	1-6
Function bail and code lever clearance . . . . .	1-8
Intermediate gear bracket . . . . .	1-13
Lock ball channel . . . . .	1-8
Lock ball end play . . . . .	1-11
Mounting typing unit on keyboard or base . . . . .	1-17
Plastic window . . . . .	1-18
Space bar bail pivot . . . . .	1-3
Transfer bail detent plate . . . . .	1-6
Universal bail extension . . . . .	1-10
Universal bail latch lever . . . . .	1-10
b. Spring Tensions:	
Clutch drum . . . . .	1-4
Clutch latch lever . . . . .	1-5
Clutch shoe . . . . .	1-12
Clutch shoe lever . . . . .	1-12
Clutch stop lever . . . . .	1-5
Clutch trip bar . . . . .	1-7
Code bar . . . . .	1-7
Code bar bail . . . . .	1-14
Code bar bail latch . . . . .	1-9
Code lever . . . . .	1-15
Code lever universal bail . . . . .	1-3
Contact box . . . . .	1-6
Contact box drive link . . . . .	1-6
Line break lever . . . . .	1-14
Local carriage function bail . . . . .	1-15
Local line feed trip link . . . . .	1-10
Lock bar . . . . .	1-7
Margin Indicator . . . . .	1-16
Non-repeat lever . . . . .	1-9
Plunger . . . . .	1-10
Transfer bail detent latch . . . . .	1-6
Transfer lever . . . . .	1-16
Transfer lever locking bail . . . . .	1-16
Universal bail latch . . . . .	1-10

## CONTENTS

Paragraph	Page
3. BASE ADJUSTMENTS AND SPRING TENSIONS . . . . .	1-19
4. TYPING UNIT . . . . .	1-19
a. Adjustments:	
Anti-deflection plate . . . . .	1-33
Carriage return latch bail . . . . .	1-52
Carriage return lever . . . . .	1-53
Carriage wire rope . . . . .	1-50
Clutch drum position . . . . .	1-37
Clutch shoe lever . . . . .	1-36
Clutch trip shaft set collars . . . . .	1-33
Code bar clutch trip lever . . . . .	1-31
Code bar detent . . . . .	1-78
Code bar shift lever drive arm . . . . .	1-29
Code bar shift lever link bracket . . . . .	1-30
Dash pot vent screw . . . . .	1-54
Figs - ltrs shift code bar operating mechanism . . . . .	1-45
Function clutch trip lever . . . . .	1-32
Function reset bail blade . . . . .	1-46
Horizontal positioning drive linkage . . . . .	1-48
Intermediate arm backstop bracket . . . . .	1-28
Left margin . . . . .	1-55
Left vertical positioning lever eccentric stud . . . . .	1-42
Line feed clutch phasing . . . . .	1-39
Line feed clutch trip lever adjusting screw . . . . .	1-35
Line feed clutch trip lever eccentric post . . . . .	1-35
Line feed spur gear detent eccentric . . . . .	1-69
Margin indicator lamp . . . . .	1-79
Oscillating rail slide position . . . . .	1-43
Paper finger adjustment . . . . .	1-75
Paper straightener collar . . . . .	1-74
Printing arm . . . . .	1-62
Printing carriage lower roller . . . . .	1-58
Printing carriage position . . . . .	1-59
Printing hammer bearing stud . . . . .	1-59
Printing hammer stop bracket . . . . .	1-62
Printing track . . . . .	1-61
Range finder knob phasing . . . . .	1-25
Reversing slide adjusting stud . . . . .	1-47
Reversing slide bracket . . . . .	1-47
Ribbon feed lever bracket . . . . .	1-65
Ribbon reverse detent . . . . .	1-64
Ribbon reverse spur gear . . . . .	1-64
Right margin . . . . .	1-56
Right margin with automatic carriage return - line feed ring . . . . .	1-73
Right vertical positioning lever eccentric stud . . . . .	1-41
Rocker shaft bracket eccentric stud . . . . .	1-40
Rocker shaft left bracket . . . . .	1-39
Selector armature . . . . .	1-20
Selector cam lubricator . . . . .	1-28
Selector clutch drum . . . . .	1-23

## CONTENTS

Paragraph	Page
Selector clutch stop arm . . . . .	1-25
Selector magnet bracket . . . . .	1-21
Selector receiving margin . . . . .	1-26
Shift linkage . . . . .	1-60
Spacing clutch trip lever . . . . .	1-34
Spacing gear clearance . . . . .	1-38
Spacing gear phasing . . . . .	1-38
Spacing trip lever bail cam plate . . . . .	1-44
Stripper blade drive cam position . . . . .	1-70
Stunt box clip . . . . .	1-68
Transfer lever eccentric . . . . .	1-27
Type box alignment . . . . .	1-63
Type box clutch trip lever . . . . .	1-36
Type box clutch trip lever eccentric post . . . . .	1-35
Unshift on space function pawl . . . . .	1-77
Vertical positioning lock lever . . . . .	1-49
b. Spring Tensions:	
Breaker slide bail . . . . .	1-40
Carriage return . . . . .	1-51
Carriage return latch bail . . . . .	1-52
Clutch latch lever. . . . .	1-31
Clutch shoe . . . . .	1-37
Clutch shoe lever . . . . .	1-37
Clutch trip lever . . . . .	1-34
Code bar clutch cam follower. . . . .	1-32
Code bar detent. . . . .	1-78
Code bar yield . . . . .	1-78
Common transfer lever . . . . .	1-27
Decelerating slide. . . . .	1-57
Function bar . . . . .	1-67
Function contact . . . . .	1-76
Function lever . . . . .	1-67
Function pawl . . . . .	1-67
Horizontal positioning drive linkage . . . . .	1-48
Horizontal positioning lock lever . . . . .	1-40
Horizontal stop slide. . . . .	1-74
Keyboard lock lever . . . . .	1-54
Line feed bar bell crank . . . . .	1-69
Line feed bar release lever . . . . .	1-69
Line feed stripper bail . . . . .	1-71
Lower wire rope pulley bail . . . . .	1-50
Marking lock lever . . . . .	1-22
Paper finger . . . . .	1-75
Paper straightener lever . . . . .	1-74
Paper pressure bail . . . . .	1-75
Platen detent bail . . . . .	1-69
Pressure roller lever . . . . .	1-75
Printing hammer operating bail . . . . .	1-61
Printing hammer operating bail latch . . . . .	1-61
Printing hammer plunger . . . . .	1-61
Printing hammer yield . . . . .	1-61



CONTENTS

Paragraph	Page
Push lever reset bail . . . . .	1-24
Reversing slide detent . . . . .	1-47
Ribbon feed lever . . . . .	1-65
Ribbon lever . . . . .	1-66
Ribbon ratchet wheel friction . . . . .	1-65
Ribbon reverse detent lever . . . . .	1-64
Ribbon tension spring . . . . .	1-66
Selector armature . . . . .	1-22
Selector clutch latch lever . . . . .	1-24
Selector lever . . . . .	1-23
Selector push lever . . . . .	1-23
Shift linkage . . . . .	1-60
Single - double line feed stripper bail assembly . . . . .	1-72
Spacing feed pawl . . . . .	1-43
Spacing feed pawl release link . . . . .	1-51
Spacing lock lever . . . . .	1-24
Spacing suppression bail . . . . .	1-71
Spacing trip lever . . . . .	1-44
Spacing trip lever bail . . . . .	1-44
Start lever . . . . .	1-26
Transfer lever . . . . .	1-27
Transfer slide . . . . .	1-54
Trip shaft lever . . . . .	1-31
Type box carriage roller arm . . . . .	1-58
Type pallet . . . . .	1-62
Vertical positioning lever . . . . .	1-41
Vertical positioning lock lever . . . . .	1-42
 5. MOTORS . . . . .	 1-80
a. Adjustments:	
Governed motor positioning . . . . .	1-80
Governed motor speed . . . . .	1-81
Governor contact . . . . .	1-80
Governor contact backstop . . . . .	1-80
Synchronous motor positioning . . . . .	1-80
b. Spring Tensions:	
Governor brush . . . . .	1-81
 6. CABINET . . . . .	 1-82
a. Adjustments:	
Copyholder . . . . .	1-85
Copy lamp . . . . .	1-85
Counter balance . . . . .	1-84
Cradle . . . . .	1-82
Detent . . . . .	1-84
Dome . . . . .	1-83
Dome catch . . . . .	1-83

## CONTENTS

Paragraph	Page
Indicator lamp . . . . .	1-85
Remote signal bell . . . . .	1-82
Small door . . . . .	1-84
Small door catch . . . . .	1-83
Small door stop arm . . . . .	1-84
Window and paper guide . . . . .	1-85
b. Spring Tensions:	
Armature . . . . .	1-82
7. ELECTRICAL SERVICE UNIT . . . . .	1-86
a. Adjustment:	
Start magnet core . . . . .	1-86
b. Spring Tensions:	
Intermediate lever . . . . .	1-86
Start armature . . . . .	1-86
Stop armature . . . . .	1-86
8. PAPER AND RIBBON . . . . .	1-87
Path of paper . . . . .	1-88
Path of ribbon . . . . .	1-88
9. TOOLS . . . . .	1-89
10. DISASSEMBLY AND REASSEMBLY . . . . .	1-89
a. Typing Unit:	
Code bars . . . . .	1-91
Code bar positioning mechanism . . . . .	1-94
Front plate . . . . .	1-90
Function bar, pawl and lever . . . . .	1-91
Lower draw wire rope . . . . .	1-93
Main shaft . . . . .	1-92
Platen (friction feed) . . . . .	1-93
Platen (sprocket feed) . . . . .	1-93
Printing carriage . . . . .	1-89
Selector cam - clutch . . . . .	1-94
Selector magnet assembly . . . . .	1-95
Selector mechanism . . . . .	1-94
Stunt box . . . . .	1-90
Type box . . . . .	1-89
Type box carriage . . . . .	1-90
Upper draw wire rope . . . . .	1-92
b. Keyboard (Earlier Design):	
Code bar . . . . .	1-97

CONTENTS

Paragraph	Page
Keyboard code bar assembly . . . . .	1-97
Keyboard label . . . . .	1-95
Keyboard lockball channel . . . . .	1-96
Keyboard lock - local line feed mechanism . . . . .	1-97
Keyboard selector cam assembly . . . . .	1-95
Keylever . . . . .	1-96
Keylever cover . . . . .	1-95
Keylever guide plate . . . . .	1-96
Sealing plate . . . . .	1-96
Signal generator . . . . .	1-95
Space bar . . . . .	1-96
c. Keyboard (New Design):	
Contact box . . . . .	1-99
Keyboard . . . . .	1-98
Keylever guide plate . . . . .	1-99
Keyboard labels . . . . .	1-98
Signal generator . . . . .	1-97
Signal generator shaft . . . . .	1-99
Transfer lever locking bail . . . . .	1-99
d. Motor:	
Governed . . . . .	1-100
Synchronous . . . . .	1-100
e. Electrical Service Unit: . . . . .	1-100

SECTION 2

VARIABLE FEATURE ADJUSTMENTS

1. REPEAT ON SPACE MECHANISM (Spring tension) . . . . .	2-1
2. TIME DELAY MECHANISM . . . . .	2-2
a. Adjustments:	
Time delay disabling device . . . . .	2-5
Time delay mechanism position . . . . .	2-4
Time delay switch position . . . . .	2-2
b. Spring Tensions:	
Contact latch pawl . . . . .	2-3
Contact pawl . . . . .	2-3
Eccentric follower pawl . . . . .	2-5
Time delay ratchet wheel . . . . .	2-2
3. SIGNAL LINE BREAK MECHANISM . . . . .	2-6

CONTENTS

Paragraph	Page
a. Adjustment:	
Lever extension . . . . .	2-6
b. Spring Tension:	
Break keylever . . . . .	2-6
4. PAPER FEED-OUT MECHANISM (switch lever spring) . . . . .	2-7
5. SPROCKET FEED MECHANISM . . . . .	2-8
a. Adjustments:	
Copy window (cabinet) . . . . .	2-14
Front form guide (cabinet). . . . .	2-13
Guide bracket (cabinet). . . . .	2-13
Left margin . . . . .	2-9
Line feed spur gear detent eccentric . . . . .	2-10
Paper finger or guide bracket . . . . .	2-11
Paper guide . . . . .	2-12
Platen end play . . . . .	2-10
Printed line . . . . .	2-10
Printing carriage position . . . . .	2-9
Printing hammer stop bracket . . . . .	2-9
Rear form guide (cabinet) . . . . .	2-13
Ribbon reverse detent. . . . .	2-12
Ribbon reverse spur gear . . . . .	2-12
Right margin . . . . .	2-9
Sprocket pin separation . . . . .	2-10
Type box alignment . . . . .	2-9
Type box position . . . . .	2-8
b. Spring Tensions:	
Line feed bar bell crank . . . . .	2-12
Paper finger or guide bracket latch . . . . .	2-15
Paper finger or guide bracket shaft . . . . .	2-15
Platen detent bail . . . . .	2-15
Sprocket pin . . . . .	2-12
6. HORIZONTAL TABULATOR MECHANISM . . . . .	2-16
a. Adjustments:	
Cam arm stripper bail. . . . .	2-19
Latch bail adjusting plate . . . . .	2-18
Operating lever adjusting plate . . . . .	2-17
Operating lever slide arm . . . . .	2-17
Right margin . . . . .	2-20
Spacing clutch trip lever . . . . .	2-16
Spacing cut-out transfer bail set collar . . . . .	2-19
Tabulator pawl - horizontal (final) . . . . .	2-23

CONTENTS

Paragraph	Page
Tabulator pawl (preliminary) . . . . .	2-21
Tabulator pawl - vertical (final) . . . . .	2-22
Tabulator stop settings . . . . .	2-24
Transmitter control contact gap . . . . .	2-25
Trip lever arm latch bail . . . . .	2-18
b. Spring Tensions:	
Blocking lever . . . . .	2-22
Clutch trip lever . . . . .	2-16
Horizontal tabulator slide arm . . . . .	2-19
Intermediate bail . . . . .	2-18
Operating lever cam arm . . . . .	2-19
Operating lever slide arm . . . . .	2-17
Space suppression by-pass . . . . .	2-20
Tabulator pawl . . . . .	2-22
Transmitter control contact . . . . .	2-25
Trip lever arm latch bail . . . . .	2-18
<b>7. PAGE FEED OUT MECHANISM . . . . .</b>	<b>2-26</b>
a. Adjustments:	
Blocking arm . . . . .	2-27
Indexing disk . . . . .	2-26
Mounting bracket . . . . .	2-26
Page feed-out gear play . . . . .	2-26
Pointer . . . . .	2-27
Switch operating arm . . . . .	2-26
b. Spring Tension:	
Blocking arm . . . . .	2-27
<b>8. SELECTIVE CALLING MECHANISM . . . . .</b>	<b>2-28</b>
a. Adjustments:	
Blocking bail . . . . .	2-29
Code bar shift mechanism . . . . .	2-28
Condition code (zero) code bar shift mechanism . . . . .	2-28
Off line shift bracket assembly . . . . .	2-28
Type bar clutch suppressor arm . . . . .	2-29
Type box clutch trip lever . . . . .	2-28
b. Spring Tensions:	
Automatic carriage return - line feed blocking slide . . . . .	2-30
Condition code shift fork . . . . .	2-30
Off line stunt shift solenoid . . . . .	2-29
Suppressor code bar . . . . .	2-28
<b>9. LOCAL BACK SPACE MECHANISM . . . . .</b>	<b>2-31</b>

## CONTENTS

Paragraph	Page
a. Adjustments:	
Camming bail stop arm . . . . .	2-33
Transfer bail adjusting lever . . . . .	2-32
b. Spring Tensions:	
Back space transfer bail . . . . .	2-31
Backspace space trip link horizontal . . . . .	2-31
Back space trip link vertical . . . . .	2-31
Camming bail . . . . .	2-33
10. REVERSE LINE FEED MECHANISM . . . . .	2-34
a. Adjustments:	
Line feed clutch spur gear . . . . .	2-35
Line feed spur gear detent eccentric . . . . .	2-36
Reverse line feed slide link stop bracket . . . . .	2-34
b. Spring Tensions:	
Line feed bar . . . . .	2-37
Line feed bar bell crank . . . . .	2-37
Line feed bar release lever . . . . .	2-36
Platen detent bail . . . . .	2-36
Reverse line feed slide link . . . . .	2-34
Reverse line feed trip link horizontal . . . . .	2-34
Reverse line feed trip link vertical . . . . .	2-34
11. MOTOR CONTROL RELAY MECHANISM . . . . .	2-38
a. Adjustments:	
Inner contact spring gap . . . . .	2-38
Switch position . . . . .	2-38
b. Spring Tensions:	
Middle contact . . . . .	2-38
Outer contact . . . . .	2-38
12. END-OF-FORM ALARM MECHANISM (Cabinet) . . . . .	2-39
13. OFF-SET COPYHOLDER . . . . .	2-40
a. Adjustments:	
Copyholder bracket and top bracket alignment . . . . .	2-40
Pivot arm and line guide . . . . .	2-40
14. DIRECTORY HOLDER (TWX) . . . . .	2-40

CONTENTS

Paragraph	Page
15. PRINT SUPPRESSION DURING SELECTION . . . . .	2-41
a. Adjustments:	
Suppression code bar mechanism . . . . .	2-41
Zero code bar shift mechanism . . . . .	2-41
16. CONTINUOUS SPACING . . . . .	2-42
a. Adjustments:	
Carriage return lever . . . . .	2-43
Function clutch trip lever . . . . .	2-42
Suppression bail adjusting bracket . . . . .	2-43
b. Spring Tensions:	
Reset bail operating . . . . .	2-43
Solenoid plunger . . . . .	2-42
17. LINE TEST KEY . . . . .	2-44
18. PAPER OUT ALARM . . . . .	2-44
19. OFF-LINE CONTACTS . . . . .	2-45
a. Adjustments:	
Back space keylever operated switch position . . . . .	2-46
Contact bracket . . . . .	2-45
Solenoid mounting bracket position . . . . .	2-45
Solenoid operated switch plate position . . . . .	2-46
b. Spring Tensions:	
Code bar . . . . .	2-46
Contact . . . . .	2-46
Operating lever . . . . .	2-46
Solenoid bail . . . . .	2-45

SECTION 3 - LUBRICATION

1. GENERAL . . . . .	3-1
2. DISASSEMBLY . . . . .	3-2
2.02 Base disassembly . . . . .	3-2
2.01 Cabinet disassembly . . . . .	3-2
2.03 Keylever cover disassembly . . . . .	3-2
3. CABINET . . . . .	3-3
3.01 Electrical service unit . . . . .	3-3

## CONTENTS

Paragraph	Page
4. KEYBOARD - EARLIER DESIGN (see paragraph 7) . . . . .	3-4 through 3-10
4.09 Code bar mechanism . . . . .	3-6
4.10 Code bar mechanism . . . . .	3-6
4.11 Code bar mechanism . . . . .	3-6
4.12 Code bar mechanism . . . . .	3-7
4.13 Code bar mechanism . . . . .	3-7
4.02 Code lever mechanism . . . . .	3-4
4.08 Contact box . . . . .	3-6
4.01 Keyboard - bottom view . . . . .	3-4
4.05 Keyboard lock mechanism . . . . .	3-5
4.14 Keyboard selector mechanism . . . . .	3-7
4.06 Keyboard - top view . . . . .	3-5
4.03 Local carriage return mechanism . . . . .	3-4
4.04 Local line feed mechanism . . . . .	3-5
4.07 Margin indicating mechanism . . . . .	3-5
4.15 Signal generator mechanism . . . . .	3-8
4.16 Signal generator mechanism . . . . .	3-8
4.17 Signal generator mechanism . . . . .	3-8
4.18 Signal generator mechanism . . . . .	3-9
4.19 Signal generator mechanism . . . . .	3-9
4.20 Signal generator mechanism . . . . .	3-10
4.21 Signal generator mechanism . . . . .	3-10
4.22 Time delay mechanism . . . . .	3-10
5. TYPING UNIT . . . . .	3-11 through 3-33
5.31 Carriage return mechanism . . . . .	3-24
5.32 Carriage return mechanism . . . . .	3-24
5.33 Carriage return mechanism . . . . .	3-24
5.05 Code bar mechanism . . . . .	3-13
5.06 Code bar mechanism . . . . .	3-13
5.07 Code bar mechanism . . . . .	3-14
5.08 Code bar mechanism . . . . .	3-14
5.19 Code bar mechanism . . . . .	3-19
5.28 Function rocker shaft mechanism . . . . .	3-22
5.35 Horizontal positioning mechanism . . . . .	3-25
5.36 Horizontal positioning mechanism . . . . .	3-26
5.37 Horizontal positioning mechanism . . . . .	3-26
5.38 Horizontal positioning mechanism . . . . .	3-26
5.15 Left ribbon feed mechanism . . . . .	3-17
5.16 Left ribbon feed mechanism . . . . .	3-17
5.40 Letters - figures shift mechanism . . . . .	3-27
5.41 Letters - figures shift mechanism . . . . .	3-28
5.54 Line feed mechanism . . . . .	3-33
5.45 Main shaft . . . . .	3-30
5.46 Main shaft . . . . .	3-30
5.48 Main shaft . . . . .	3-31
5.42 Oscillating mechanism . . . . .	3-28
5.43 Oscillating mechanism . . . . .	3-29
5.09 Paper feed mechanism . . . . .	3-14
5.02 Printing mechanism . . . . .	3-11
5.03 Printing mechanism . . . . .	3-12



## CONTENTS

Paragraph	Page
5.26 Ribbon reverse mechanism . . . . .	3-21
5.12 Right ribbon feed mechanism . . . . .	3-15
5.13 Right ribbon feed mechanism . . . . .	3-16
5.47 Selector cam-clutch assembly . . . . .	3-30
5.20 Selector mechanism . . . . .	3-19
5.21 Selector mechanism . . . . .	3-20
5.27 Shift mechanism . . . . .	3-22
5.30 Spacing drum drive mechanism (earlier design) . . . . .	3-23
5.50 Spacing mechanism . . . . .	3-32
5.51 Spacing mechanism . . . . .	3-32
5.52 Spacing mechanism . . . . .	3-32
5.24 Stunt box mechanism . . . . .	3-21
5.25 Stunt box mechanism . . . . .	3-21
5.04 Type box carriage mechanism . . . . .	3-12
5.29 Typing unit - bottom view . . . . .	3-23
5.44 Typing unit - bottom view . . . . .	3-29
5.49 Typing unit - bottom view . . . . .	3-31
5.01 Typing unit - front view . . . . .	3-11
5.34 Typing unit - front view . . . . .	3-25
5.39 Typing unit - front view . . . . .	3-27
5.10 Typing unit - left view . . . . .	3-15
5.22 Typing unit - rear view . . . . .	3-20
5.23 Typing unit - rear view . . . . .	3-20
5.53 Typing unit - rear view . . . . .	3-33
5.11 Typing unit - right view . . . . .	3-15
5.18 Typing unit - right view . . . . .	3-18
5.17 Vertical positioning mechanism - left view . . . . .	3-18
5.14 Vertical positioning mechanism - right view . . . . .	3-16
 6. VARIABLE FEATURES . . . . .	 3-34 through 3-54
6.36 Base - top view . . . . .	3-49
6.38 Cabinet - dome open . . . . .	3-50
6.41 Continuous spacing mechanism . . . . .	3-51
6.42 Continuous spacing mechanism . . . . .	3-51
6.43 Continuous spacing mechanism . . . . .	3-51
6.39 End-of-form alarm mechanism . . . . .	3-50
6.54 Horizontal tabulator bail extension arm . . . . .	3-54
6.47 Horizontal tabulator blocking lever . . . . .	3-53
6.52 Horizontal tabulator intermediate bail . . . . .	3-54
6.50 Horizontal tabulator latch bail . . . . .	3-54
6.49 Horizontal tabulator operating lever . . . . .	3-53
6.51 Horizontal tabulator operating lever . . . . .	3-54
6.12 Horizontal tabulator (early) operating lever . . . . .	3-38
6.48 Horizontal tabulator slide arm . . . . .	3-53
6.53 Horizontal tabulator spacing cut-out transfer bail . . . . .	3-54
6.10 Horizontal tabulator (early) space suppression mechanism . . . . .	3-37
6.13 Horizontal tabulator (early) spacing clutch mechanism . . . . .	3-39
6.53 Horizontal tabulator spacing cut-out transfer bail . . . . .	3-54
6.09 Horizontal tabulator (early) shaft mechanism . . . . .	3-37
6.01 Keyboard - rear view . . . . .	3-34
6.22 Keyboard - top view . . . . .	3-43
6.23 Local backspace mechanism . . . . .	3-44

## CONTENTS

Paragraph	Page
6.26 Local backspace mechanism . . . . .	3-45
6.29 Local backspace mechanism . . . . .	3-46
6.24 Local reverse line feed mechanism . . . . .	3-44
6.28 Local reverse line feed mechanism . . . . .	3-46
6.32 Local reverse line feed mechanism . . . . .	3-47
6.55 Off-line contacts . . . . .	3-55
6.58 Off-line contacts - contact insulators . . . . .	3-55
6.56 Off-line contacts - keyboard - top view . . . . .	3-55
6.57 Off-line contacts - solenoid bail . . . . .	3-55
6.59 Off-line contacts - switch operating lever . . . . .	3-55
6.34 Page feed-out mechanism . . . . .	3-48
6.37 Paper feed-out mechanism (keyboard) . . . . .	3-49
6.40 Paper out alarm mechanism . . . . .	3-50
6.31 Paper spindle latch mechanism . . . . .	3-47
6.02 Repeat on space mechanism . . . . .	3-34
6.21 Selective calling - clutch suppression . . . . .	3-43
6.19 Selective calling - function reset bail . . . . .	3-42
6.16 Selective calling - shift and stripper bail . . . . .	3-40
6.18 Selective calling - single-double line feed . . . . .	3-41
6.15 Selective calling - stripper bail . . . . .	3-40
6.35 Signal line break mechanism (base) . . . . .	3-49
6.03 Signal line break mechanism (electrical) . . . . .	3-34
6.05 Sprocket feed-line feed mechanism . . . . .	3-35
6.06 Sprocket feed-paper guide mechanism . . . . .	3-36
6.11 Typing unit (early) bottom view . . . . .	3-38
6.27 Typing unit - bottom view . . . . .	3-45
6.46 Typing unit - bottom view . . . . .	3-52
6.07 Typing unit - front view . . . . .	3-36
6.25 Typing unit - front view . . . . .	3-44
6.45 Typing unit - front view . . . . .	3-52
6.20 Typing unit - left view . . . . .	3-42
6.33 Typing unit - left view . . . . .	3-48
6.04 Typing unit - rear view . . . . .	3-35
6.30 Typing unit - rear view . . . . .	3-47
6.14 Typing unit - rear view . . . . .	3-39
6.17 Typing unit - rear view . . . . .	3-41
6.44 Typing unit - rear view . . . . .	3-51
6.08 Universal drum mechanism (new design) . . . . .	3-37
 7. KEYBOARD - NEW DESIGN . . . . .	 3-55 through 3-64
7.04 Break lever mechanism . . . . .	3-57
7.08 Code bar . . . . .	3-58
7.22 Code bar bail . . . . .	3-62
7.05 Code lever mechanism . . . . .	3-57
7.26 Code lever universal bail . . . . .	3-64
7.13 Contact box . . . . .	3-60
7.25 Electrical line break . . . . .	3-63
7.15 Function clutch . . . . .	3-60
7.19 Intermediate gear mechanism . . . . .	3-61
7.01 Keyboard - bottom view . . . . .	3-56
7.24 Keyboard - left view . . . . .	3-63
7.06 Keyboard lock mechanism . . . . .	3-57

## CONTENTS

Paragraph	Page
7.10 Keyboard - rear view - signal generator . . . . .	3-59
7.20 Keyboard - right view . . . . .	3-62
7.07 Keyboard - top view . . . . .	3-58
7.03 Keylever mechanism. . . . .	3-56
7.09 Local carriage return . . . . .	3-58
7.17 Local line feed mechanism . . . . .	3-61
7.28 Local paper feed-out mechanism . . . . .	3-64
7.27 Lock bar latch . . . . .	3-64
7.21 Locking bail . . . . .	3-62
7.16 Margin indicating mechanism . . . . .	3-61
7.11 Non-repeat lever . . . . .	3-59
7.18 Shaft mechanism . . . . .	3-51
7.02 Space bar . . . . .	3-56
7.14 Transfer bail . . . . .	3-60
7.12 Transfer lever . . . . .	3-59
7.23 Universal bail latch lever . . . . .	3-63

## SECTION 4 - EARLIER DESIGN MECHANISM ADJUSTMENTS

1. KEYBOARD . . . . .	4-1
a. Adjustments:	
Clutch shoe lever . . . . .	4-7
Clutch stop lever . . . . .	4-8
Code bar bail adjusting screw . . . . .	4-11
Code bar bail bumper . . . . .	4-17
Code bar bounce suppressor bracket support screw. . . . .	4-18
Code bar guides . . . . .	4-15
Code bar latch . . . . .	4-18
Code lever bail . . . . .	4-19
Code lever bail latch lever eccentric . . . . .	4-15
Code lever bail non-repeat extension . . . . .	4-16
Code lever guide. . . . .	4-18
Detent toggle stop bracket. . . . .	4-4
Flutter lever. . . . .	4-6
Generator contact . . . . .	4-10
Intermediate gear bracket . . . . .	4-20
Intermediate lever stop plate. . . . .	4-5
Keylever lock-ball channel and lock-ball end play . . . . .	4-14
Non-repeat lever . . . . .	4-13
Rocker bail detent . . . . .	4-2
Rocker bail pivot screw . . . . .	4-1
Rocker extension . . . . .	4-3
Space bar pivot . . . . .	4-19
Selector lever guide . . . . .	4-1
b. Spring Tensions:	
Clutch latch lever . . . . .	4-9
Clutch stop lever . . . . .	4-8
Clutch trip bar . . . . .	4-17
Code bar . . . . .	4-17

## CONTENTS

Paragraph	Page
Code bar bail . . . . .	4-12
Code bar bail latch. . . . .	4-12
Code bar latch . . . . .	4-18
Code lever . . . . .	4-16
Code lever bail . . . . .	4-15
Code lever bail latch lever . . . . .	4-13
Contact box. . . . .	4-10
Detent lever . . . . .	4-5
Flutter lever . . . . .	4-6
Intermediate lever . . . . .	4-3
Local carriage return bail . . . . .	4-21
Local line feed trip link. . . . .	4-21
Lock bail . . . . .	4-21
Lock bar . . . . .	4-17
Locking bail. . . . .	4-1
Margin indicator . . . . .	4-22
Non-repeat . . . . .	4-13
Over-load mechanism. . . . .	4-20
Paper feed-out motor start mechanism . . . . .	4-22
Reset lever . . . . .	4-11
Selector lever . . . . .	4-1
Transfer lever . . . . .	4-2
2. TYPING UNIT. . . . .	4-23
a. Adjustments:	
Automatic carriage return and line feed arm . . . . .	4-35
Bail lever guide . . . . .	4-23
Bell or motor stop function contact . . . . .	4-37
Code bar shift lever drive arm . . . . .	4-24
Code bar shift lever link bracket . . . . .	4-25
Function reset bail blade . . . . .	4-28
Function stripper blade arm . . . . .	4-35
Horizontal positioning drive linkage . . . . .	4-29
Left margin . . . . .	4-30
Margin indicator lamp . . . . .	4-39
Oscillating rail slide position . . . . .	4-26
Printing arm . . . . .	4-33
Printing hammer stop bracket . . . . .	4-33
Ribbon reverse detent. . . . .	4-34
Ribbon reverse spur gear. . . . .	4-34
Right margin. . . . .	4-31
Shift code bar operating mechanism. . . . .	4-27
Single-double line feed lever . . . . .	4-36
Type box carriage roller. . . . .	4-32
 b. Spring Tensions:	
Automatic CR-LF bell crank . . . . .	4-30
Decelerating slide bell crank . . . . .	4-31
Function contact . . . . .	4-38
Horizontal positioning drive linkage . . . . .	4-29

CONTENTS

Paragraph	Page
Ribbon reverse detent lever . . . . .	4-34
Shift linkage . . . . .	4-32
Spacing cut-out transfer bail . . . . .	4-31
Spacing feed pawl . . . . .	4-26
Start lever . . . . .	4-23
Type pallet . . . . .	4-33
 3. VARIABLE FEATURES . . . . .	 4-40
Horizontal tabulator . . . . .	4-45
a. Adjustments:	
Cam plate stripper bail . . . . .	4-47
Columnar tabulator stops . . . . .	4-50
Operating lever adjusting plate . . . . .	4-45
Operating lever slide arm . . . . .	4-45
Pawl mounting arm operating range (final) . . . . .	4-50
Pawl mounting arm operating range (preliminary) . . . . .	4-49
Right margin . . . . .	4-48
Spacing cut-out transfer bail set collar . . . . .	4-47
Tabulator shaft mounting brackets . . . . .	4-48
Tabulator stop setting. . . . .	4-50
Trip arm latch bail . . . . .	4-46
Trip arm latch bail adjusting plate . . . . .	4-46
b. Spring Tensions:	
Horizontal tabulator slide arm . . . . .	4-47
Operating lever cam plate . . . . .	4-47
Operating lever extension link. . . . .	4-45
Space suppression by-pass . . . . .	4-48
Tabulator pawl . . . . .	4-48
Tabulator shaft . . . . .	4-45
Trip arm latch bail . . . . .	4-46
Miscellaneous features . . . . .	4-40
a. Adjustments:	
Back space transfer bail adjusting lever - vertical adjustment . . . . .	4-43
Back space transfer bail adjusting lever - horizontal adjustment. . . . .	4-44
Repeat-on-space lever . . . . .	4-40
Time delay disabling device . . . . .	4-41
b. Spring Tensions:	
Back space transfer bail. . . . .	4-43
Back space trip link horizontal. . . . .	4-43
Back space trip link vertical. . . . .	4-43
Break keylever . . . . .	4-42
Break lever . . . . .	4-42
Eccentric follower pawl. . . . .	4-41
Repeat-on-space lever . . . . .	4-40



## SECTION 1 - STANDARD UNIT ADJUSTMENTS

## 1. GENERAL

a. The adjustments of each unit are arranged in a sequence that would be followed if a complete re-adjustment of the unit were undertaken. Tools and spring scales required to perform the adjustments are listed in Teletype bulletin 1124B but are not supplied as part of the equipment. After an adjustment has been completed, be sure to tighten any nuts or screws that may have been loosened. The adjusting illustrations, in addition to indicating the adjusting tolerances, positions of moving parts, and spring tension, also show the angle at which the scale should be applied when measuring spring tensions. If a part that is mounted on shims is to be removed, the number of shims used at each of its mounting screws should be noted so that the same shim pile-up can be replaced when the part is remounted.

b. The spring tensions given in this specification are indicated values and should be checked with proper spring scales in the position indicated.

## NOTE

When rotating the main shaft of the Typing Unit by hand, the clutches do not fully DISENGAGE upon reaching their stop positions. In order to relieve the drag on the clutches and permit the main shaft to ROTATE freely, apply pressure on the lug of each clutch disk (Figure 1-35) with a screwdriver to cause it to ENGAGE its latch lever and thus fully DISENGAGE the internal expansion clutch. This procedure should always be followed prior to placing the Typing Unit on the base and switching on the power.

c. References made to LEFT or RIGHT, UP or DOWN, FRONT or REAR, etc. apply to the unit in its normal operating position as viewed from the operator's position in front of the unit.

d. When the requirement calls for a clutch to be disengaged, the clutch shoe lever must be fully latched between its trip lever and latch lever so that the clutch shoes (Figure 1-35) release their tension on the clutch drum. When engaged, the clutch shoe lever is unlatched and the clutch shoes are wedged firmly against the clutch drum.

e. The Typing Unit may be safely placed in any

one of three positions for servicing: (1) in upright position on its four feet. (2) tilted backward so that it rests on its rear feet and rear points of side frames, (3) bottom upwards so that it rests on two upper points of each side frame.

f. When cleaning plastic parts, use soap or detergent and water. Do not use solvents containing alcohol or chlorinated compounds.

g. Reference made to KEYBOARD means Keyboard base or sending and receiving base. Reference to BASE means receiving only base.

h. Where instructions call for the removal of parts or subassemblies, refer to Disassembly and Reassembly Paragraph 10. Page 1-89.

## i. MANUAL SELECTION OF CHARACTERS OR FUNCTIONS

(1) To manually operate the Typing Unit while removed from Keyboard or Base hold the selector magnet armature (Figure 1-17) operated by means of an armature clip and rotate the main shaft in a counter-clockwise direction (by means of the handwheel listed in bulletin 1124B) to bring all clutches to their disengaged position.

## NOTE

The armature clip is attached to the armature by carefully inserting the flat-formed end of the clip over the top of the armature between the pole pieces and hooking the extruded projection under the edge of the armature. The top end of the clip should then be hooked over the top of the selector coil terminal bakelite guard. The spring tension of the clip will hold the armature in the marking (attracted) position.

(2) Fully disengage all clutches as described in the preceding note. Release armature momentarily to permit the selector clutch to engage. Turn the main shaft slowly until the No. 5 selector lever has just moved to the peak of its cam. Strip from the selector levers the push levers which are spacing in the code combination of the character or function that is being selected. It should be noted that selector levers (Figure 1-24) move in succession starting with the inner (Number One). Continue to rotate main shaft until all operations initiated by selector action clear through unit.

j. VARIABLE FEATURES

In addition to standard unit adjustments, which are covered in section 1 of this bulletin, adjustments for a number of Variable Features appear in Section 2. Where adjustments of these Variable Features affect the adjusting sequence, cross reference information has been included in Section 1. Variable Feature adjustments which do not affect the adjusting sequence may be done at any time during the adjusting pro-



cedure.

k. EARLIER DESIGNED MECHANISMS

Section 1 contains illustrations and adjusting procedure for mechanism currently being manufactured. Illustrations and adjusting procedure for mechanisms of earlier design are located in section 4. Where a new mechanism has replaced one of earlier design, reference has been made in section 1 to the corresponding mechanism in section 4.




2. KEYBOARD (NEW DESIGN)\*



\* See page 1-2 Paragraph k.

FIGURE 1-1 KEYBOARD, CODE BAR AND SPACE BAR MECHANISMS



**CLUTCH SHOE LEVER  
REQUIREMENT**

CLEARANCE WHEN CLUTCH IS DISENGAGED SHOULD BE 0.055  
INCH TO 0.085 INCH LESS THAN WHEN CLUTCH IS ENGAGED.

**TO CHECK**

LATCH CLUTCH IN DISENGAGED POSITION AND MEASURE  
CLEARANCE. ROTATE GEAR UNTIL OIL HOLE IS UPWARD.  
ENGAGE CLUTCH AND MEASURE CLEARANCE.

**TO ADJUST**

LOOSEN THE TWO ADJUSTING DISK CLAMP SCREWS TO PO-  
SITION DISK.

**NOTE:**

AFTER ABOVE ADJUSTMENT IS MADE, CHECK FOR DRAG ON  
DRUM AS FOLLOWS: DISENGAGE CLUTCH. HOOK SPRING  
SCALE ON TOP TOOTH OF GEAR AND PULL AT RIGHT ANGLE  
TO RADIUS OF GEAR. IF PULL OF 8 OZS. OR MORE IS RE-  
QUIRED TO MOVE THE DRUM, REFINE ABOVE ADJUSTMENT.




FIGURE 1-2 KEYBOARD, SIGNAL GENERATOR CLUTCH AND GEAR MECHANISM










FIGURE 1-3 KEYBOARD, SIGNAL GENERATOR CLUTCH AND LEVER MECHANISM




(D) CONTACT BOX DRIVE LINK SPRING TENSION

REQUIREMENT  
 SPRING REMOVED FROM LINK  
 MIN. 11 OZS.  
 MAX. 13 OZS.  
 AT .438 INCH

(E) CONTACT BOX SPRING TENSION

REQUIREMENT  
 TRANSFER BAIL HELD CLEAR OF DRIVE LINK.  
 MIN. 2 OZS.  
 MAX. 3 OZS.  
 TO START LINK MOVING.

FIGURE 1-4 KEYBOARD, TRANSFER BAIL AND CONTACT BOX MECHANISM



(A) CLUTCH TRIP BAR SPRING TENSION  
REQUIREMENT


CLUTCH DISENGAGED, POWER OFF.  
MIN. 9 OZS.  
MAX. 12 OZS.  
TO MOVE BAR.

(B) CODE BAR SPRING TENSION  
REQUIREMENT

LETTERS KEYLEVER DEPRESSED.  
MIN. 3 OZS.  
MAX. 5 OZS.  
TO START CODE BAR MOVING.

(C) LOCK BAR SPRING TENSION  
REQUIREMENT


CLUTCH DISENGAGED. KEYBOARD LOCK KEYLEVER DEPRESSED.  
MIN. 4 OZS.  
MAX. 7 OZS.  
TO START LOCK BAR MOVING.



(D) CODE BAR AND CODE LEVER CLEARANCE  
REQUIREMENT

CARRIAGE RETURN KEY DEPRESSED BUT NOT ENOUGH TO TRIP OFF  
UNIVERSAL BAIL LATCH OR CLUTCH BAR.  
MIN. 0.006 INCH.  
MAX. 0.015 INCH.  
MEASURED AT CODE BAR #5.  
TO ADJUST  
POSITION GUIDE BY ADJUSTING SLOT WITH (4) MOUNTING SCREWS  
LOOSENED.

FIGURE 1-5 KEYBOARD, CODE BAR AND CODE LEVER MECHANISM



NOTE: THIS ADJUSTMENT SHOULD NOT BE MADE UNLESS THE LOCK BALL CHANNEL HAS BEEN DISASSEMBLED.

(B) LOCK BALL CHANNEL


REQUIREMENT

THERE SHOULD BE SOME TO 0.006 INCH CLEARANCE BETWEEN END OF LOCK BALL CHANNEL AND ADJUSTING SCREW WHEN MOST OF THE CODE LEVERS ARE CENTRALLY LOCATED IN THE LOCK BALL CHANNEL SLOTS.

TO CHECK

REMOVE THE LOCK BALL RETAINER. REMOVE A WEDGE FROM EACH END AND ONE FROM THE CENTER IN ORDER TO VIEW THE POSITION OF THE CODE LEVER.


MOUNTING SCREW




TO ADJUST

LOOSEN THE LOCK BALL CHANNEL MOUNTING SCREWS. BACK OFF LATERAL ADJUSTING SCREWS AND POSITION CHANNEL. TURN ONE ADJUSTING SCREW IN AGAINST THE END OF THE CHANNEL AND LOCK IT. TURN THE OTHER ADJUSTING SCREW IN TO THE END OF THE CHANNEL AND BACK IT OFF 1/4 TURN. LOCK THE SCREW. REPLACE THE WEDGES AND CHECK THEIR POSITION WITH RESPECT TO THE BALLS. PULL CHANNEL ASSEMBLY DOWNWARD UNTIL ALL CODE LEVERS STRIKE THEIR UPSTOP WITHOUT WEDGES JUMPING OUT OF POSITION. REPLACE LOCK-BALL RETAINER. BACK OFF BALL END PLAY ADJUSTING SCREW.

FIGURE 1-6 KEYBOARD, FUNCTION BAIL AND LOCK BALL TRACK MECHANISMS



(B) CODE BAR BAIL  
 REQUIREMENT  
 CAM ECCENTRIC AND ARM WHICH HOLD THE BAIL IN EXTREME RESET POSITION TO THE LEFT.  
 MIN. 0.004 INCH  
 MAX. 0.012 INCH  
 BETWEEN CODE BAR BAIL ROLLER AND CODE BAR BAIL LATCH  
 TO ADJUST  
 ADJUST ECCENTRIC STUD WITH LOCK NUT LOOSENED.



(D) CODE BAR BAIL AND NON-REPEAT LEVER CLEARANCE  
 REQUIREMENT  
 MECHANISM IN INITIAL TRIP-OFF POSITION, ANY KEY DEPRESSED,  
 NO POWER.  
 MIN. 0.010 INCH  
 MAX. 0.030 INCH  
 BETWEEN LIP OF CODE BAR BAIL AND NON-REPEAT LEVER PICK-UP STEP  
 TO ADJUST  
 LOOSEN LOCK NUT AND SHOULDER SCREW AND MOVE MECHANISM  
 LEFT OR RIGHT

(FRONT VIEW)

FIGURE 1-7 KEYBOARD, FUNCTION BAIL, CODE BAR BAIL AND NON-REPEAT LEVER MECHANISMS




FIGURE 1-8 KEYBOARD, UNIVERSAL BAIL LATCH LEVER AND LOCAL LINE FEED TRIP LINK MECHANISMS




**(B) LOCK BALL END PLAY****REQUIREMENT (UNDER POWER)**

THE TRIP OFF PRESSURE OF ANY KEYLEVER IN THE THIRD ROW SHOULD BE BETWEEN 3 AND 5 OZS. WITH 6 OZS. OF PRESSURE APPLIED PERPENDICULAR TO THE A KEYLEVER IN THE THIRD ROW AND CR DEPRESSED ALTERNATELY, THE A KEYLEVER SHOULD TRIP EACH TIME. THE CLUTCH SHOULD NOT TRIP WHEN TWO KEYLEVERS ARE DEPRESSED SIMULTANEOUSLY. THE LOCK BALL ADJUSTMENT SHOULD NOT PREVENT THE CODE LEVER OF A DEPRESSED KEY FROM MEETING ITS UPSTOP.

**TO ADJUST**

DEPRESS CR KEYLEVER AGAINST ITS UPSTOP. ROTATE THE ADJUSTING SCREW WITH FINGERS UNTIL A SLIGHT RESISTANCE IS FELT. RELEASE CR KEYLEVER, TURN ADJUSTING SCREW 1/4 TURN AND TIGHTEN LOCK NUT.

**NOTE:** IT MAY BE NECESSARY TO RECHECK CODE BAR BAIL, CODE BAR BAIL AND NON-REPEAT LEVER CLEARANCE, UNIVERSAL BAIL LATCH LEVER, AND UNIVERSAL BAIL EXTENSION.

**(A) BALL WEDGELOCK AND BALL TRACK CLEARANCE****REQUIREMENT**

ADJUSTMENT SCREW BACKED OUT TO PERMIT MAXIMUM BALL MOVEMENT WITHOUT THE BALLS ROLLING OUT OF THE TRACK.

A OR P KEYLEVER FULLY DEPRESSED

MIN. 0.015 INCH.


MAX. 0.020 INCH -

BETWEEN THE TIP OF THE WEDGELOCK AND THE BALL TRACK

**TO ADJUST**


LOOSEN MOUNTING SCREWS AT EACH END OF THE BALL TRACK AND ADJUST TRACK UP OR DOWN

FIGURE 1-9 KEYBOARD, WEDGELOCK AND BALL TRACK MECHANISM



(A) CLUTCH SHOE LEVER SPRING TENSION  
REQUIREMENT

CLUTCH ENGAGED.  
CAM DISK HELD TO PREVENT TURNING.  
MIN. 15 OZS.  
MAX. 20 OZS.  
TO MOVE SHOE LEVER IN CONTACT WITH STOP LUG.



(B) CLUTCH SHOE SPRING TENSION

NOTE

IN ORDER TO CHECK THIS SPRING TENSION, IT IS NECESSARY TO REMOVE THE CLUTCH FROM THE MAIN SIGNAL GENERATOR DRIVE SHAFT. THEREFORE, IT SHOULD NOT BE CHECKED UNLESS THERE IS GOOD REASON TO BELIEVE THAT IT DOES NOT MEET ITS REQUIREMENT.

REQUIREMENT

CLUTCH DRUM REMOVED.  
MIN. 3 OZS.  
MAX. 5 OZS.  
TO START PRIMARY SHOE MOVING AWAY FROM SECONDARY SHOE AT POINT OF CONTACT.

FIGURE 1-10 KEYBOARD, SIGNAL GENERATOR CLUTCH MECHANISM






FIGURE 1-11 KEYBOARD OR BASE, MOTOR AND TYPING UNIT GEARING, LEFT SIDE VIEW



(A) CODE BAR BAIL SPRING TENSION REQUIREMENT  
 CLUTCH DISENGAGED. SPRING UNHOOKED FROM ARM.  
 MIN. 9 OZS.  
 MAX. 11 OZS.  
 TO PULL TO INSTALLED LENGTH.



(B) LINE BREAK LEVER SPRING TENSION REQUIREMENT  
 REQUIREMENT  
 (COMBINED CODE LEVER AND BREAK LEVER SPRING)  
 MIN. 3 OZS.  
 MAX. 4 OZS.  
 TO MOVE SWITCH BREAK LEVER IN CONTACT WITH SWITCH PLUNGER.  
 MIN. 6 OZS.  
 MAX. 8 OZS.  
 TO ACTUATE SENSITIVE SWITCH

FIGURE 1-12 KEYBOARD, CODE BAR BAIL AND LINE BREAK LEVER






FIGURE 1-13 KEYBOARD, CODE LEVER AND LOCAL CARRIAGE FUNCTION BAIL MECHANISMS

(B) TRANSFER LEVER LOCKING BAIL SPRING TENSION REQUIREMENT  
 SPRING UNHOOKED FROM POST.  
 MIN. 5 OZS.  
 MAX. 6 OZS.  
 TO PULL TO INSTALLED LENGTH.

(A) TRANSFER LEVER SPRING TENSION REQUIREMENT  
 CLUTCH DISENGAGED.  
 MIN. 1 1/2 OZS.  
 MAX. 2 1/2 OZS.  
 TO START EACH OF 7 LEVERS MOVING.



(C) MARGIN INDICATOR SPRING TENSION REQUIREMENT  
 MIN. 7 OZS.  
 MAX. 11 OZS.  
 TO START LEVER MOVING.




FIGURE 1-14 KEYBOARD, TRANSFER LEVER AND MARGIN INDICATOR MECHANISMS





FIGURE 1-15 MOUNTING TYPING UNIT ON KEYBOARD OR BASE, TOP VIEW



PLASTIC WINDOW

REQUIREMENT

PLASTIC WINDOW SHOULD BE FULLY SEATED  
IN POSITION BEFORE TIGHTENING MOUNTING SCREW.  
TO ADJUST  
POSITION WINDOW WITH MOUNTING SCREW LOOSENED.

FIGURE 1-16 KEYBOARD, PLASTIC WINDOW



## 3. BASE

THE FOLLOWING KEYBOARD ADJUSTMENTS CONSTITUTE THE ADJUSTMENT FOR THE BASE:

## a. ADJUSTMENTS

## (1) STANDARD

- (a) INTERMEDIATE GEAR BRACKET - FIGURE 1-11
- (b) MOUNTING TYPING UNIT ON BASE - FIGURE 1-15

## (2) VARIABLE FEATURES

- (a) BREAK LEVER EXTENSION - FIGURE 2-6
- (b) TIME DELAY DISABLING DEVICE - FIGURE 2-5
- (c) TIME DELAY MECHANISM POSITION - FIGURE 2-4
- (d) TIME DELAY SWITCH POSITION - FIGURE 2-2

## b. SPRING TENSIONS

## (1) STANDARD

- (a) LOCAL CARRIAGE RETURN BAIL - FIGURE 4-22
- (b) LOCAL LINE FEED TRIP LINK - FIGURE 4-22
- (c) MARGIN INDICATOR - FIGURE 1-14

## (2) VARIABLE FEATURES

- (a) BREAK KEYLEVER - FIGURE 2-6
- (b) CONTACT LATCH PAWL - FIGURE 2-3
- (c) CONTACT PAWL - FIGURE 2-3
- (d) ECCENTRIC FOLLOWER PAWL - FIGURE 2-5
- (e) TIME DELAY RATCHET WHEEL - FIGURE 2-2

## 4. TYPING UNIT

WHEN MAKING A COMPLETE ADJUSTMENT OF TYPING UNIT, THE FOLLOWING CONDITIONING OPERATIONS SHOULD BE PERFORMED TO PREVENT DAMAGE:

- a. LOOSEN THE SHIFT LEVER DRIVE ARM CLAMP SCREW, (FIGURE 1-26)
- b. MOVE THE RIGHT AND LEFT VERTICAL POSITIONING LEVER ECCENTRIC STUDS (FIGURES 1-39 AND 1-40) IN ROCKER SHAFT BRACKETS TO THEIR LOWEST POSITION.
- c. LOOSEN THE TWO BEARING STUD MOUNTING SCREWS AND THE TWO CONNECTING STRIP CLAMP SCREWS IN THE HORIZONTAL POSITIONING DRIVE LINKAGE (FIGURE 1-46).
- d. LOOSEN THE CLAMP SCREWS AND MOVE THE REVERSING SLIDE BRACKETS TO THEIR UPPERMOST POSITION (FIGURE 1-45).
- e. LOOSEN THE FUNCTION RESET BAIL BLADE MOUNTING SCREWS (FIGURE 1-44).
- f. UNITS EQUIPPED WITH TWO-STOP FUNCTION CLUTCHES: LOOSEN THE SHOULDER BUSHINGS ON EACH FUNCTION STRIPPER BLADE ARM AND MOVE STRIPPER BLADE AND ARMS TO THEIR LOWEST POSITIONS. (FIGURE 4-37).
- g. LOOSEN THE CARRIAGE RETURN LEVER CLAMP SCREW. (FIGURE 1-51).
- h. LOOSEN THE CLAMP SCREWS IN THE OSCILLATING RAIL SLIDE. (FIGURE 1-41).
- i. LOOSEN THE REVERSING SLIDE ADJUSTING STUD. (FIGURE 1-45).
- j. LOOSEN THE SHIFT CODE BAR GUIDE PLATE MOUNTING NUTS. (FIGURE 1-45).
- k. CHECK THE FOLLOWING ADJUSTMENTS DURING EACH LUBRICATING PERIOD:
  - (1) PRINTING CARRIAGE POSITION (FIGURE 1-57).
  - (2) PRINTING HAMMER BEARING STUD. (FIGURE 1-57).
  - (3) PRINTING HAMMER STOP BRACKET. ALSO SEE NOTE. (FIGURE 1-60).
  - (4) CARRIAGE WIRE ROPE. (FIGURE 1-48).

## NOTE

TO FACILITATE MAKING THE FOLLOWING ADJUSTMENTS, REMOVE THE RANGE FINDER AND SELECTOR MAGNET ASSEMBLIES. TO INSURE BETTER OPERATION, PULL A PIECE OF PAPER BETWEEN THE ARMATURE AND THE POLE PIECES TO REMOVE ANY OIL OR FOREIGN MATTER THAT MAY BE PRESENT. MAKE CERTAIN THAT NO LINT OR PIECES OF PAPER REMAIN BETWEEN THE POLE PIECES AND ARMATURE.





FIGURE 1-17 TYPING UNIT, SELECTOR MAGNET

**SELECTOR MAGNET BRACKET****(1) REQUIREMENT**

SPACING LOCK LEVER ON HIGH PART OF CAM.  
 ARMATURE IN CONTACT WITH POLE PIECE.  
 CLEARANCE BETWEEN END OF ARMATURE EXTENSION  
 AND SHOULDER ON SPACING LOCK LEVER.  
 MIN. 0.020 INCH  
 MAX. 0.035 INCH

**TO ADJUST**

LOOSEN TWO MAGNET BRACKET MOUNTING SCREWS  
 AND ADJUSTING LINK CLAMP SCREW. POSITION  
 MAGNET BRACKET BY MEANS OF ADJUSTING LINK  
 AND TIGHTEN LINK CLAMP SCREW ONLY.

**(2) REQUIREMENT**

SPACING LOCK LEVER ON HIGH PART OF CAM. ARMATURE IN CONTACT  
 WITH POLE PIECE. SOME CLEARANCE BETWEEN UPPER SURFACE OF ARMATURE  
 EXTENSION AND LOWER SURFACE OF SPACING LOCK LEVER WHEN LOCK LEVER  
 IS HELD DOWNWARD.  
 MAX. 0.003 INCH

**TO ADJUST**

POSITION UPPER END OF MAGNET BRACKET. TIGHTEN TWO MAGNET  
 BRACKET MOUNTING SCREWS. RECHECK REQUIREMENT (1).

FIGURE 1-18 TYPING UNIT, RIGHT SIDE VIEW


**SELECTOR ARMATURE SPRING**

**REQUIREMENT**

MARKING LOCK LEVER, SPACING LOCK LEVER, AND START LEVER ON HIGH PART OF THEIR CAMS. SCALE APPLIED AS NEARLY VERTICAL AS POSSIBLE UNDER END OF ARMATURE EXTENSION. APPROX. 3 OZS.

TO PULL ARMATURE TO MARKING POSITION. IT MAY BE NECESSARY TO READJUST THIS SPRING TENSION WHEN MAKING DISTORTION TOLERANCE TESTS OF THE UNIT.

TO ADJUST POSITION ADJUSTING NUT.



**MARKING LOCK LEVER SPRING REQUIREMENT**

LETTERS COMBINATION SELECTED, MAIN SHAFT ROTATED UNTIL SELECTOR CLUTCH IS DISENGAGED. PUSH SCALE APPLIED TO LOWER EXTENSION OF LOCK LEVER.

MIN. 1-1/2 OZS.

MAX. 3 OZS.

TO START LEVER MOVING.

FIGURE 1-19 TYPING UNIT, SELECTOR MECHANISM, RIGHT SIDE VIEW





FIGURE 1-20 TYPING UNIT, SELECTOR CAM CLUTCH




FIGURE 1-21 TYPING UNIT, SELECTOR CLUTCH MECHANISM, RIGHT SIDE VIEW

Low

110 dup + 25 / low 2

217B


**(A) RANGE FINDER KNOB PHASING**

**REQUIREMENT**

WITH RANGE FINDER KNOB TURNED TO EITHER END OF RACK, ZERO MARK ON SCALE SHOULD BE WITHIN 3 POINTS OF SCRIBED LINE ON RANGE FINDER PLATE.

**TO ADJUST**

REMOVE MOUNTING NUT, DISENGAGE KNOB FROM RACK AND POSITION KNOB. RE-ENGAGE KNOB WITH RACK AND REPLACE MOUNTING NUT.



**(B) SELECTOR CLUTCH STOP ARM**


**REQUIREMENT**

RANGE SCALE SET AT 60. SELECTOR CLUTCH DISENGAGED. ARMATURE IN MARKING POSITION. CLUTCH STOP ARM SHOULD ENGAGE CLUTCH SHOE LEVER BY APPROXIMATELY FULL THICKNESS OF SHOE LEVER.

**TO ADJUST**

POSITION STOP ARM ON STOP ARM BAIL WITH CLAMP SCREW LOOSENED.

FIGURE 1-22 TYPING UNIT, RANGE FINDER MECHANISM, RIGHT SIDE VIEW

**SELECTOR RECEIVING MARGIN**

WHEN A SIGNAL DISTORTION TEST SET IS USED FOR DETERMINING THE RECEIVING MARGINS OF THE SELECTOR, AND WHERE THE CONDITION OF THE COMPONENTS IS EQUIVALENT TO THAT OF NEW EQUIPMENT, THE RANGE AND DISTORTION TOLERANCES BELOW SHOULD BE MET.

**SELECTOR RECEIVING MARGIN MINIMUM REQUIREMENTS**

CURRENT	SPEED IN W. P. M.	POINTS RANGE WITH ZERO DISTORTION	PERCENTAGE OF MARKING AND SPACING BIAS TOLERATED	END DISTORTION TOLERATED WITH SCALE AT BIAS OPTIMUM SETTING
0.060 AMP. (WINDINGS PARALLEL)	60	72	40	35
	75			
	100			
0.020 AMP. (WINDINGS SERIES)	60	72	40	35
	75			
	100			

TO ADJUST: REFINE THE SELECTOR ARMATURE SPRING (FIGURE 1-19)

FIGURE 1-23 TYPING UNIT, SELECTOR CLUTCH MECHANISM, RIGHT SIDE VIEW







FIGURE 1-24 TYPING UNIT, CODE BAR SHIFT MECHANISM



(A) INTERMEDIATE ARM BACKSTOP BRACKET




REQUIREMENT

PUSH LEVERS NOT SELECTED. ALL CODE BAR SHIFT BARS TO THE RIGHT. SELECTOR CLUTCH DISENGAGED. CODE BAR SHIFT LEVER LINK IN LOWERMOST POSITION. CLEARANCE BETWEEN FRONT CODE BAR SHIFT LEVER AND INNER STEP OF CODE BAR SHIFT BAR FARTHEST FROM FRONT CODE BAR SHIFT LEVER  
 MIN. 0.010 INCH  
 MAX. 0.025 INCH  
 WHEN PLAY IN PARTS IS TAKEN UP FOR MAXIMUM CLEARANCE.

TO ADJUST

POSITION BACKSTOP BRACKET WITH ITS TWO CLAMP SCREWS LOOSENED.

CODEBAR SHIFT LEVER LINK BRACKET



(B) SELECTOR CAM LUBRICATOR REQUIREMENT

THE LUBRICATOR TUBE SHOULD CLEAR THE HIGH PART OF THE LOCK LEVER CAM  
 MIN. 0.020 INCH  
 THE HIGH PART OF THE SELECTOR LEVER CAMS SHOULD TOUCH THE LUBRICATOR WICK, BUT SHOULD NOT RAISE IT MORE THAN 1/32 INCH.  
 NOTE: THERE SHOULD BE SOME CLEARANCE BETWEEN THE MARKING LOCK LEVER SPRING AND THE RESERVOIR.

TO ADJUST

POSITION THE LUBRICATOR BRACKET WITH ITS MOUNTING SCREWS LOOSENED.

FIGURE 1-25 TYPING UNIT, CODE BAR SHIFT MECHANISM




FIGURE 1-26 TYPING UNIT, CODE BAR SHIFT MECHANISM

**CODE BAR SHIFT LEVER LINK BRACKET****REQUIREMENT**

MOTION OF FRONT AND REAR CODE BAR SHIFT LEVERS SHOULD BE EQUALIZED WITH RESPECT TO CODE BAR TRAVEL.

**TO CHECK (FRONT)**

SELECT BLANK COMBINATION AND ROTATE MAINSHAFT UNTIL CODE BAR SHIFT LEVER LINK REACHES HIGHEST TRAVEL. TAKE UP PLAY FOR MAXIMUM CLEARANCE. CLEARANCE BETWEEN FRONT CODE BAR SHIFT LEVER AND SHOULDER ON NEAREST CODE BAR SHIFT BAR  
 MIN. 0.002 INCH  
 MAX. 0.025 INCH

**TO CHECK (REAR)**

SELECT LETTERS COMBINATION. CHECK CLEARANCE BETWEEN REAR CODE BAR SHIFT LEVER AND SHOULDER OF CODE BAR SHIFT BAR IN SAME WAY.  
 MIN. 0.002 INCH  
 MAX. 0.025 INCH

**TO ADJUST**

POSITION ADJUSTING PLATES (FRONT AND REAR) WITH CLAMP SCREWS LOOSENED.





FIGURE 1-27 TYPING UNIT, CODE BAR SHIFT MECHANISM






FIGURE 1-28 TYPING UNIT, CODE BAR CLUTCH TRIP SHAFT MECHANISM



REQUIREMENT

CODE BAR CLUTCH AND FUNCTION CLUTCH DISENGAGED. FUNCTION CLUTCH TRIP LEVER SHOULD ENGAGE CLUTCH SHOE LEVER BY FULL THICKNESS OF SHOE LEVER. (CHECK AT LUG WITH LEAST BITE ON TWO STOP CLUTCHES)

TO ADJUST

POSITION TRIP LEVER ON ITS SHAFT WITH CLAMP SCREW LOOSENED, LETTING SHAFT HAVE END PLAY  
 MIN. SOME  
 MAX. 0.006 INCH

CODE BAR CLUTCH CAM FOLLOWER SPRING TENSION

REQUIREMENT

CAM FOLLOWER ROLLER ON THE LOW PART OF CAM. THE SPRING UNHOOKED FROM SPRING BRACKET.  
 MIN. 20 OZS.  
 MAX. 24 OZS.  
 TO PULL SPRING TO INSTALLED LENGTH.



FIGURE 1-29 TYPING UNIT, FUNCTION CLUTCH MECHANISM

(A) CLUTCH TRIP SHAFT SET COLLARS

(1) REQUIREMENT  
 SPACING CLUTCH LATCH LEVER SHOULD HAVE SIDE PLAY  
 MIN. SOME  
 MAX. 0.008 INCH  
 TO ADJUST  
 POSITION SPACING CLUTCH LATCH LEVER SET COLLAR.

(2) REQUIREMENT  
 APPROXIMATE ALIGNMENT OF RIGHT END OF STOP EXTENSIONS ON TRIP LEVER AND SHOE LEVER  
 TO ADJUST  
 POSITION LINE FEED CLUTCH TRIP LEVER SET COLLAR.

(3) REQUIREMENT  
 LINE FEED CLUTCH LATCH LEVER SHOULD HAVE SIDE PLAY  
 MIN. SOME  
 MAX. 0.008 INCH  
 TO ADJUST  
 POSITION LINE FEED CLUTCH LATCH LEVER SET COLLAR



NOTE: ANTI-DEFLECTION PLATE ADJUSTMENT APPLIES ONLY TO UNITS SO EQUIPPED.

(B) ANTI-DEFLECTION PLATE  
 REQUIREMENT  
 WITH TYPING UNIT UPSIDE DOWN AND FUNCTION, SPACING, LINE FEED, AND TYPE BOX CLUTCHES LATCHED DISENGAGED.  
 MIN. 1 LB. MAX. 5 LBS.  
 TO PULL TRIP SHAFT AWAY FROM ANTIDEFLECTION PLATE.  
 TO ADJUST  
 POSITION PLATE WITH MOUNTING SCREWS LOOSENED.

(LEFT SIDE VIEW, UPSIDE DOWN)

FIGURE 1-30 TYPING UNIT, TRIP LATCH MECHANISM





FIGURE 1-31 TYPING UNIT, SPACING CLUTCH MECHANISM






FIGURE 1-32 TYPING UNIT, TYPE BOX CLUTCH AND LINE FEED CLUTCH MECHANISM




FIGURE 1-33 TYPING UNIT, TYPE BOX CLUTCH MECHANISM





FIGURE 1-34 TYPING UNIT, CLUTCH SHOE MECHANISM (ALL CLUTCHES)



**CLUTCH SHOE LEVER SPRING TENSIONS REQUIREMENT**

CLUTCH ENGAGED. HOLD CAM DISK TO PREVENT TURNING. SPRING SCALE PULLED AT TANGENT TO CLUTCH.

MIN. 15 OZS. ONE-STOP CLUTCHES  
MAX. 20 OZS.

MIN. 16 OZS. MULTIPLE-STOP CLUTCHES  
MAX. 22 OZS.

TO MOVE THE SHOE LEVER IN CONTACT WITH THE STOP LUG.


**CLUTCH DRUM POSITION (EXCEPT SELECTOR)**

**REQUIREMENT**

CLUTCH SHOE LEVER HELD DISENGAGED. CLUTCH SHOULD HAVE SOME END PLAY  
MAX. 0.020 INCH

**TO ADJUST**

POSITION EACH DRUM AND SPACING CLUTCH SET COLLAR WITH MOUNTING SCREWS LOOSENED.



**CLUTCH SHOE SPRING TENSION**

**NOTE**

IN ORDER TO CHECK THIS SPRING TENSION, IT IS NECESSARY TO REMOVE THE CLUTCH FROM THE MAIN SHAFT. THEREFORE, IT SHOULD NOT BE CHECKED UNLESS THERE IS GOOD REASON TO BELIEVE THAT IT DOES NOT MEET ITS REQUIREMENT.

**REQUIREMENT**

CLUTCH DRUM REMOVED. SPRING SCALE APPLIED TO PRIMARY SHOE AT A TANGENT TO THE FRICTION SURFACE.

MIN. 3 OZS.  
MAX. 5 OZS.

TO START THE PRIMARY SHOE MOVING AWAY FROM SECONDARY SHOE AT POINT OF CONTACT.

FIGURE 1-35 TYPING UNIT, CLUTCH MECHANISM LEFT SIDE VIEW




FIGURE 1-36 TYPING UNIT, SPACING MECHANISM




FIGURE 1-37 TYPING UNIT, LINE FEED AND ROCKER SHAFT MECHANISMS

*Do not check adjustment  
one side*

ROCKER SHAFT BRACKET ECCENTRIC STUD

REQUIREMENT

TYPE BOX CLUTCH DISENGAGED. PLAY IN LOCKING ARM TAKEN TOWARDS FRONT. GAP BETWEEN LOWER SIDE OF LOCK LEVER ROLLER AND TOP EDGE OF SHOULDER ON HORIZONTAL POSITIONING LOCK LEVER

MIN. 0.065 INCH

MAX. 0.080 INCH

TO ADJUST

POSITION ECCENTRIC STUD IN LOWER END OF ROCKER SHAFT LEFT BRACKET. KEEP HIGH PART OF ECCENTRIC (MARKED WITH DOT) BELOW CENTER LINE OF DRIVE LINK.

NOTE:

ANY CHANGE IN THIS ADJUSTMENT WILL REQUIRE A RECHECKING OF THE FOLLOWING ADJUSTMENTS: HORIZONTAL POSITIONING DRIVE LINKAGE (FIGURE 1-46), RIGHT VERTICAL POSITIONING LEVER ECCENTRIC STUD (FIGURE 1-39), LEFT VERTICAL POSITIONING LEVER ECCENTRIC STUD (FIGURE 1-40), VERTICAL POSITIONING LOCK LEVER (FIGURE 1-47), RIBBON FEED LEVER STOP BRACKET (FIGURE 1-63), FUNCTION STRIPPER BLADE ARMS (FIGURE 4-37), SPACING TRIP LEVER BAIL CAM PLATE (FIGURE 1-42), PRINTING TRACK (FIGURE 1-59), PRINTING ARM (FIGURE 1-60) AND REVERSING SLIDE BRACKETS (FIGURE 1-45).




FIGURE 1-38 TYPING UNIT, SHIFT AND POSITIONING MECHANISMS.




FIGURE 1-39 TYPING UNIT, VERTICAL POSITIONING MECHANISM, RIGHT SIDE

*Cam... 217B*


217B

VERTICAL POSITIONING LOCK LEVER

SPRING TENSION

REQUIREMENT

TYPE BOX CLUTCH DISENGAGED  
 MIN. 2 OZS.  
 MAX. 4 OZS.  
 TO START LOCK LEVER MOVING.  
 CHECK RIGHT AND LEFT SPRINGS



LEFT VERTICAL POSITIONING LEVER ECCENTRIC STUD

REQUIREMENT

RIGHT AND LEFT VERTICAL POSITIONING LEVERS SHOULD BUCKLE EQUALLY WITHIN 0.006 INCH

TO CHECK

COMMON CODE BAR IN SPACING POSITION. TRIP TYPE BOX CLUTCH. ROTATE MAIN SHAFT UNTIL RIGHT VERTICAL POSITIONING LEVER TOE TOUCHES COMMON CODE BAR, BUCKLING ITS LOWER LINK 0.008 INCH (MAXIMUM) LEFT VERTICAL POSITIONING LEVER TOE SHOULD TOUCH COMMON CODE BAR, BUCKLING ITS LOWER LINK EQUALLY WITHIN 0.006 INCH

TO ADJUST

POSITION ECCENTRIC STUD ON ROCKER SHAFT LEFT BRACKET INNER ARM. POSITION HIGH PART OF CAM (MARKED WITH DOT) TOWARD REAR.


FIGURE 1-40 TYPING UNIT, VERTICAL POSITIONING MECHANISM LEFT SIDE



OSCILLATING RAIL SLIDE POSITION

REQUIREMENT

CARRIAGE RETURN RING AND AUTOMATIC CARRIAGE RETURN-LINE FEED RING FREE TO ROTATE ON SPACING DRUM (FIVE MOUNTING SCREWS LOOSENED.) SPACING CLUTCH DISENGAGED. FEED PAWL, WHICH IS FARTHEST ADVANCED, ENGAGING TOOTH IMMEDIATELY ABOVE CUT-AWAY SECTION OF RATCHET CLEARANCE BETWEEN SLIDE AND PULLEY MIN. 0.025 INCH—MAX. 0.050 INCH TO ADJUST POSITION SLIDE ON WIRE ROPE WITH CLAMP SCREWS LOOSENED.



NOTE: FOR EARLIER DESIGN SEE FIGURE 4-27

SPACING FEED PAWL SPRING TENSION

REQUIREMENT

EACH SPACING PAWL IN LEAST ADVANCED POSITION RESTING AGAINST RATCHET WHEEL. EACH SPRING UNHOOKED FROM BRACKET MIN. 2 1/2 OZS. MAX. 4 OZS. TO PULL SPRINGS TO INSTALLED LENGTH. NOTE: ON UNITS EQUIPPED FOR 6 SPACES PER INCH THIS TENSION SHOULD BE MIN. 8 OZS. MAX. 10 OZS. TO PULL SPRINGS TO INSTALLED LENGTH.

SPACING FEED PAWL SPRING BRACKET

FIGURE 1-41 TYPING UNIT, SPACING MECHANISM

(A) SPACING TRIP LEVER BAIL CAM PLATE

REQUIREMENT


SPACING TRIP LEVER ARM IN UPWARD POSITION. TYPE BOX CLUTCH ROTATED THROUGH APPROXIMATELY ONE-HALF OF ITS CYCLE. ALL FUNCTION PAWLS DISENGAGED FROM FUNCTION BAR. CLEARANCE BETWEEN TOP SURFACE OF TRIP LEVER ARM EXTENSION AND SPACING TRIP LEVER SHOULDER.

MIN. 0.010 INCH

MAX. 0.040 INCH

TO ADJUST

POSITION CAM PLATE ON ROCKER SHAFT WITH MOUNTING SCREWS LOOSENED. POSITION FORWARD EDGE OF CAM PLATE PARALLEL TO SHAFT.



(B) SPACING TRIP LEVER SPRING TENSION

REQUIREMENT

TYPE BOX CLUTCH DISENGAGED.

MIN. 2 1/2 OZS.

MAX. 5 OZS.

TO START LEVER MOVING.

REQUIREMENT

SPACING TRIP LEVER BAIL AGAINST STOP.

SPACING TRIP LEVER BAIL SPRING UNHOOKED.

MIN. 8 OZS.

MAX. 12 OZS.

TO PULL SPRING TO INSTALLED LENGTH.


FIGURE 1-42 TYPING UNIT, SPACING MECHANISM

*Do not function properly on fig. and. When it is not...*

*also upper  
slide set of  
way.  
comes to  
light.*

**FIGS-LTRS SHIFT CODE BAR OPERATING MECHANISM**

- (1) REQUIREMENT  
WITH FUNCTION CLUTCH ROTATED UNTIL CLUTCH DISK STOP LUG IS TOWARD BOTTOM OF UNIT, HOOK FIGURES FUNCTION PAWL OVER THE END OF THE FUNCTION BAR. CLEARANCE BETWEEN UPPER GUIDE PLATE EXTENSION AND SHIFT SLIDE. MAX. 0.020 WHEN PLAY IS TAKEN UP FOR MAXIMUM.
  - (2) REQUIREMENT  
WITH 32 OZ. PULL APPLIED TO FUNCTION PAWL THERE SHOULD BE MIN. 0.002 INCH BETWEEN SHOULDER OF FIGURES FUNCTION PAWL AND FACE OF FUNCTION BAR.
  - (3) REQUIREMENT  
REPEAT THE PROCEDURE FOR THE LETTERS FUNCTION PAWL. CHECK CLEARANCE BETWEEN LOWER GUIDE PLATE EXTENSION AND SHIFT SLIDE.
- TO ADJUST  
POSITION UPPER AND/OR LOWER GUIDE PLATE BY THE ADJUSTING SLOT WITH THE CLAMP NUTS LOOSENED.




NOTE: FOR EARLIER DESIGN SEE FIGURE 4-28

FIGURE 1-43 TYPING UNIT, SHIFT CODE BAR OPERATING MECHANISM.

**(A) FUNCTION RESET BAIL BLADE****(1) REQUIREMENT**

FUNCTION AND TYPE BOX CLUTCHES DISENGAGED. FUNCTION PAWLS UNLATCHED. FUNCTION BAR HELD IN MAXIMUM REARWARD POSITION. CLEARANCE BETWEEN FUNCTION BAR AND RESET BAIL BLADE:  
MIN. 0.018 INCH      MAX. 0.035 INCH

**REQUIREMENT**

RESET BAIL SPRINGS IN MINIMUM LENGTH POSITION  
MIN. 10 OZS.      MAX. 22 OZS.  
TO START BAIL MOVING

**TO CHECK**

MEASURE CLEARANCE AT BARS LOCATED IN STUNT BOX SLOTS 1, 4, 11, 18, 23, 33, 38 AND 41. IF THERE IS NO BAR IN A DESIGNATED SLOT, USE NEAREST BAR. IF THERE IS A BAR ON EACH SIDE OF A DESIGNATED VACANT SLOT, USE BAR IN HIGHEST NUMBERED SLOT. (NOTE: FACING REAR OF UNIT, SLOTS ARE NUMBERED FROM LEFT TO RIGHT).

**TO ADJUST**

POSITION BLADE ON RESET BAIL WITH ITS MOUNTING SCREWS FRICTION TIGHT.

**(2) REQUIREMENT**

FUNCTION PAWL SHOULD OVER TRAVEL FUNCTION BAR BY A MIN. OF 0.002 INCH.

**TO CHECK**

IF CARRIAGE RETURN LEVER ADJUSTMENT HAS NOT BEEN MADE, ITS CLAMP SCREW SHOULD BE LOOSENED. POSITION FUNCTION CLUTCH SO THAT LUG ON CLUTCH DISK IS TOWARD BOTTOM OF UNIT. STRIP OFF ANY SELECTED FUNCTION PAWLS. HOLD FUNCTION LEVER IN MAXIMUM REARWARD POSITION (DO NOT PUT OVER 2 LBS. OF TENSION ON LEVER) AND HOLD FUNCTION PAWL TO REAR WITH A TENSION OF 32 OZS. (AS LOAD ON RESET BAIL AFFECTS OVER TRAVEL, DO NOT LATCH MORE THAN ONE PAWL AT A TIME). MEASURE CLEARANCE. REPEAT FOR EACH FUNCTION PAWL ON STUNT BOX.

**TO ADJUST**

IF NECESSARY, REFINE THE ABOVE ADJUSTMENT WITHIN THE FOLLOWING LIMITS:  
MIN. 0.018      MAX. 0.035 INCH

NOTE: FOR EARLIER DESIGN SEE FIGURE 4-29





FIGURE 1-44 TYPING UNIT, RESET BAIL MECHANISM

*causes a partial buckling action*

217B



(B) REVERSING SLIDE ADJUSTING STUD REQUIREMENT

TYPE BOX CLUTCH DISENGAGED.  
WITH NO. 3 CODE BAR IN SPACING POSITION (RIGHT), THE REVERSING SLIDE DETENT ROLLERS SHOULD BE FULLY SEATED IN THE RIGHT-HAND NOTCHES OF THE DETENT LEVER.  
WITH NO. 3 CODE BAR IN MARKING POSITION (LEFT), THE REVERSING SLIDE DETENT ROLLERS SHOULD BE FULLY SEATED IN THE LEFT-HAND NOTCHES OF THE DETENT LEVER.  
TO ADJUST  
POSITION THE REVERSING SLIDE STUD IN ITS ELONGATED HOLE WITH ITS MOUNTING NUT LOOSENED.




FIGURE 1-45 TYPING UNIT, HORIZONTAL MOTION REVERSING MECHANISM FRONT VIEW

NOTE: THESE ADJUSTMENTS APPLY ONLY TO HORIZONTAL POSITIONING DRIVE MECHANISMS  
EQUIPPED WITH TORSION SPRINGS.

HORIZONTAL POSITIONING DRIVE LINKAGE

REQUIREMENT

TYPE BOX CLUTCH DISENGAGED.

CODE BARS 4 AND 5 TO SPACING (RIGHT).


CLEARANCE BETWEEN EACH SIDE OF CENTER HORIZONTAL STOP SLIDE AND DECELERATING SLIDES,  
ON SIDE WHERE KNEE LINK IS STRAIGHT SHOULD BE EQUAL ( WITHIN 0.008 INCH)

MIN. 0.015 INCH

MAX. 0.040 INCH

TO ADJUST

LOOSEN BEARING STUD MOUNTING SCREWS AND CONNECTING STRIP MOUNTING SCREWS FRICTION TIGHT.  
POSITION ONE OR BOTH BEARING STUDS ON THE CONNECTING STRIP TO PROVIDE 0.025  
INCH TO 0.035 INCH BETWEEN THE CENTER HORIZONTAL SLIDE AND THE DECELERATING  
SLIDE ON THE SIDE WHERE THE LINKAGE IS NOT BUCKLED. TIGHTEN THE TWO INNER  
MOUNTING SCREWS. CHANGE POSITION OF REVERSING SLIDE AND CHECK OPPOSITE  
CLEARANCE. EQUALIZE BY SHIFTING BOTH STUDS AND CONNECTING STRIP AS A UNIT.  
HOLD THE DRIVE LINKAGE HUB AGAINST THE LOWER VERTICAL LINK OF THE DRIVE  
LINKAGE. TIGHTEN THE TWO OUTER BEARING STUD MOUNTING SCREWS. CHECK THE  
LINKAGE FOR FREENESS THROUGHOUT A COMPLETE CYCLE.



HORIZONTAL POSITIONING DRIVE LINKAGE  
SPRING TENSION

REQUIREMENT

WITH LINKAGE IN UNBUCKLED POSITION,  
SCALE APPLIED NEAR END OF UPPER EXTENSION  
MIN. 6 OZS.  
MAX. 12 OZS.  
TO START LINK BUCKLING.

NOTE: FOR EARLIER DESIGN SEE FIGURE 4-30

FIGURE 1-46 TYPING UNIT, HORIZONTAL POSITIONING DRIVE MECHANISM, FRONT VIEW

may stagger type

217B





FIGURE 1-47 TYPING UNIT, VERTICAL POSITIONING MECHANISM, LEFT SIDE VIEW

FIGURE 1-48 TYPING UNIT, SPACING MECHANISM FRONT VIEW






4. E.A.

CHANGE 4

FIGURE 1-49 TYPING UNIT, CARRIAGE RETURN MECHANISM, FRONT VIEW



CARRIAGE RETURN SPRING  
REQUIREMENT

SPACING DRUM IN ITS RETURNED POSITION. PRINTING TRACK IN LOWER POSITION TRANSFER SLIDE AND CARRIAGE RETURN LATCH HELD AWAY  
 MIN. 3 LBS.  
 MAX. 3 3/4 LBS.  
 TO START THE SPRING DRUM MOVING.


TO ADJUST

ROTATE THE SPRING DRUM RATCHET WHEEL WITH THE SPRING DRUM NUT LOOSENED TO INCREASE TENSION. OPERATE ESCAPEMENT LEVER TO DECREASE IT.

SPACING FEED PAWL RELEASE LINK  
SPRING TENSION

REQUIREMENT

MIN. 1/2 OZ.  
 MAX. 2 1/2 OZS.  
 TO START SPRING STRETCHING



217B

(A)

CARRIAGE RETURN LATCH BAILREQUIREMENT


CARRIAGE FULLY RETURNED (SEE FIGURE 1-53)  
 PLAY IN CARRIAGE RETURN BAIL TAKEN UP  
 TO RIGHT BY HOLDING RIGHT SIDE OF BAIL  
 AGAINST ITS RETAINER. CLEARANCE BETWEEN  
 CARRIAGE RETURN LATCH BAIL AND CARRIAGE  
 RETURN LEVER.

MIN. 0.004 INCH

MAX. 0.040 INCH

TO ADJUST

POSITION LATCH BAIL PLATE WITH CLAMP  
 SCREW LOOSENED



(B)

CARRIAGE RETURN LATCHBAIL SPRING TENSIONREQUIREMENT

SPACING DRUM FULLY RETURNED


MIN. 3 OZS.

MAX. 4 1/2 OZS.

TO START LATCH BAIL MOVING

FIGURE 1-50 TYPING UNIT, CARRIAGE RETURN MECHANISM, FRONT VIEW

*Carrige return trouble, put bottom middle in middle*



**CARRIAGE RETURN LEVER REQUIREMENT (UNITS EQUIPPED WITH ONE-STOP FUNCTION CLUTCH)**

CARRIAGE RETURN FUNCTION SET UP ON SELECTOR. MAIN SHAFT ROTATED UNTIL FUNCTION CLUTCH STOP LUG IS TOWARD BOTTOM OF UNIT. CARRIAGE RETURN FUNCTION PAWL HOOKED OVER ITS FUNCTION BAR. SPACING DRUM HELD SO THAT CARRIAGE RETURN LATCH BAIL IS LATCHED.

CLEARANCE BETWEEN LATCH BAIL AND CARRIAGE RETURN LEVER.

MIN. 0.006 INCH — MAX. 0.035 INCH

**REQUIREMENT (UNITS EQUIPPED WITH TWO-STOP FUNCTION CLUTCH)**

SAME EXCEPT MAIN SHAFT SHOULD BE ROTATED UNTIL FUNCTION CLUTCH IS DISENGAGED IN STOP POSITION THAT RESULTS IN LEAST CLEARANCE.

TO ADJUST POSITION CARRIAGE RETURN LEVER ON CARRIAGE RETURN BAIL WITH CLAMP SCREW LOOSENED.

FIGURE 1-51 TYPING UNIT, CARRIAGE RETURN MECHANISM






FIGURE 1-52 TYPING UNIT, DASHPOT AND KEYBOARD LOCK MECHANISMS

*Handwritten notes:*  
 This can vary from 15 to 16  
 but some require 17  
 to 18 and play at the spacing drum

**PRINTING CARRIAGE POSITION**  
 USE STANDARD ADJUSTMENT  
 (FIGURE 1-57)



NOTE: FOR EARLIER DESIGN SEE FIGURE 4-31



(2) REQUIREMENT  
 SPACING CLUTCH DISENGAGED. FRONT SPACING FEED PAWL FARTHEST ADVANCED. SPACING DRUM FULLY RETURNED. PLAY IN SPACING SHAFT GEAR (FIG. 1-36) TAKEN UP CLOCKWISE. CLEARANCE BETWEEN PAWL AND SHOULDER OF RATCHET WHEEL TOOTH IMMEDIATELY AHEAD  
 MIN. 0.002 INCH  
 MAX. 0.015 INCH

(3) REQUIREMENT  
 REAR PAWL, WHEN FARTHEST ADVANCED, SHOULD REST AT BOTTOM OF INDENTATION BETWEEN RATCHET WHEEL TEETH.

THIS VIEW SHOWS THE SPACING DRUM FULLY RETURNED


TO ADJUST  
 SHIFT TYPE BOX TO LETTERS POSITION. RETURN PRINT CARRIAGE TO ITS LEFT POSITION. LOOSEN FOUR INDICATED CARRIAGE RETURN RING MOUNTING SCREWS. HOLD CARRIAGE RETURN RING IN ITS COUNTER-CLOCKWISE POSITION. LOCATE TYPE BOX SO ITS LTRS INDICATOR IS IN THE REQUIRED POSITION. TIGHTEN THE FOUR MOUNTING SCREWS.

NOTE: THE MARGIN MAY BE VARIED AS REQUIRED. RANGE OF ADJUSTMENT IS 0 TO 85 CHARACTERS.

FIGURE 1-53 TYPING UNIT, CARRIAGE RETURN MECHANISM

*7/1/54*  
*7/1/54*

*units of unit*



**RIGHT MARGIN  
REQUIREMENT**

TYPE BOX CLUTCH DISENGAGED. CARRIAGE IN POSITION TO PRINT CHARACTER ON WHICH SPACING CUTOUT IS TO OCCUR. FRONT FEED PAWL FARTHEST ADVANCED. SPACING CUTOUT TRANSFER BAIL HELD IN ITS UPPERMOST POSITION. CLEARANCE BETWEEN EXTENSION ON SPACE SUPPRESSION RING AND TRANSFER BAIL  
MIN. 0.006 INCH — MAX. 0.025 INCH

**TO ADJUST**

POSITION SPACE SUPPRESSION RING WITH FOUR INDICATED MOUNTING SCREWS LOOSENED.

**NOTE**

- (1) RANGE OF ADJUSTMENT IS FROM 0 TO 85 CHARACTERS.
- (2) ON UNITS EQUIPPED WITH AUTOMATIC CARRIAGE RETURN - LINE FEED RING, THIS ADJUSTMENT IS NOT APPLICABLE. (SEE FIGURE 1-71)

**NOTE: FOR EARLIER DESIGN SEE FIGURE 4-32**

**FIGURE 1-54 TYPING UNIT, SPACE SUPPRESSION**

*double  
can cause intermittent trouble if slide is not properly adjusted*

**DECELERATING SLIDE SPRING TENSION**

**REQUIREMENT**

PRINTING BAIL IN DOWNWARD POSITION. PRINTING CARRIAGE AND DECELERATING SLIDE ASSEMBLY IN RIGHT HAND POSITION.  
 MIN. 1/2 OZ.  
 MAX. 1 1/2 OZS.  
 TO START THE SLIDE MOVING.  
 WITH THE PRINTING CARRIAGE AND DECELERATING SLIDE IN THEIR LEFT HAND POSITION  
 CHECK THE LEFT HAND DECELERATING SLIDE SPRING





FIGURE 1-55 TYPING UNIT, DECELERATING SLIDE (FRONT VIEW)



PRINTING CARRIAGE LOWER ROLLER

REQUIREMENT


CARRIAGE WIRE ROPE CLAMP SCREWS LOOSENED. PLAY OF CARRIAGE ON TRACK-MIN. WITHOUT BIND, THROUGHOUT TRACK'S FULL LENGTH

TO ADJUST (ECCENTRIC BUSHING)

POSITION LOWER ROLLER WITH SCREW NUT LOOSENED. KEEP HIGH PART OF ECCENTRIC (CHAMFERED CORNER) TOWARD THE RIGHT

TO ADJUST (SLIDING SCREW)

POSITION LOWER ROLLER WITH MOUNTING SCREW LOOSENED.



TYPE BOX CARRIAGE ROLLER ARM SPRING

REQUIREMENT

MIN. 28 OZS.

MAX. 36 OZS.


TO START UPPER ROLLER, NEAREST TYPE BOX LATCH, MOVING AWAY FROM CARRIAGE TRACK.

NOTE: FOR EARLIER DESIGN SEE FIGURE 4-33

FIGURE 1-56 TYPING UNIT, PRINTING AND TYPE BOX CARRIAGE




*Check for proper alignment of type box to carriage  
 if letter not printing better structure*



**REQUIREMENT**  
 TYPE BOX IN LETTERS POSITION. M TYPE PALLET  
 SELECTED. TYPE BOX IN PRINTING POSITION.  
 M TYPE PALLET SHOULD BE APPROXIMATELY  
 IN CENTER OF PRINTING HAMMER WHEN HAMMER  
 IS JUST TOUCHING M TYPE PALLET.

**TO ADJUST**  
 POSITION PRINTING CARRIAGE ON WIRE  
 ROPE WITH CLAMP SCREWS LOOSENED.



**REQUIREMENT**  
 TYPE BOX AT MIDPOINT OF PLATEN AND IN  
 POSITION TO PRINT PERIOD. PRINTING HAMMER  
 IN CONTACT WITH TYPE PALLET AND PRESSED  
 DOWNWARD AT BEARING POST. FACE OF  
 HAMMER SHOULD BE FULLY ON END OF  
 TYPE PALLET.

**TO ADJUST**  
 ADD OR REMOVE SHIMS BETWEEN SHOULDER  
 ON BEARING POST AND STOP BRACKET

FIGURE 1-57 TYPING UNIT, PRINTING CARRIAGE

*Can be used on standard type box in addition to hammer*

**(A) SHIFT LINKAGE**

**REQUIREMENT**



CARRIAGE NEAR MIDPOINT OF PLATEN. TYPE BOX IN POSITION TO PRINT M. MANUALLY BUCKLE RIGHT SHIFT LINKAGE. SHIFT TYPE BOX TO LEFT. PERIOD TYPE PALLET SHOULD BE APPROXIMATELY IN CENTER OF PRINT HAMMER WHEN HAMMER IS JUST TOUCHING PERIOD TYPE PALLET

TO ADJUST

POSITION LEFT SHIFT LINKAGE ON OSCILLATOR RAIL WITH TWO CLAMP SCREWS LOOSENED

TO RECHECK

SHIFT ALTERNATELY FROM M TO PERIOD. TAKE UP PLAY IN EACH DIRECTION. REFINE ADJUSTMENT IF NECESSARY.



**REQUIREMENT**

LINK IN STRAIGHT POSITION  
 MIN. 7 OZS.  
 MAX. 14 OZS.  
 TO START EACH LINK MOVING.

NOTE: FOR SHIFT MECHANISMS WITH TORSION SPRINGS SEE FIGURE 4-34

FIGURE 1-58 TYPING UNIT, SHIFT MECHANISM

can. Start to front of them stop. or pressure of 257.

217B

(A) PRINTING TRACK

REQUIREMENT

PRINTING TRACK IN ITS EXTREME DOWNWARD POSITION. BLANK SELECTION IN FIGURES. PRINTING HAMMER OPERATING BAIL LATCHING EXTENSION HELD WITH LEFT FACE IN LINE WITH THE LATCH SHOULDER. PRINTING ARM SLIDE POSITIONED ALTERNATELY OVER EACH TRACK MOUNTING SCREW. PRINTING BAIL RESET EACH TIME. CLEARANCE BETWEEN LATCHING EXTENSION AND OPERATING BAIL LATCH SHOULD BE

MIN. 0.015 INCH  
MAX. 0.040 INCH

TO ADJUST

POSITION THE PRINTING TRACK UP OR DOWN WITH ITS MOUNTING SCREWS LOOSENED.




FIGURE 1-59 TYPING UNIT, PRINTING MECHANISM

*May not print if maladjusted  
may print light*

217B

**PRINTING HAMMER STOP BRACKET**

**REQUIREMENT**

TYPE BOX IN POSITION TO PRINT M PRINTING TRACK IN ITS MAXIMUM DOWNWARD POSITION. PRINTING HAMMER STOP BRACKET HELD TOWARD THE PLATEN WITH 8 OZS. OF PRESSURE. CLEARANCE BETWEEN PRINTING HAMMER AND M TYPE PALLET

MIN. 0.005 INCH

MAX. 0.035 INCH

CHECK AT BOTH ENDS OF PLATEN.

TO ADJUST

POSITION STOP BRACKET BY MEANS OF ITS MOUNTING SCREW

**TYPE PALLET SPRING TENSION**


**REQUIREMENT**

TYPE BOX REMOVED FROM THE UNIT. 8 OZS. SCALE APPLIED VERTICALLY TO THE END OF THE PALLET SHANK.

MIN. 1/4 OZS.

MAX. 3/4 OZS.

TO START PALLET MOVING.



(TOP VIEW)

PRINTING ARM *SCALE*

**(1) REQUIREMENT**

PRINTING TRACK IN MAXIMUM DOWNWARD POSITION.

PRINTING HAMMER OPERATING BAIL AGAINST ITS STOP.

SOME CLEARANCE BETWEEN SECONDARY PRINTING ARM AND FORWARD EXTENSION OF HAMMER OPERATING BAIL.

MAX. 0.015 INCH

WHEN PRINTING ARM SLIDE IS HELD DOWNWARD OVER EACH PRINTING TRACK MOUNTING SCREW FOR MAXIMUM CLEARANCE.


**(2) REQUIREMENT**

PRINTING TRACK IN UPPERMOST POSITION. LATCHING EXTENSION OF PRINTING HAMMER OPERATING BAIL SHOULD OVERTRAVEL LATCHING SURFACE OF OPERATING BAIL LATCH BY MIN. 0.006 INCH

CHECK RIGHT AND LEFT POSITIONS

TO ADJUST

POSITION SECONDARY PRINTING ARM WITH CLAMP SCREWS LOOSENED.



NOTE

THE PRINTING ARM ADJUSTMENT SHOULD ALWAYS BE MADE WITH THE PRINTING HAMMER OPERATING BAIL SPRING BRACKET IN THE NO. 1 POSITION. POSITIONS NO. 2 AND 3 ARE TO BE USED ONLY FOR MAKING MULTIPLE COPIES.

NOTE:


FOR EARLIER DESIGN SEE FIGURE 4-35

FIGURE 1-60 TYPING UNIT, PRINTING MECHANISM

*This can cause upper portion of Baller to  
 require adjustment*



217B

NOTE: THIS ADJUSTMENT APPLIES ONLY TO UNITS SO EQUIPPED AND SHOULD BE MADE WITH THE TYPEBOX IN ITS UPPER POSITION.



NOTE: SOME TYPING UNITS ARE EQUIPPED WITH A RIBBON GUIDE WHICH HAS A TYPE BOX RETAINING CLIP WITH A LIMITED YIELD. IN CASES WHERE IT IS NECESSARY TO BACK THE ADJUSTING SCREW OUT TO PROVIDE HEAVIER PRINTING AT THE TOP OF A CHARACTER, IT MAY BE NECESSARY TO BEND THE SPRING CLIP ON THE RIBBON GUIDE TOWARD THE FRONT SO THAT THE TAB AT THE BOTTOM OF THE TYPE BOX IS HELD AGAINST THE HEAD OF THE ADJUSTING SCREW.

FIGURE 1-61 TYPING UNIT, TYPE BOX



(A) RIBBON REVERSE SPUR GEAR REQUIREMENT

WHEN RIGHT REVERSING LEVER IS IN MAXIMUM DOWNWARD POSITION, THE LEFT REVERSING LEVER SHOULD BE IN ITS MAXIMUM UPWARD POSITION.

TO ADJUST

LOOSEN THE SET SCREWS IN THE DETENT CAM. LOOSEN THE LEFT SPUR GEAR NUT. SECURELY TIGHTEN THE RIGHT SPUR GEAR NUT. MOVE THE RIGHT REVERSING LEVER TO ITS MAXIMUM DOWNWARD POSITION AND HOLD LEFT REVERSING LEVER IN ITS MAXIMUM UPWARD POSITION. THEN TIGHTEN THE LEFT SPUR GEAR NUT.

DETENT LINK

(B) RIBBON REVERSE DETENT REQUIREMENT


RIBBON REVERSE DETENT LINK BUCKLED IN ITS DOWNWARD POSITION, CLEARANCE BETWEEN DETENT LINK AND DETENT LEVER

MIN. SOME - MAX. 0.040 INCH

WHEN PLAY IN THE LEVER IS TAKEN UP LIGHTLY TOWARD THE RIGHT SIDE OF THE PRINTER.

TO ADJUST

HOLD LEFT RIBBON REVERSING LEVER IN ITS DOWNWARD POSITION, POSITION DETENT LINK, AND TIGHTEN THE UPPER SET SCREW IN THE HUB OF THE DETENT LINK. BUCKLE THE DETENT LINK UPWARD AND TIGHTEN LOWER SET SCREW.



NOTE: FOR EARLIER DESIGN SEE FIGURE 4-36

(C) RIBBON REVERSE DETENT LEVER SPRING TENSION

(IF UNIT IS EQUIPPED)

REQUIREMENT

DETENT LINK BUCKLED IN UPWARD POSITION

MIN. 10 OZS.

MAX. 18 OZS.

TO START DETENT LEVER MOVING TOWARD REAR.

FIGURE 1-62 TYPING UNIT, RIBBON REVERSE MECHANISM

**RIBBON FEED LEVER BRACKET**

**(1) REQUIREMENT (LEFT-HAND MECHANISM)**


LEFT REVERSING LEVER IN UPWARD POSITION.  
 RIBBON MECHANISM IN UPPER POSITION.  
 RATCHET WHEEL HELD AGAINST THE DETENT LEVER.  
 CLEARANCE BETWEEN THE FRONT FACE OF THE  
 FEED LEVER AND THE SHOULDER OF A TOOTH  
 ON THE RATCHET WHEEL

MIN. 0.020 INCH  
 MAX. 0.030 INCH

**TO ADJUST**

POSITION THE FEED LEVER BRACKET WITH ITS  
 MOUNTING SCREWS LOOSENED.

**RIBBON REVERSING LEVER-LEFT**



**(2) REQUIREMENT (RIGHT-HAND MECHANISM)**

RIGHT REVERSING LEVER AND RIBBON  
 MECHANISM IN UPWARD POSITION.  
 ADJUST FEED LEVER BRACKET IN THE  
 SAME MANNER

**NOTE**

ROTATE THE MAIN SHAFT. THE  
 RATCHET WHEEL SHOULD STEP ONE  
 TOOTH ONLY WITH EACH OPERATION

**RIBBON FEED LEVER SPRING TENSION**

**REQUIREMENT**

RIBBON FEED LEVERS IN UPPERMOST POSITION.  
FOR LONG LEVER: PUSH DOWNWARD NEAR  
 ITS SPRING.

FOR SHORT LEVER: PUSH DOWNWARD AT POINT  
 NEAR LONG LEVER SPRING.

MIN. 3/4 OZ.  
 MAX. 2 OZS.

TO START FEED LEVERS MOVING.  
 MEASURE ALL FOUR PAWLS.

NOTE: IF MINIMUM REQUIREMENT OF  
 SHORT LEVER IS NOT MET,  
 PULL LOWER END OF TORSION  
 SPRING TO REAR.

**RIBBON RATCHET WHEEL FRICTION  
 SPRING TENSION**

**REQUIREMENT**

FEED LEVERS DISENGAGED.

MIN. 3 OZS.  
 MAX. 7 1/2 OZS.

TO START THE RATCHET WHEEL MOVING.


FIGURE 1-63 TYPING UNIT, RIBBON FEED MECHANISM, LEFT SIDE VIEW

RIBBON LEVER SPRING TENSION

## REQUIREMENT

MIN. 1 1/2 OZS.

MAX. 3 OZS.

TO START THE LEVER MOVING. CHECK  
BOTH RIGHT AND LEFT SPRINGSRIBBON TENSION SPRING

## REQUIREMENT

RIBBON RATCHET WHEEL POSITIONED SO  
THAT EACH DRIVING PIN IS TOWARD  
THE OUTSIDE OF THE SPOOL SHAFT.


MIN. 3 OZS.

MAX. 5 1/2 OZS.

TO START SPOOL SHAFT MOVING.



FIGURE 1-64 TYPING UNIT, RIBBON REVERSE MECHANISM, TOP VIEW






CAUTION: SEVERE WEAR TO THE POINT OF OPERATIONAL FAILURE WILL RESULT IF THE TELETYPEWRITER IS OPERATED WITHOUT EACH FUNCTION PAWL HAVING EITHER A RELATED FUNCTION BAR OR, WHERE A FUNCTION BAR IS MISSING, A RELATED FUNCTION PAWL CLIP TO HOLD THE FUNCTION PAWL AWAY FROM THE STRIPPER BLADE.

FIGURE 1-65 TYPING UNIT, STUNT BOX MECHANISM



STUNT BOX CLIP (FOR UNITS EQUIPPED WITH CLIPS ONLY)

- (1) REQUIREMENT ( RIGHT-HAND POSITION)  
THE CLIP SHOULD NOT PREVENT THE ASSOCIATED FUNCTION PAWL FROM ENGAGING ITS FUNCTION BAR.  
TO ADJUST  
POSITION THE CLIP TO ITS EXTREME RIGHT-HAND POSITION
- (2) REQUIREMENT ( CENTER POSITION)  
THE CLIP SHOULD HOLD THE FUNCTION PAWL OUT OF ENGAGEMENT WITH ITS FUNCTION BAR BUT SHOULD NOT INTERFERE WITH THE FUNCTION LEVER.  
TO ADJUST  
POSITION THE CLIP WITH ITS MOUNTING SCREW LOOSENED.
- (3) REQUIREMENT ( LEFT-HAND POSITION)  
THE CLIP SHOULD HOLD THE FUNCTION PAWL UPWARD OUT OF ENGAGEMENT WITH ITS FUNCTION BAR. IT SHOULD ALSO HOLD THE TOP END OF THE FUNCTION LEVER IN ITS REAR POSITION.  
TO ADJUST  
POSITION THE CLIP TO ITS EXTREME LEFT-HAND POSITION.



FUNCTION BAR

(RIGHT SIDE VIEW)

FIGURE 1-66 TYPING UNIT, STUNT BOX MECHANISM

can cause improper line feed.

217B




FIGURE 1-67 TYPING UNIT, LINE FEED MECHANISM, RIGHT SIDE

STRIPPER BLADE DRIVE CAM POSITION

## REQUIREMENT

STRIPPER BLADE DRIVE CAM SHOULD MOVE EACH STRIPPER BLADE CAM ARM AN EQUAL DISTANCE ABOVE AND BELOW CENTER LINE OF ITS PIVOT ( GAUGE BY EYE)

- A. UPWARD DIRECTION
- B. DOWNWARD DIRECTION

## TO CHECK

WITH FUNCTION CLUTCH DISENGAGED OBSERVE ENGAGEMENT OF STRIPPER BLADE DRIVE CAM ( UPPER PEAK) WITH STRIPPER BLADE CAM ARM. THEN ROTATE CLUTCH TO TURN CAM TO ITS EXTREME DOWNWARD POSITION AND OBSERVE ENGAGEMENT OF LOWER CAM PEAK.

## TO ADJUST

WITH STRIPPER BLADE DRIVE ARM MOUNTING SCREWS LOOSENED, EQUALIZE THE OVERTRAVEL OF EACH CAM PEAK.




FIGURE 1-68 TYPING UNIT, FUNCTION PAWL STRIPPER





FIGURE 1-69. TYPING UNIT, SPACING SUPPRESSION AND FUNCTION PAWL STRIPPER MECHANISMS






FIGURE 1-70 TYPING UNIT, SINGLE-DOUBLE LINE FEED MECHANISM.



NOTE: FOR ADJUSTMENT ON EARLIER MODELS SEE FIGURE 4-38

FIGURE 1-71 TYPING UNIT, AUTOMATIC CARRIAGE RETURN-LINE FEED MECHANISM




HORIZONTAL STOP SLIDE SPRING TENSION  
REQUIREMENT

CODE BARS IN MARKING POSITION (LEFT)  
TYPE BOX CLUTCH ROTATED 1/4 TURN FROM ITS STOP POSITION  
HORIZONTAL MOTION DECELERATING SLIDES (FIG. 1-46) HELD AWAY  
FROM HORIZONTAL STOP SLIDES

MIN. 1/2 OZ. MAX. 1 1/2 OZS. FOR UPPER AND LOWER SLIDES  
MIN. 1 3/4 OZS. MAX. 3 OZS. FOR MIDDLE SLIDE  
TO START SLIDE MOVING.

NOTE: WHEN CHECKING UPPER AND LOWER SLIDES, HOLD MIDDLE  
SLIDE 1/32 INCH FORWARD.


FIGURE 1-72 TYPING UNIT, HORIZONTAL MOTION STOP



PAPER STRAIGHTENER COLLAR  
REQUIREMENT

LEFT COLLAR SPACE  
MIN. 9/32 INCH  
MAX. 21/64 INCH  
FROM THE LEFT SHOULDER ON THE  
PAPER STRAIGHTENER SHAFT.  
RIGHT COLLAR SPACE  
MIN. 1/16 INCH  
MAX. 5/64 INCH  
FROM THE RIGHT SHOULDER.

TO ADJUST  
POSITION COLLARS ON SHAFT WITH SET  
SCREWS LOOSENED



NOTE: FOR SPROCKET FEED MECHANISM SEE SECTION 2

FIGURE 1-73 TYPING UNIT, PAPER MECHANISM









FIGURE 1-74 PAPER MECHANISM



NOTE: FOR EARLIER DESIGN SEE FIGURE 4-40 AND 4-41



CAUTION: CARE SHOULD BE EXERCISED IN SOLDERING TO CONTACT SPRINGS SINCE EXCESSIVE HEAT WILL ANNEAL THE SPRINGS. CONTACT SPRINGS ONCE SOLDERED SHOULD NOT BE USED AGAIN. TO REPLACE A SPRING, REMOVE THE TWO SCREWS WHICH MOUNT THE SWITCH ASSEMBLY TO THE STUNT BOX. CLEAN SOLDER FROM SPRING. COMPRESS LOOP OF SPRING AND REMOVE FROM TERMINAL PLATE. PLACE NEW SPRING IN TERMINAL PLATE AND SNAP INTO PLACE. REPLACE TERMINAL PLATE. RESOLDER CABLE. DO NOT OVERHEAT.

NOTE: BEFORE TIGHTENING TERMINAL PLATE SCREWS PROVIDE A MINIMUM OF 0.006 INCH CLEARANCE HERE. APPLY GREASE TO INSULATOR AND LEVER.

FIGURE 1-75 TYPING UNIT, FUNCTION CONTACTS




FIGURE 1-76 TYPING UNIT, UNSHIFT-ON-SPACE MECHANISM, LEFT SIDE VIEW

**CODE BAR DETENT**

**REQUIREMENT**

FRONT PLATE REMOVED. ALL CLUTCHES DISENGAGED. SUPPRESSION AND SHIFT CODE BARS SHOULD DETENT EQUALLY (GAUGED BY EYE)

**TO ADJUST**

EQUALIZE THE DETENTING OF THE CODE BARS BY ADDING OR REMOVING SHIMS BETWEEN THE CASTING AND THE CODE BAR BRACKET.

**CODE BAR DETENT SPRING TENSION**

**NOTE**

UNLESS THERE IS REASON TO BELIEVE THAT THESE SPRINGS ARE CAUSING OPERATING FAILURE DO NOT CHECK THIS REQUIREMENT.


**REQUIREMENT**

CODE BAR DETENT BRACKET CAREFULLY REMOVED AND CODE BARS REMOVED FROM DETENT BRACKET. SCALE APPLIED TO DETENT BALL AND PULLED IN DIRECTION OF BALL TRAVEL

MIN. 1 1/2 OZS.

MAX. 3 1/2 OZS.

TO START BALL MOVING AGAINST COMPRESSION OF SPRING. CHECK EACH BALL



**REQUIREMENT**


SELECTOR CLUTCH, CODE BAR CLUTCH, AND TYPE BOX CLUTCH DISENGAGED. NO. 1 CODE BAR IN SPACING POSITION

MIN. 17 OZS.

MAX. 23 OZS.

TO START CODE BAR SHIFT BAR PIVOT MOVING AWAY FROM CODE BAR. CHECK NO. 2 AND COMMON CODE BAR SHIFT BAR IN THE SAME MANNER.

FIGURE 1-77 TYPING UNIT, CODE BAR DETENT MECHANISM



### MARGIN INDICATOR LAMP

#### REQUIREMENT


OPERATING UNDER POWER, THE LAMP SHOULD LIGHT ON THE DESIRED CHARACTER.

#### TO ADJUST

SET THE TYPE BOX CARRIAGE TO PRINT THE DESIRED CHARACTER AND POSITION THE CAM DISK COUNTERCLOCKWISE ON THE SPRING DRUM WITH ITS THREE MOUNTING SCREWS LOOSENED SO THAT THE SWITCH JUST OPENS.

FIGURE 1-78 BASE AND TYPING UNIT, MARGIN INDICATING MECHANISM

## 5. MOTORS



**CAUTION**  
 IF THE MOTOR SHOULD BECOME BLOCKED FOR SEVERAL SECONDS, THE THERMAL CUT-OUT SWITCH WILL BREAK THE CIRCUIT. SHOULD THIS HAPPEN, ALLOW THE MOTOR TO COOL AT LEAST 5 MINUTES BEFORE MANUALLY DEPRESSING THE RED BUTTON. AVOID REPEATED DEPRESSION.

MOTOR SHAFT

**SYNCHRONOUS MOTOR POSITIONING REQUIREMENT**

TWO OILERS SHOULD BE UPWARD AND APPROXIMATELY EQUIDISTANT FROM A VERTICAL LINE THROUGH THE MOTOR SHAFT.

TO ADJUST


POSITION THE MOTOR WITH THE TWO CLAMP SCREWS LOOSENED.

FIGURE 1-79 SYNCHRONOUS MOTOR

**GOVERNED MOTOR POSITIONING**

**REQUIREMENT**

MOTOR SHOULD BE CENTRALLY POSITIONED IN ITS RUBBERMOUNTS SO AS TO PROVIDE AT LEAST 0.020 CLEARANCE BETWEEN THE MOTOR HOUSING AND THE CRADLE AT THE GOVERNOR END. THE CABLE SHOULD ALSO CLEAR THE GROMMET IN THE SCREEN BY AT LEAST 0.030 INCH.



**A. GOVERNOR CONTACT**

**REQUIREMENT**

THE CONTACTS SHOULD MEET SQUARELY AND NOT OVERLAP MORE THAN 0.010 INCH.

TO ADJUST

POSITION THE STATIONARY CONTACT AND CONTACT ARM WITH THE CLAMP SCREW AND POST LOOSENED.

**B. GOVERNOR CONTACT BACKSTOP**

**REQUIREMENT**

CLEARANCE BETWEEN THE MOVABLE CONTACT ARM AND ITS ECCENTRIC BACKSTOP.


MIN. 0.030 INCH

MAX. 0.050 INCH

TO ADJUST

ROTATE THE ECCENTRIC BACKSTOP WITH CLAMPING SCREW LOOSENED.

FIGURE 1-80 GOVERNED MOTOR



GOVERNED MOTOR SPEED ADJUSTMENT

REQUIREMENT

WITH THE TARGET ILLUMINATED AND VIEWED THROUGH THE VIBRATING SHUTTERS OF A 120 VPS TUNING FORK, THE SPOTS SHOULD APPEAR STATIONARY WHILE ROTATING

TO ADJUST

STOP THE MOTOR AND TURN THE ADJUSTING SCREW AS INDICATED ON THE GOVERNOR COVER.

NOTE

IT IS POSSIBLE TO ADJUST THE MOTOR AT SOME MULTIPLE OF THE CORRECT SPEED. TO CHECK FOR CORRECT SPEED, HAVE THE TYPE BOX CARRIAGE AT THE LEFT MARGIN, SET UP ANY CHARACTER ON THE SELECTOR AND MANUALLY TRIP THE TYPE BOX CLUTCH TRIP LEVER. IF THE UNIT IS EQUIPPED WITH GEAR FOR 60 SPEED OPERATION, IT SHOULD PRINT 70 CHARACTERS IN 10 SECONDS: WITH 75 SPEED GEARS - 44 CHARACTERS IN 5 SECONDS: WITH 100 SPEED GEARS - 57 CHARACTERS IN 5 SECONDS.

FIGURE 1-81 MOTOR GOVERNOR BRUSH AND MOTOR SPEED.

6. CABINET

(A)

ARMATURE SPRING TENSION

REQUIREMENT

MIN. 1/2 OZ.

MAX. 1 OZ.

TO PUSH THE ARMATURE AGAINST THE CORE (VERTICALLY)

(B)

REMOTE SIGNAL BELL

REQUIREMENT

ARMATURE HELD AGAINST THE MAGNET CORE.


CLEARANCE BETWEEN THE ARMATURE BALL AND THE BELL.

MIN. 0.020 INCH

MAX. 0.030 INCH

TO ADJUST

BEND THE ARMATURE EXTENSION JUST BELOW THE ARMATURE SPRING.



(C)

CRADLE

REQUIREMENT

TOP OF HINGE BRACKET PARALLEL TO TOP OF HINGE BAR.

TO ADJUST

TURN STOP SCREW WITH LOCK NUT LOOSENED.





FIGURE 1-82 REMOTE SIGNAL BELL AND CRADLE



NOTE: THE FOLLOWING ADJUSTMENTS ARE MADE AT THE FACTORY AND SHOULD NOT BE DISTURBED UNLESS THERE IS REASON TO BELIEVE THAT THE PARTS ARE OUT OF ADJUSTMENT OR HAVE BEEN DISASSEMBLED.



(A) DOME

(1) REQUIREMENT

THE DOME SHOULD BE CENTERED ON THE CABINET FROM RIGHT TO LEFT AND PLACED MIN. 3/16 INCH MAX. 1/4 INCH FROM THE FRONT EDGE OF THE CABINET

TO ADJUST

POSITION THE DOME WITH THE SIX NUTS WHICH SECURE THE DOME HINGES TO THE DOME LOOSENED. TIGHTEN THE NUTS.

(2) REQUIREMENT

THERE SHOULD BE A LIGHT-PROOF SEAL AT THE REAR OF THE DOME BETWEEN THE RUBBER GASKET AND THE TOP EDGE OF THE CABINET.

TO ADJUST

POSITION THE DOME DOWNWARD WITH THE SIX NUTS, WHICH SECURE THE DOME HINGES TO THE CABINET, LOOSENED. TIGHTEN THE NUTS.

(B) DOME CATCH

(1) REQUIREMENT


THE DOME SHOULD LATCH SECURELY WITH A LIGHT-PROOF SEAL AT THE FRONT OF THE DOME BETWEEN THE RUBBER GASKET AND THE TOP EDGE OF THE CABINET.

(2) REQUIREMENT

THE DOME CATCH SHOULD UNLATCH WHEN THE CATCH BUTTON IS DEPRESSED NO DEEPER THAN THE OUTER SURFACE OF THE DOME

TO ADJUST

BEND THE TWO DOME CATCHES



(C) SMALL DOOR CATCH

(1) REQUIREMENT

THE SMALL DOOR SHOULD SECURELY LATCH.


(2) REQUIREMENT

WHEN THE DOOR IS RELEASED FROM ITS CATCH IT SHOULD SPRING OPEN AT LEAST 1/2 INCH.

TO ADJUST

BEND THE SMALL DOOR CATCH. RECHECK REAR OF DOOR TO MAKE CERTAIN IT IS FLUSH WITH OR SLIGHTLY ABOVE THE DOME.

FIGURE 1-83 CABINET



(A)  
SMALL DOOR  
REQUIREMENT

THE SMALL DOOR SHOULD BE CENTERED FROM RIGHT TO LEFT. IT SHOULD BE POSITIONED SO AS TO PROVIDE A LIGHT TIGHT SEAL BETWEEN THE RUBBER GASKET AND THE LEDGE OF THE DOME AT ALL POINTS.

TO ADJUST

LOOSEN THE TWO NUTS THAT SECURE DETENT BRACKET TO DOME BRACKET. LOOSEN THE TWO NUTS THAT SECURE DETENT ARM TO HINGE EXTENSION. LOOSEN THE FOUR NUTS THAT SECURE DOOR HINGES TO DOME BRACKET. PUSH HINGES AGAINST DOME BRACKET AND TIGHTEN THE FOUR NUTS THAT SECURE HINGES TO DOME BRACKET. LOOSEN THE THREE NUTS THAT SECURE HINGE EXTENSION TO DOOR. SLIDE DOOR TO ITS EXTREME FORWARD

POSITION AND POSITION CENTRALLY FROM SIDE TO SIDE. TIGHTEN THE THREE NUTS THAT SECURE HINGE EXTENSION TO DOOR. LOOSEN THE FOUR NUTS THAT FASTEN DOOR HINGES TO HINGE EXTENSION. POSITION DOOR FLUSH WITH OR SLIGHTLY ABOVE DOME. TIGHTEN THE FOUR NUTS THAT FASTEN HINGES TO HINGE EXTENSION. AGAIN LOOSEN THE THREE NUTS THAT SECURE HINGE EXTENSION TO DOOR. CLOSE DOOR AND SLIDE IT TOWARD REAR TO PROVIDE A LIGHT TIGHT SEAL AT FRONT CORNERS OF DOOR. TIGHTEN THE THREE NUTS THAT SECURE HINGE EXTENSION TO DOOR.

(B)  
DETENT ARM AND DETENT BRACKET

(1) REQUIREMENT

THE DETENT ARM SHOULD BE HORIZONTALLY IN LINE WITH THE UPPER EDGES OF THE TWO HINGES.


TO ADJUST

POSITION THE ARM AND TIGHTEN THE TWO NUTS.

(2) REQUIREMENT

WITH THE DOME IN FULLY RAISED POSITION AND THE SMALL DOOR LATCH BUTTON DEPRESSED, THE SMALL DOOR SHOULD NOT OPEN BEYOND ITS DETENT. WITH THE DOME CLOSED, THE SMALL DOOR SHOULD SPRING OPEN AT LEAST 1/2 INCH WHEN RELEASED FROM ITS CATCH.

SMALL DOOR STOP ARM



TO ADJUST

POSITION THE DETENT BRACKET AND TIGHTEN THE TWO NUTS. IF NECESSARY REPOSITION THE DETENT ARM. RECHECK ALL NUTS FOR TIGHTNESS.

(C)  
SMALL DOOR STOP ARM

REQUIREMENT

STOP ARM SHOULD BE FREE OF BINDS WHEN DOOR IS OPENED OR CLOSED.

TO ADJUST

LOOSEN THE STOP ARM BRACKET MOUNTING SCREWS. CLOSE THE DOOR. DISCONNECT THE TORSION SPRING. ALIGN STOP ARM FOR FREENESS AND TIGHTEN MOUNTING SCREWS WITH DOOR CLOSED. REPLACE TORSION SPRING.

(D)  
COUNTERBALANCE

REQUIREMENT

THE DOME SHOULD REMAIN IN ITS MAXIMUM OPEN POSITION AND NOT CLOSE UNLESS MOVED MANUALLY

TO ADJUST

TURN THE SPRING ADJUSTING SCREW. (FIGURE 1-83)

FIGURE 1-84 CABINET




FIGURE 1-85 CABINET

7. ELECTRICAL SERVICE UNIT





FIGURE 1-86 MOTOR CONTROL ASSEMBLY

## 8. PAPER AND RIBBON

a. To replenish the supply of friction feed paper, open the dome of the cabinet, move the paper release lever on the Typing Unit toward the rear, slide one of the spindle retainers toward the rear and remove the paper spindle. Insert the spindle in a fresh roll of paper and remount it so that the paper unwinds from underneath. Feed the paper over the paper straightener shaft (Figure 1-85) and fold the end of the paper backward to square it off. With the paper release lever toward the rear, start the paper feeding around the platen and then restore the release lever to its forward position. Depress the line feed wheel and continue to feed the paper upward. Do not disturb the ribbon. Make certain that the paper passes under the paper fingers which may be raised temporarily to facilitate the operation. It may be necessary to operate the release lever momentarily when finally straightening the paper.

\*b. The Sprocket feed typing unit is capable of handling as many as 12 copies of stapled continuous form stationery or as many as 6 copies of unstapled form stationery. For stapled stationery, place the

form supply box on the floor behind the cabinet or on the shelf provided in the 152349 paper supply box and form-accumulating shelf. For unstapled stationery, place the form supply box on a platform not more than 18 inches below the paper admission slot or on the shelf provided in the 159349 paper supply box and form-accumulating shelf.

c. To replace the ribbon, open the dome of the cabinet, raise the toggles on the ribbon spool shafts (Figure 1-86) to the vertical position and remove both spools. Engage the hook that is on the end of the new ribbon in the hub of the empty spool. Wind a few turns of the ribbon onto the empty spool to make sure that the reversing eyelet has been wound upon the spool. Place the spools on the ribbon spool shafts in such a manner that the ribbon feeds from the rear of each spool without twisting. Turn each spool shaft slightly until the driving pins on the spool shafts engage the holes in the spools. Thread the ribbon forward around both ribbon rollers, through the slots in the ribbon reverse levers, and through the ribbon guide on the type box carriage. Make certain that ribbon remains in guide slots and that both reversing eyelets are between ribbon spools and reverse levers. Eliminate slack in ribbon.




FIGURE 1-87 PATH OF PAPER




FIGURE 1-88 PATH OF RIBBON

## 9. TOOLS

For a listing of tools required to maintain the Model 28 Printer Set, refer to Teletype Bulletin 1124B.

10. DISASSEMBLY AND REASSEMBLY. (for illustration of parts referred to herein, see Teletype Model 28 Printer Parts bulletin).

### NOTE

If a part that is mounted on shims is to be removed, the number of shims used at each of its mounting screws should be noted so that the same shim pile-up can be replaced when the part is re-mounted. Retaining rings (Tru-arc) are of spring steel and have a tendency to release suddenly. Loss of these can be minimized as follows: Hold the tru-arc with your left hand to prevent it from rotating. Place the blade of a suitable screwdriver in one of the slots of the tru-arc. Rotate the screwdriver in a direction to increase diameter of tru-arc. Tru-arc will come off easily without flying.

a. TYPING UNIT. To remove the Typing Unit from the Keyboard or Base proceed as follows: Remove the four 151678 screws that secure the Typing Unit to the Keyboard or Base. Remove the 152466 Cable Plug from the right side frame. Lift the typing unit from the Keyboard or Base.

### (1) TYPE BOX

(a) To remove the type box, proceed as follows:

1. Trip the 150075 typebox latch toggle to the right.

2. Lift the right end of the type box upward to an angle of approximately 45 degrees and pull the type box toward the right to disengage it from the left hand bearing stud.

\*(b) To disassemble type box and replace a type pallet, proceed as follows:

1. Remove both screws and nuts that secure the front plate to the rear plate assembly. Separate the two plates.

2. Remove the spring from the pallet by compressing the spring slightly and pulling the formed end out of the slot in the pallet.

Note: This spring should be discarded once it has been removed from its assembly.

3. Replace pallet (omit this step if replacing spring only).

4. Install new pallet spring making sure that the formed end of the spring extends through the slot in the pallet.

5. Line up the front plate with the rear plate assembly and draw the two plates together until the head of the pallet leaves the rear plate by approximately 1/16". This may be accomplished by using two 6-40 screws (at least 11/32" long) and nuts in place of the screws and nuts removed in step 2 and tightening them only enough to hold the pallets as specified above. (Do not clamp the plates together until all pallets have been moved into their correct position).

6. Manipulate the pallets until they fall into their respective openings in the front plate and press plates together.

7. Replace screws and nuts used in step 5 with screws and nuts removed in step 1.

\*(c) To reinstall type box, reverse the procedure used in removing it. CAUTION: THE TYPE BOX SHOULD BE FIRMLY SEATED ON THE BEARING STUDS AND THE POINT OF THE LATCH TOGGLE SHOULD BE PLACED IN THE NOTCH OF THE TYPE BOX PLATE BEFORE MOVING THE TOGGLE TO ITS LATCHED POSITION TO AVOID SPRINGING THE LATCH.

### (2) PRINTING CARRIAGE

(a) To remove the printing carriage, proceed as follows:

1. Loosen the two 151152 screws which clamp the 150230 plate to the wirerope and disengage the carriage from the wire rope.

2. Move the carriage to the left of its track and tilt the lower part forward to disengage the rollers from the track.

\* Indicates Change

3. The disassembly of the printing carriage is shown in bulletin 1149B.

(b) To reinstall the carriage, reverse the procedure used in removing it.

1. Make certain that the 150068 printing arm is correctly re-engaged with the 150598 printing track.

2. Position the carriage clamp on the wire rope for correct printing position as specified in figure 1-57.

### (3) TYPE BOX CARRIAGE

(a) To remove the type box carriage, proceed as follows:

1. Move the type box carriage to its extreme right hand position.

2. Hold the 152548 and 152255 code bar shift bar levers in the marking position and rotate the main shaft so that the type box is in its uppermost position.

3. Remove the 119652 retainer ring from the stud in the right hand end of the 152503 type box carriage link and disengage the link from the carriage.

4. Hold the 153810 ribbon guide forward and the 150311 ribbon reverse lever back and pull the carriage toward the right to disengage it from the carriage track. For disassembly see 1149B.

(b) To reinstall the carriage, reverse the procedure used in removing it. (See Fig. 1-56)

### (4) FRONT PLATE

(a) To remove the front plate, proceed as follows:

1. Remove the Typing Unit from the Base.

2. Remove the 119652 retainer ring from the 152503 type box carriage link right hand stud and disengage the link from the carriage. (See instructions for removing the link retainer in paragraph 10.a.(3).)

3. Remove the two 151659 or 152893 and 153841 screws, which secure the 150245 main bail drive bracket to the 150365 rocker shaft.

4. Remove the 150202 spacing shaft gear.

5. Remove the four 151606 screws which secure the front plate assembly to the typing unit side frames.

6. Pull the front plate assembly forward to disengage it from its connecting parts in the Typing Unit.

7. The disassembly of the front plate is shown in 1149B.

(b) To reinstall the front plate assembly, reverse the procedure used in removing it.

1. Make certain that the 150770 and 150771 code bar bell cranks, the 152596 letters-figures shift slide, the 152522 reversing slide shift lever, the 150438 automatic C.R. - L.F. bell crank, and the 152545 carriage return lever extension are properly engaged with their mating parts before tightening the front plate mounting screws.

2. Replace the 150202 spacing shaft gear. See figure 1-36 for adjustment on phasing the spacing gears.

### (5) STUNT BOX

(a) To remove the stunt box, proceed as follows:

1. Remove the Typing Unit from the Base.

2. Remove the 151627 rear tie bar from the Typing Unit side frames.

3. Remove the 150915 or 155060 line feed function pawl stripper from the 150424 or 155061 stripper blade.

4. Remove the 151657 or 1010 single-double line feed lever screw and disengage the lever from the notch in the stripper blade.

5. Hold the stripper blade toward the right side of the Typing Unit and unhook the 152541 stripper blade left hand arm from the blade. (LP 3, 5, 7, only).

6. Pull the stripper blade toward the left side of the Typing Unit to disengage the stripper blade from the 152542 right hand arm and remove the stripper blade from the Typing Unit. (LP 3, 5, 7, only).



7. Remove the 151692 screws which secure the stunt box assembly in the Typing Unit.

8. Remove the 151637 screw from the 153291 cam shaft drive arm, and slide the drive arm to left out of engagement with the 153300 stripper blade drive arm. (on LP 6 and up.)

9. Lift the stunt box assembly upward to disengage it from its locating brackets and pull toward the rear to disengage all code bar forks from the code bars. Remove the contact assembly and cable clamp, if present, from the stunt box. Remove the stunt box.

10. Disassembly of the stunt box is shown in 1149B.

(b) To reinstall the stunt box assembly:

1. Push it forward in its guide rails to within 1/8 inch of its final position.

2. Manually disengage the function pawls from their function bars and push the stunt box assembly forward and downward until it is latched in place on its locating brackets.

3. Replace the stunt box mounting screws, receptacle and selector magnet wires.

#### (6) FUNCTION BAR, PAWL, AND LEVER

(a) To remove a function bar, proceed as follows:

1. Remove the stunt box from the Typing Unit - See paragraph 10.a.(5).

2. Unhook the 4703 function bar spring.

3. Hold the function bar toward the rear of the stunt box and disengage its function pawl from the function bar.

4. Pull the function bar toward the front to remove it from the stunt box.

(b) To remove a function pawl after the function bar has been removed:

1. Remove the pawl spring.

2. Hold associated function lever back.

3. Remove the pawl from top of stunt box.

(c) To remove a function lever after the function bar and function pawl have been removed:

1. Remove the 152889 shaft retainer plate.

2. Remove the 150547 shaft nearest the front of the stunt box.

3. Unhook spring from function lever and remove the lever through top of stunt box.

4. Disassembly of the stunt box is shown in 1149B.

(d) To replace the function bar, reverse the procedure used in removing it.

#### (7) CODE BARS

(a) To remove the code bar assembly, proceed as follows:

1. Remove the Typing Unit from the Base.

2. Remove the stunt box assembly. See paragraph 10.a.(5).

3. Remove the front plate assembly. See paragraph 10.a.(4).

4. Remove the 151657 screws and 2191 lock washers which secure the code bar assembly to the side frame.

5. Remove the 150301 code bar shift bar retainer plate from 152576 right hand code bar casting.

6. Remove the 152548 and 152255 code bar shift bars and 152257 springs from the code bars and pull the code bar assembly forward and to the left.

7. Disassembly of the code bars is shown in 1149B.

(b) To reinstall the code bar assembly, reverse the procedure used in removing it, except do not tighten the mounting screws.

1. Hook the short extension of the 152257 spring in the spring hole of the 152256 code bar shift bar. The short extension of the springs should be hooked from the bottom of the code bar and the long extension should be hooked over the top of the code bar shift bar.

2. Loosen the 151630 code bar assembly tie bar screws and hold the code bar castings back and downward firmly against their locating surfaces on the side frame and tighten the four mounting screws.

3. Tighten the two tie bar screws.

#### (8) MAIN SHAFT

(a) To remove the main shaft, proceed as follows:

1. Remove the Typing Unit from the Base.
2. Remove the selector cam-clutch assembly. See paragraph 10.a.(13).
3. Set the Typing Unit upside down.
4. Return the carriage to its left-hand position.
5. Remove the 151686 screw which secures the 150673 spacing shaft in the 150668 spacing pawl hub.
6. Remove the spacing shaft with gear.
7. Remove the 151686 screw which secures the 152454 or 153823 collar and the 152455 or 153824 clamp from right end of main shaft. Remove the 152573 main shaft right hand bearing retainer plate.
8. Remove the 150010 retainer plate at the 150046 clutch bearing and remove the 150244 link.
9. Remove the two 151630 screws from the 152537 main shaft left hand bearing clamp.
10. Unhook the 74701 or 135716, 74712 and 70388 spring from the trip levers and latch levers associated with all clutches. Position the code bar clutch so that the low part of the clutch cam clears the spring cam on the cam follower. Unhook the 74712 code bar clutch cam follower spring.
11. Remove the 153300 function clutch arm by removing the two 151630 screws and 119652 Retainer Ring if present.
12. Unhook the 154688 springs from the 153573 function bar reset bail.
13. Move the main shaft assembly toward

the left to disengage the code bar clutch and function clutch links from their connecting pins.

14. Lift the left end of the shaft assembly out of the side frame and position the shaft so that the function clutch link passes the suppression assembly bracket and remove the shaft assembly from the typing unit.

15. When assembling the clutches which have cams and disks marked "O" for identification, the marked side of the parts should face away from the clutch side of the assembly. The function and code bar clutches should have their driving links assembled so that the longer end of the hub faces away from the clutch side of the assembly.

16. Disassembly of the main shaft and clutches is shown in 1149B.

(b) To re-install the shaft assembly, reverse the procedure used in removing it.

(c) To phase the spacing gears, see figures 1-36 and 1-37 respectively.

(d) Remake the stripper blade drive cam position adjustment (Figure 1-68).

#### (9) UPPER DRAW WIRE ROPE

(a) To remove the upper draw wire rope, proceed as follows:

1. Return the carriage to the left hand position.
2. Loosen the 112626 nut on the front end of the 150197 spring drum bearing post. Operate the 150237 ratchet escapement lever to unwind the 74272 carriage return spring.
3. Remove the 150712 wire rope from the 150230 clamp plate on the printing carriage, and the 152521 clamp on the 150728 oscillating rail slide.
4. Loosen the 151618 clamp screw which secures the wire rope to the 150827 spring drum, and remove the wire rope from the drum.
5. Remove the 151618 or 151658 screw in the spacing drum which secures the ends of the wire rope, and remove the rope from the drum.

6. Disassembly of the wire rope, spring drum and spacing drum is shown in 1149B.

(b) To replace the upper draw wire rope, reverse the procedure used in removing it.

#### (10) LOWER DRAW WIRE ROPE

(a) To remove the lower draw wire rope, proceed as follows:

1. Remove the 151618 or 151658 screw which secures the 150225 lower draw wire rope to the 152587 or 154627 spacing drum, and remove the end of the rope from the drum.

2. Loosen the 151637 screws which secure the 150796 margin indicator cam disk on the spring drum and position the disk to expose the wire rope mounting screw.

3. Remove the 151618 lower draw wire rope screw and move the rope from the spring drum.

4. Loosen the 151632 screws in the 150800 bearing studs which mount 150224 printing carriage pulleys and move the studs toward the center of the Typing Unit.

5. Disassembly of the lower draw wire rope is shown in 1149B.

(b) To replace the wire rope, reverse the procedure used in removing it.

1. Make certain that the lower draw wire rope is in front of the printing carriage wire rope in the track around the drums.

2. Adjust the position of the type box, the printing carriage, and the wire rope tension as specified in the figures 1-49, 1-53, and 1-56.

#### (11) PLATEN (FRICTION FEED)

(a) To remove the platen, proceed as follows:

1. Remove the 150715 line feed spur gear.

2. Remove the 150719 and 150720 platen bearing retainers.

3. Remove the 152832 paper finger shaft.

4. Hold off the 150900 detent and lift the platen out of the side frame.

5. Disassembly of the platen is shown in 1149B.

(b) To replace the platen, reverse the procedure used in removing it.

1. When replacing each platen bearing retainer, put its upper screw in first. Leave the screw slightly loose. Press the lower end of the retainer downward and hook it into the elongated hole in the side frame. Replace the lower screw. Tighten both screws.

#### \*(12) PLATEN (SPROCKET FEED)

(a) To remove the platen proceed as follows:

1. Remove the paper fingers or guide bracket assembly.

2. Remove the spur gear from left end.

3. Remove the 156719 and 150720 platen bearing retainers.

4. Hold off the 153676 detent and remove the platen.

5. Remove sprocket hub assembly from platen assembly.

6. Insert the 153673 shaft tool into the hub and fasten it with the 151346 screw.

7. Remove the 157286 clamp and 153699 cam from the assembly.

8. To replace a pin, rotate the hub assembly within the retaining tool with a tommy wrench inserted in the shaft tool until the desired pin is opposite the notch in the retaining tool. A pin may then be removed or replaced.

Note: While rotating the hub, the notch must be covered to prevent the pins from being released.

9. Pack with grease.

10. Disassembly of platen shown in 1149B.

\* Indicates Change

(b) To replace the platen, reverse the procedure used in removing it. When replacing each platen bearing retainer, put its upper screw in first. Leave the screw slightly loose. Press the lower end of the retainer downward and hook it into the elongated hole in the side frame. Replace the lower screw. Tighten both screws.

### (13) SELECTOR CAM-CLUTCH

(a) To remove the selector cam-clutch, proceed as follows:

1. Lift the 152410 push lever reset bail cam follower from its cam and latch it in its raised position on the push lever guide. Lift the selector levers and the marking lock lever by moving the marking lock lever forward until the armature drops behind it.

2. Remove the 151642 screw which mounts the 150001 selector clutch drum and position the cam clutch so that the stop lug on the 150028 disk is in the uppermost position.

3. Place 152410 or 158903 reset bail in raised position. Hold 152432 or 158928 stop arm and 152405 or 158902 marking lock lever to left, grasp cam-clutch by cam-disk (not by drum) and pull forward while rotating cam-clutch slowly. Cam-clutch should come off easily. Do not force it.

4. Disassembly of the selector cam clutch is shown in 1149B.

(b) To replace the cam-clutch assembly, reverse the procedure used in removing it except:

1. As the cam-clutch approaches its fully installed position, move the trip shaft lever and the cam-clutch latch lever so that they ride on their respective cams.

2. Restore the push lever reset bail and the armature to their operating position.

### (14) SELECTOR MECHANISM

(a) To remove the selector mechanism, proceed as follows:

1. In order to remove the selector mechanism from the Typing Unit the cam-clutch assembly must be removed. See paragraph 10.a.(13).

2. Remove the 152457 felt wick. Remove

the 151658 screw which secures the selector mechanism to the 152546 bracket on the code bar positioning mechanism.

3. Remove from the selector mechanism the 150563 spring which connects with the 152640 common transfer lever on the code bar positioning mechanism.

4. Remove the remaining three 151630 selector mounting screws and lift the selector from the main shaft bearing housing.

5. Disassembly of the selector mechanism is shown in 1149B.

(b) To replace the selector mechanism, reverse the procedure used in removing it.

(c) For readjustment of selector mechanism see the adjusting figures 1-17 to 1-19 and 1-21 to 1-23.

### (15) CODE BAR POSITIONING MECHANISM

(a) To remove the code bar positioning mechanism, proceed as follows:

1. Remove from the selector the 150563 spring attached to the common transfer lever and restore any operating push levers to the spacing position by raising the 152410 reset bail.

2. Loosen the 151721 clamp screw on the 150447 shift lever drive arm, and remove the two screws which mount the mechanism - the 151630 to the side frame, and the 151658 to the 152400 selector plate.

3. Manipulate the 152635 to 152640 transfer levers and 152548 or 152255 code bar shift bars while gently twisting the mechanism so as to slide the mechanism off the code bar shift bars.

4. Disassembly of the code bar positioning mechanism is shown in 1149B.

(b) To replace the mechanism on the Typing Unit, reverse the procedure used in removing it.

1. With the main shaft in the stop position, push the code bar shaft bars to the marking position (left front view). Manipulate the code bar shift bars and transfer levers so that the shift bars line up with their respective slots in the 150525 bracket, and slide

the shift bars through the slots, one at a time (leave the bottom slot vacant).

#### (16) SELECTOR MAGNET ASSEMBLY

(a) To remove the selector magnet assembly, proceed as follows:

1. Remove the two 151657 screws and 3598 nut which mount the range finder to the selector.
2. Remove the 152468 cable from the 1028 coil terminal screws.
3. Remove the two 151658 magnet assembly mounting screws and lift the assembly out.
4. Disassembly of the selector magnet assembly is shown in 1149B.

b. KEYBOARD (EARLIER DESIGN) - Remove the four 151549 screws at each corner of the Keyboard that secure the Keyboard to the cradle. Remove the 152465 plug from its receptacle at the left rear corner of the base. Lift the keyboard from the cradle.

#### (1) SIGNAL GENERATOR

(a) To remove the signal generator from the Keyboard, proceed as follows:

1. Remove the two 151152 screws located to the right and left of the contact box, and raise the 151358 contact box. (Do not unsolder connections if box is connected to metal tubing). If wire connections to contact box are flexible, unsolder the wires inside the box and do not remove the box.
2. Remove the four 151642 mounting screws which mount the signal generator casting, two at the front end of the casting, and two at the rear. (NOTE: if the unit is equipped with an electrical signal line break mechanism, remove the mechanism by removing its two mounting screws.
3. Lift the signal generator upward from the Keyboard.
4. Disassembly of the signal generator is shown in 1149B.

(b) To replace the signal generator, reverse the procedure used in removing it.

1. The code bar bail latch should be under

the code lever bail latch lever, and in the notches of all code bars, trip bar and upstop bar, the break rod in its guide hole, and the clutch trip bail extension in the clutch trip bar notch.

2. Recheck the non-repeat lever adjustment figure 4-13, the contact box adjustment figure 4-10, and the code lever adjustment figure 4-19.

#### (2) KEYBOARD SELECTOR CAM ASSEMBLY

(a) To remove cam assembly from signal generator, proceed as follows:

1. Remove signal generator from Keyboard Base. See paragraph 10.b.(1) above.
2. Disconnect the 90260 clutch latch lever spring.
3. Disconnect the 31636 clutch stop lever spring.
4. Disconnect the 125268 flutter lever spring.
5. Remove the 112625 front nut of the 151157 stationary shaft.
6. Remove the two 151658 screws that hold the 151064 rear plate to casting.
7. Remove the shaft assembly by lifting it upward and pulling to the rear simultaneously.
8. Disassembly of the cam assembly is shown in 1149B.

(b) To replace the Keyboard selector cam assembly, reverse the procedure used in removing it.

#### (3) KEYBOARD LABEL

(a) To remove the labels, proceed as follows:

1. Remove the 151354 or 153118 plastic cover mounting screw and remove the plastic cover.
2. Pick up plastic cover at top edge first.

(b) To replace the Keyboard label, reverse the procedure used in removing it.

#### (4) KEYLEVER COVER

(a) To remove cover from the Keyboard, proceed as follows:

1. Remove the 151353 label covers and labels. See paragraph 10.b.(3).

2. Remove the four 151346 screws located under the labels, two at the extreme right side and two at the extreme left side.

3. Pull keylever cover forward to remove.

4. See 1149B for disassembly.

(b) To replace the keylever cover, reverse the procedure used in removing it.

(c) To remove the 153117 cover from base, proceed as follows:

1. Remove the two 151658 screws located inside the sealing plate, one at the right side and one at the left side.

2. Pull keylever cover forward and downward to unhook it from two studs near bottom.

(d) To replace the keylever cover, reverse the procedure used in removing it.

#### (5) KEYLEVER

(a) To remove keylever, proceed as follows:

1. Use keylever remover tool No. 151383 in the following manner. Insert the smaller lug of the keylever remover in the slot of the keylever and engage the shoulder of the larger lug on the top of the code lever. Pry upward to unsnap keylever from code lever. The plastic keytop should not be removed from any keylever to change a character.

2. See 1149B for disassembly.

(b) To replace the keylever, reverse the procedure used in removing it.

#### (6) SPACE BAR

(a) To remove space bar, proceed as follows:

1. Remove the keylever cover. See paragraph 10.b.(4).

2. Remove the two 151223 pivot shoulder screws on left and right sides of the 151045 space bar

assembly.

3. See 1149B for disassembly of the space bar.

(b) To replace the space bar, reverse the procedure used in removing it.

#### (7) KEYLEVER GUIDE PLATE

(a) To remove keylever guide plate, proceed as follows:

1. Remove the keylever cover. See paragraph 10.b.(4).

2. Remove the six 151346 mounting screws on top side of guide plate.

3. See 1149B for disassembly.

(b) To replace the keylever guide plate, reverse the procedure used in removing it.

#### (8) KEYBOARD LOCKBALL CHANNEL

(a) To remove lockball channel, proceed as follows:

1. Remove the keylever cover. (See paragraph 10.b.(4).

2. Remove the two 151637 channel mounting screws at the left and right ends.

3. Pull channel forward with caution to avoid dropping the wedges that are located on the code levers. Wedges must be replaced separately when reassembling.

4. See 1149B for disassembly.

(b) To replace the keyboard lockball channel, reverse the procedure used in removing it.

#### (9) SEALING PLATE

(a) To remove sealing plate proceed as follows:

1. Remove the keylever cover. See paragraph 10.b.(4).

2. Remove the keylevers. See paragraph 10.b.(5).

3. Disconnect the 151105 space bar link (keyboard only) at its snap connection.

4. Remove all sealing plate mounting screws.

5. See 1149B for disassembly.

(b) To replace the sealing plate, reverse the procedure used in removing it.

#### (10) KEYBOARD LOCK-LOCAL LINE FEED MECHANISM

(a) To remove keyboard lock-local line feed mechanism, proceed as follows:

1. Remove the signal generator from the keyboard. See paragraph 10.b.(1). above.

2. Unhook the 7618 code lever bail spring from the 151840 code lever bail.

3. Loosen the two 151090 pilot screws and remove the 151840 code lever bail.

4. Remove the 119651 retaining ring from the 151858 local line feed trip bail.

5. Remove the two 151692 mounting screws and remove the mechanism through the hole in the bottom of the base.

6. See 1149B for disassembly.

(b) To replace the keyboard lock-local line feed mechanism, reverse the procedure used in removing it.

#### (11) KEYBOARD CODE BAR ASSEMBLY

(a) To remove code bar assembly, proceed as follows:

1. Remove the keylever cover. See paragraph 10.b.(4).

2. Remove the keylevers. See paragraph 10.b.(5).

3. Disconnect the 151105 space bar link at its snap connection.

4. Remove the signal generator. See paragraph 10.b.(1).

5. Remove the two 151658 and two 151346 code bar assembly mounting screws located on top of base.

6. Remove the two 151692 mounting screws and remove the 151856 local C.R. bracket.

7. Remove the keyboard lock-local line feed mechanism. See paragraph 10.b.(10).

8. Remove the 3599 nut and the 151008 code lever bail latch lever with spring. Remove the three 151657 screws which mount the 151367 non-repeat bell crank plate assembly. Remove the plate assembly. Remove code bar assembly through the opening in top side of the base.

9. The disassembly of the keyboard code bar assembly is shown in 1149B.

(b) To replace the keyboard code bar assembly, reverse the procedure used in removing it.

#### (12) CODE BAR

(a) To remove a code bar from the keyboard assembly, proceed as follows:

1. Remove code bar assembly. See paragraph 10.b.(11).

2. Disconnect the 42661 code bar springs.

3. Remove the 151082 mounting screw and remove the 151102 lock bar pawl from the 151849 code lever guide.

4. Loosen the 151688 mounting screws for the left and right code bar guides until they are friction tight and lift the 151023 guides to their extreme upward position.

5. Remove code bar by sliding it to the left or right to get one end of the code bar out of its guide.

6. Disassembly of the code bar mechanism is shown in 1149B.

(b) To replace a code bar, reverse the procedure used in removing it.

#### c. KEYBOARD (NEW DESIGN)\*

##### (1) SIGNAL GENERATOR

\*See Page 1-2, Paragraph k.

(a) To remove the signal generator assembly, proceed as follows:

1. Remove the typing unit if it is present.
2. Remove the 154131 contact box cover, and disconnect the signal line leads from the 154042, 154043 contact terminals.
3. Remove the two 153841 hold-down screws at the front of the 154200 signal generator frame, and the 74805 screw at the right rear of the frame.
4. Lift the signal generator carefully, while holding the universal bail back so that the non-repeat lever clears and its spring will not be excessively stretched.
5. Disassembly of signal generator is shown in 1149B.

#### CAUTION

If the non-repeat lever gets pulled down approximately 90 degrees from normal position, its spring might be stressed beyond elastic limits which will result in assembly malfunction.

(b) To replace the signal generator, reverse the procedure used in removing it.

#### (2) KEYBOARD

(a) To remove the keyboard assembly, proceed as follows:

1. Remove the typing unit and signal generator assembly as specified in paragraph 10.a. and b.(1).
2. Remove the plastic windows and labels, hood, seal, and seal plate as specified in paragraph 10.b.(3).
3. Remove the four 151631 screws which hold the 154210, 154211 front frames to the front of the 154000 base.
4. Remove the two 151632 screws which hold the 154068, 154069 right and left code lever guide brackets on the top of the base, and the two 151632 screws at the extreme right and left of the 154055 front bracket which hold it on the base.

5. When these four screws in front and four on top of the base have been removed, tip up the front of the keyboard assembly and pull it forward, disengaging the function levers.

6. Note that all function levers are under their corresponding function bails - except the keyboard lock function lever - which fits on top of its function bail.

7. When reassembling, depress the keyboard lock keylever so that the lock function lever will go in over its bail instead of under as the other function levers should.

8. Disassembly of the Keyboard is shown in 1149B.

#### NOTE

It is easier to disassemble and reassemble the keyboard assembly with the base standing up on its rear side.

(b) To replace the keyboard assembly, reverse the procedure used in removing it.

#### (3) KEYBOARD LABELS

(a) To remove the plastic windows and labels, hood, seal, and seal plates, proceed as follows:

1. Remove the four 154202 screws which secure the 154198 windows and labels.
2. Remove the two 151632 screws underneath the 154110 hood which hold the hood to the 154203 hood mounting bracket; and remove the four 151659 screws on top of the hood which hold it to the 154210, 154211 left and right frame mounting brackets.
3. Pull the hood forward to remove.
4. Stretch the 154020 rubber keyboard seal off its 154057, 154058 plates.
5. Remove the four 151442 screws and two 154203 hood mounting brackets.
6. Remove the 154058 upper seal plate by unscrewing the three 151722 screws at its rear.



7. Remove the 154057 lower seal plate by unscrewing the two 151632 screws at its front.

8. See 1149B for disassembly.

(b) To replace the Keyboard labels reverse the procedure used in removing it.

#### (4) CONTACT BOX

(a) To remove the contact box assembly, proceed as follows:

1. Remove the 154131 contact box cover and disconnect the signal line leads.

2. Unhook the 86304 drive link spring.

3. Unscrew the two 151632 screws at the front of the 154009 front plate which hold the contact box assembly.

4. Disengage the 156644 drive link from the transfer bail and lift off the assembly. It is most economical to replace the entire contact assembly if contacts need replacement.

5. Disassembly of the contact box is shown in 1149B.

(b) To replace the contact box, reverse the procedure used in removing it.

#### (5) TRANSFER LEVER LOCKING BAIL

(a) To remove the transfer lever locking bail, proceed as follows:

1. Remove the signal generator assembly from the keyboard as specified in paragraph 10.b.(1).

2. Remove the contact box assembly as specified in paragraph 10.c.(4).

3. Remove the 70388 transfer lever locking bail spring.

4. Extract the 154140 locking bail by unlatching the clutch and rotating the shaft to position the cam in such a way so that the locking bail can be unhooked and dropped down from its guide post. Turn the locking bail clockwise until it forms a right angle with its guide and extract it out the bottom of the frame.

5. Disassembly of the mechanism is shown in 1149B.

(b) To replace the transfer lever locking bail, reverse the procedure used in removing it.

#### NOTE

It may be necessary to move the shaft back and forth to position the cam for maximum clearance.

#### (6) SIGNAL GENERATOR SHAFT

(a) To remove the cam, clutch, and shaft assembly, proceed as follows:

1. Remove the transfer lever locking bail as specified in paragraph 10.c.(5).

2. Remove the two 151631 screws which mount the 154101 clutch shaft rear mounting plate to the 154200 signal generator frame, and remove the 112626 nut which locks the shaft to the front of the frame.

3. Hold the 154033 clutch latch lever and the 154034 clutch stop lever away and pull back on the shaft rear mounting plate to disengage the shaft from the front plate.

4. Remove the entire cam, clutch, and shaft assembly by rotating it to clear the various transfer levers. The 154019 code bar bail eccentric follower, the 154138 felt washer, and the 154083 cam spacer will all fall free. These must be repositioned before reassembly.

5. To take the cam (with clutch assembly) off the shaft, disengage the clutch by holding the clutch shoe lever against the stop lug and slide the cam and clutch off.

6. Disassembly of the shaft assembly is shown in 1149B.

(b) To replace the shaft assembly, reverse the procedure used in removing it.

#### (7) KEYLEVER GUIDE PLATE

(a) To remove the keylever guide plate, proceed as follows:

1. Remove the plastic windows and labels, and hood as specified in paragraph 10.c.(3).

2. Remove the 151045 space bar by unscrewing the two 151223 shoulder screws that fasten it to the 154117 space bar bail.

3. Remove the 151659 screw on the key-lever guide plate under the space bar and the two 151659 screws in the upper corners of the plate which hold the plate to the frame.

4. Work the guide plate off the keytops and let them fall free.

5. Disassembly of the mechanism is shown in 1149B.

(b) To replace the guide plate over the key-levers, flop all levers to the rear. Place the front end of the guide plate down on the frame; and push the keylevers into their respective holes, starting with the bottom row and proceeding upward to the top row.

#### d. MOTOR

Remove the four screws that secure the motor base plate to the base. Remove the screws that secure cover and remove the motor leads from terminals 1 and 2 of the terminal board.

#### (1) SYNCHRONOUS

(a) Disassembly of the Synchronous Motor is shown in 1149B.

#### (2) GOVERNED

(a) Disassembly of the Governed Motor is shown in 1149B.

(b) In order to prolong the life of governor slip ring brushes, the slip rings are machined to close concentricity requirements after assembly. These slip rings should not be replaced unless facilities for machining operation are available.


(c) After the Governor parts are assembled, the Governor is carefully balanced to reduce vibration; therefore, when it becomes necessary to replace contacts, only the parts being replaced should be moved.

#### e. ELECTRICAL SERVICE UNIT

In order to remove the Electrical Service Unit completely from the Cabinet, it will be necessary to remove the wires from the 118759 terminal blocks. However, the panel may be turned bottom side upward for maintenance purposes by removing the two 151437 studs.

## SECTION 2 - VARIABLE FEATURE ADJUSTMENTS

## 1. REPEAT SPACE MECHANISM

REPEAT SPACE LEVER SPRING

- (1) REQUIREMENT  
 MIN. 1 OZ.  
 MAX. 1-1/2 OZ.  
 TO PULL REPEAT SPACE LEVER IN  
 ENGAGEMENT WITH RESET BAIL LATCH.
- (2) REQUIREMENT  
 WITH POWER APPLIED AND THE  
 SPACE BAR FULLY DEPRESSED,  
 THE SPACE CHARACTER SHOULD  
 BE REPEATED AS LONG AS THE  
 SPACE BAR IS HELD DEPRESSED.

NOTE: FOR EARLIER DESIGN SEE FIGURE 4-43

FIGURE 2-1 KEYBOARD REPEAT ON SPACE MECHANISM


2. TIME DELAY MECHANISM

FIGURE 2-2 KEYBOARD OR BASE, TIME DELAY MECHANISM

2. TIME DELAY MECHANISM




FIGURE 2-3 KEYBOARD OR BASE, TIME DELAY MECHANISM, LEFT SIDE VIEW

## 2. TIME DELAY MECHANISM





FIGURE 2-4 KEYBOARD OR BASE, TIME DELAY MECHANISM, LEFT SIDE VIEW

## 2. TIME DELAY MECHANISM

TIME DELAY DISABLING DEVICE

## REQUIREMENT

DISABLE THE TIME DELAY MECHANISM WHEN NOT REQUIRED.

## TO ADJUST

LOOSEN THE ADJUSTING LEVER MOUNTING SCREW AND PRESS DOWNWARD ON THE LEVER TO RAISE ECCENTRIC FOLLOWER OUT OF ENGAGEMENT WITH ITS RATCHET WHEEL.

NOTE: FOR ADJUSTMENT OF EARLIER DESIGN MECHANISMS SEE FIGURE 4-44

FIGURE 2-5 KEYBOARD OR BASE, TIME DELAY DISABLING DEVICE


3. SIGNAL LINE BREAK MECHANISM (BASE)

FIGURE 2-6 BASE, BREAK MECHANISM



## 4. PAPER FEED OUT MECHANISM




FIGURE 2-7 KEYBOARD OR BASE, LOCAL PAPER FEED-OUT MECHANISM



5. SPROCKET FEED MECHANISM

FIGURE 2-8 TYPING UNIT, PLATEN AND PRINTING MECHANISM

5. SPROCKET FEED MECHANISM



(A) LEFT MARGIN

(1) REQUIREMENT

TYPE BOX CLUTCH DISENGAGED. SPACING DRUM FULLY RETURNED. TYPE BOX SHIFTED TO LETTERS POSITION. CLEARANCE BETWEEN CENTER OF LETTERS PRINT INDICATOR ON TYPE BOX AND CENTERLINE OF SPROCKET PINS IN LEFT HUB

MIN. 5/16 INCH  
MAX. 7/16 INCH

(2) REQUIREMENT

SPACING CLUTCH DISENGAGED. FRONT SPACING FEED PAWL FARTHEST ADVANCED. SPACING DRUM FULLY RETURNED. PLAY IN SPACING SHAFT GEAR (FIG. 1-36) TAKEN UP CLOCKWISE. CLEARANCE BETWEEN PAWL AND SHOULDER OF RATCHET WHEEL TOOTH IMMEDIATELY AHEAD

MIN. 0.002 INCH  
MAX. 0.015 INCH

(3) REQUIREMENT

REAR PAWL, WHEN FARTHEST ADVANCED, SHOULD REST AT BOTTOM OF INDENTATION BETWEEN RATCHET WHEEL TEETH TO ADJUST POSITION CARRIAGE RETURN RING WITH MOUNTING SCREWS LOOSENED.

(B) PRINTING HAMMER STOP BRACKET

- (1) FOR UNITS WITH THICK TYPEBOX AND DUMMY TYPE PALLETS USE CORRESPONDING STANDARD ADJUSTMENT EXCEPT CLEARANCE BETWEEN PRINTING HAMMER AND DUMMY TYPE PALLET SHOULD BE  
MIN. SOME MAX. 0.020 INCH
- (2) FOR UNITS WITH THIN TYPEBOX - NO DUMMY TYPE PALLETS, USE CORRESPONDING STANDARD ADJUSTMENT.

(C) RIGHT MARGIN

- (1) FOR UNITS WITH LIMITED ADJUSTMENT SPACING DRUM, USE CORRESPONDING STANDARD ADJUSTMENT.
- (2) FOR UNITS WITH UNIVERSAL SPACING DRUM, USE CORRESPONDING STANDARD ADJUSTMENT.

(D) PRINTING CARRIAGE POSITION  
USE STANDARD ADJUSTMENT

(E) TYPE BOX ALIGNMENT  
USE STANDARD ADJUSTMENT

FOLLOWING THIS ADJUSTMENT, ALL SCREWS SHOULD BE TIGHTENED.




FIGURE 2-9 TYPING UNIT, PLATEN AND SPACING MECHANISM

5. SPROCKET FEED MECHANISM





FIGURE 2-10 TYPING UNIT, SPROCKET FEED PLATEN

5. SPROCKET FEED MECHANISM



**PAPER FINGER OR GUIDE BRACKET**

(1) REQUIREMENT  
 SPROCKET PIN SHOULD BE CENTRALLY LOCATED IN THE PAPER FINGER OR GUIDE BRACKET SLOT.

(2) REQUIREMENT  
 THE GAP BETWEEN THE PLATEN AND THE PAPER FINGER OR GUIDE BRACKET SHOULD BE:

STAPLED MULTIPLE COPY	SINGLE COPY OR UNSTAPLED MULTIPLE COPY
MIN. 0.090 INCH	0.050 INCH
MAX. 0.105 INCH	0.060 INCH

TO ADJUST  
 WITH PAPER FINGER OR GUIDE BRACKET ASSEMBLY IN LATCHED POSITION, LOOSEN BOTH CLAMP SCREWS, POSITION ASSEMBLY HORIZONTALLY TO MEET REQUIREMENT (1). ROTATE ASSEMBLY TO MEET REQUIREMENT (2).

(3) REQUIREMENT (NOT ILLUSTRATED)  
 MIN. 0.035 INCH  
 BETWEEN LEADING EDGE OF PAPER FINGER OR GUIDE BRACKET AND RIBBON GUIDE. BOTH RIGHT AND LEFT PAPER FINGERS MUST BE PARALLEL TO THE SAME PRINTED LINE AS GAUGED BY EYE.

TO ADJUST  
 SELECT LETTERS COMBINATION AND ROTATE TYPE BOX CLUTCH 1/2 REVOLUTION. POSITION PAPER FINGERS BY MEANS OF ELONGATED MOUNTING HOLES. AFTER TIGHTENING THE SCREWS RECHECK THESE REQUIREMENTS.





FIGURE 2-11 TYPING UNIT, PLATEN MECHANISM

## 5. SPROCKET FEED MECHANISM

REQUIREMENT

MIN. 6 OZS.

MAX. 8 OZS.

TO START DEPRESSING THE PIN.

REQUIREMENT

THE CLEARANCE BETWEEN THE PLATEN AND THE FRONT EDGE OF THE PAPER GUIDE SHOULD BE

STAPLED SINGLE COPY OR

MULTIPLE COPY UNSTAPLED COPY

MIN. 0.090 INCH 0.050 INCH

MAX. 0.105 INCH 0.060 INCH

TO ADJUST

POSITION THE GUIDEWITH ITS REAR MOUNTING SCREWS LOOSENED.

(C) RIBBON REVERSE SPUR GEAR  
USE STANDARD ADJUSTMENT(D) RIBBON REVERSE DETENT  
USE STANDARD ADJUSTMENT(E) LINE FEED BAR BELL CRANK SPRING  
USE STANDARD ADJUSTMENT EXCEPT  
MIN. 28 OZS.  
MAX. 38 OZS.  
TO START BAR MOVING.

FIGURE 2-12 TYPING UNIT, PLATEN AND PAPER TRAY

5. SPROCKET FEED MECHANISM





FIGURE 2-13 CABINET, FRONT AND REAR FORM GUIDES

5. SPROCKET FEED MECHANISM



COPY WINDOW(CABINET)

REQUIREMENT

SMALL DOOR OPEN AND POSITIONED SO THAT CLEARANCE BETWEEN FRONT FORM GUIDE AND WINDOW IS AT MINIMUM CLEARANCE.


MIN. 0.060 INCH  
MAX. 0.080 INCH

TO ADJUST

POSITION WINDOW WITH FOUR WINDOW RETAINER MOUNTING SCREWS LOOSENED.

NOTE

IF STAPLED PAPER IS USED, STAPLES SHOULD PASS FREELY THROUGH SLOT. IF THEY DO NOT, INCREASE CLEARANCE AS REQUIRED.




(BOTTOM VIEW)

FIGURE 2-14 CABINET, FORM GUIDE AND COPY WINDOW



## 5. SPROCKET FEED MECHANISM

PLATEN DETENT BAIL SPRING TENSION

USE STANDARD ADJUSTMENT (FIGURE 1-67)

FIGURE 2-15 TYPING UNIT, SPROCKET FEED MECHANISM

6. HORIZONTAL TABULATOR MECHANISM (NEW DESIGN)

NOTE: FOR EARLIER DESIGN SEE FIGURES 4-48 THROUGH 4-53.





FIGURE 2-16 TYPING UNIT, HORIZONTAL TABULATOR MECHANISM, LEFT VIEW

## 6. HORIZONTAL TABULATOR MECHANISM

OPERATING LEVER SLIDE ARM

## NOTE

PRIOR TO THIS ADJUSTMENT CHECK THE FUNCTION RESET BAIL BLADE ADJUSTMENT.

## REQUIREMENT

ON UNITS WITH TWO-STOP FUNCTION CLUTCHES. FUNCTION CLUTCH DISENGAGED. TYPE BOX CLUTCH ROTATED 1/2 REVOLUTION PAST STOP POSITION. ON UNITS WITH ONE-STOP FUNCTION CLUTCH, ROTATE FUNCTION CLUTCH UNTIL FUNCTION PAWL STRIPPER BLADE IS IN ITS LOWER POSITION AND THE FUNCTION RESET BAIL ROLLER IS ON THE HIGH PART OF ITS CAM. HORIZONTAL TABULATOR FUNCTION PAWL PULLED TO REAR UNTIL LATCHED ON ITS FUNCTION BAR. CLEARANCE BETWEEN FRONT END OF OPERATING LEVER SLIDE ARM AND BLOCKING SURFACE OF BLOCKING LEVER

MIN. 0.020 INCH


MAX. 0.030 INCH

## TO ADJUST

POSITION SLIDE ARM ON OPERATING LEVER WITH MOUNTING STUD FRICTION TIGHT.

## NOTE

WHEN PULLING FUNCTION PAWL TO THE REAR, IF THE OPERATING LEVER CAM ARM SHOULD BE STRIPPED OFF THE TABULATOR SLIDE ARM BEFORE THE FUNCTION PAWL IS LATCHED ON THE FUNCTION BAR, TEMPORARILY DISABLE THE STRIPPER BAIL ARM BY LOOSENING ITS ADJUSTING SCREW.

OPERATING LEVER SLIDE ARM SPRING

## REQUIREMENT

TRIP LEVER ARM LATCH BAIL SPRING UNHOOKED. OPERATING LEVER IN OPERATED POSITION WITH SLIDE ARM AGAINST BLOCKING LEVER.

MIN. 8-3/4 OZS.

MAX. 10-3/4 OZS.

TO START LINK MOVING.

## NOTE

ON UNITS EQUIPPED WITH TRANSMITTER CONTROL CONTACT, HOLD CONTACT SPRING AWAY FROM STUD WHEN MEASURING TENSION.

OPERATING LEVER ADJUSTING PLATE

## REQUIREMENT

OPERATING LEVER IN UNOPERATED POSITION. TAKE UP PLAY IN SLIDE ARM AND BLOCKING LEVER TO MINIMIZE CLEARANCE. CLEARANCE BETWEEN FRONT END OF SLIDE ARM AND LOWER PROJECTION OF BLOCKING LEVER

MIN. 0.025 INCH

MAX. 0.040 INCH

## TO ADJUST

POSITION ADJUSTING PLATE ON BRACKET WITH MOUNTING SCREWS LOOSENED.

## NOTE

IF OPERATING LEVER SLIDE ARM OR OPERATING LEVER ADJUSTING PLATE ADJUSTMENT IS CHANGED ON UNITS EQUIPPED WITH TRANSMITTER CONTROL CONTACT, CHECK CONTROL CONTACT GAP AND REMAKE IF NECESSARY.

FIGURE 2-17 TYPING UNIT, HORIZONTAL TABULATOR MECHANISM, LEFT VIEW

6. HORIZONTAL TABULATOR MECHANISM




FIGURE 2-18 TYPING UNIT, HORIZONTAL TABULATOR MECHANISM (LEFT VIEW)

6. HORIZONTAL TABULATOR MECHANISM




FIGURE 2-19 TYPING UNIT, HORIZONTAL TABULATOR MECHANISM

## 6. HORIZONTAL TABULATOR MECHANISM





FIGURE 2-20 TYPING UNIT, HORIZONTAL TABULATOR MECHANISM

## 6. HORIZONTAL TABULATOR MECHANISM

**TABULATOR PAWL (PRELIMINARY)****NOTE:**

BEFORE MAKING THIS ADJUSTMENT, CHECK LEFT MARGIN AND SPACING GEAR PHASING ADJUSTMENTS.

**PURPOSE**

TO SELECT TABULATOR STOP TO BE USED AS REFERENCE IN MAKING FINAL TABULATOR PAWL HORIZONTAL AND VERTICAL ADJUSTMENTS.

**PROCEDURE**

- (1) BEGINNING WITH 15TH SLOT COUNTERCLOCKWISE FROM ROLLER ON TABULATOR RING, PLACE TABULATOR STOPS APPROXIMATELY AN EQUAL NUMBER OF SLOTS APART AROUND REMAINING SLOTTED PERIPHERY OF RING CORRESPONDING TO LENGTH OF PRINTED LINE.
- (2) TO MOVE STOPS, HOOK SMALL SPRING HOOK IN HOLE AND PULL OUT RADially FROM DRUM. HOLDING STOP AWAY FROM DRUM, SLIDE IT ON GARTER SPRING TO DESIRED LOCATION AND INSERT IN SLOT. SPACING DRUM MAY HAVE TO BE ROTATED TO MAKE SOME SLOTS ACCESSIBLE. **CAUTION:** MAKE SURE ALL STOPS ARE FIRMLY SEATED AND NOT TURNED SIDEWAYS.
- (3) DISENGAGE ALL CLUTCHES SO FRONT SPACING FEED PAWL IS IN LOWER POSITION. PLACE PAWL ADJUSTING PLATE AT CENTER OF HORIZONTAL AND VERTICAL ADJUSTMENT: TO ADJUST VERTICALLY, LOOSEN BOTH MOUNTING SCREWS; TO ADJUST HORIZONTALLY, LOOSEN ONLY LEFT SCREW. HORIZONTAL ADJUSTMENT SHOULD BE MADE AFTER VERTICAL. DISENGAGE SPACING FEED PAWLS AND ALLOW DRUM TO ROTATE TO EXTREME COUNTERCLOCKWISE POSITION. KEEPING SPACING CLUTCH DISENGAGED, MANUALLY ADVANCE DRUM UNTIL FIRST STOP IS IMMEDIATELY TO LEFT OF PAWL. POSITION ADJUSTING PLATE HORIZONTALLY SO THAT STOP IS ALIGNED WITH LEFT EDGE OF PAWL SHOULDER.
- (4) PLACE BLOCKING LEVER AND OPERATING LEVER SLIDE ARM IN UNBLOCKED POSITION. DISENGAGE FEED PAWLS AND LET DRUM ROTATE TWO SPACES COUNTERCLOCKWISE. BOTH FEED PAWLS SHOULD BE FULLY ENGAGED. BLOCK SLIDE ARM WITH BLOCKING LEVER. GAGE AND NOTE CLEARANCE BETWEEN STOP AND SLOPE ON PAWL.
- (5) ROTATE DRUM CLOCKWISE UNTIL NEXT STOP IS JUST TO LEFT OF PAWL. REPEAT PROCEDURE DESCRIBED IN PARAGRAPH (4) FOR THIS STOP. REPEAT PROCEDURE FOR REMAINING STOPS, NOTING EACH CLEARANCE.
- (6) STOP WITH MAXIMUM CLEARANCE SHOULD BE USED AS REFERENCE IN MAKING FINAL HORIZONTAL AND VERTICAL PAWL ADJUSTMENTS.

FIGURE 2-21 TYPING UNIT, HORIZONTAL TABULATOR MECHANISM, FRONT VIEW

6. HORIZONTAL TABULATOR MECHANISM

TABULATOR PAWL - VERTICAL (FINAL)

TO CHECK


POSITION SPACING DRUM SUCH THAT REFERENCE TABULATOR STOP, AS DETERMINED BY PRELIMINARY TABULATOR PAWL ADJUSTMENT (FIG. 2-21), IS OPPOSITE SHOULDER ON PAWL. BLOCK OPERATING LEVER SLIDE ARM WITH BLOCKING LEVER.

REQUIREMENT

CLEARANCE BETWEEN PAWL AND STOP:  
MIN. 0.060 INCH MAX. 0.070 INCH

TO ADJUST

POSITION PAWL ADJUSTING PLATE WITH BOTH MOUNTING SCREWS LOOSENED. TIGHTEN RIGHT SCREW ONLY, USING WRENCH TO PREVENT BUSHING FROM TURNING.





TABULATOR PAWL SPRING  
REQUIREMENT  
MIN. 3 OZS. MAX. 5 OZS.  
TO START PAWL MOVING.

BLOCKING LEVER SPRING  
TO CHECK  
HOLD OPERATING LEVER SLIDE  
ARM TO THE REAR.  
REQUIREMENT  
MIN. 2 1/2 OZS. MAX. 4 1/2 OZS.  
TO START BLOCKING LEVER MOVING.

FIGURE 2-22 TYPING UNIT, HORIZONTAL TABULATOR MECHANISM, FRONT VIEW



## 6. HORIZONTAL TABULATOR MECHANISM



(BOTTOM VIEW)

TABULATOR PAWL - HORIZONTAL (FINAL)

## TO CHECK

(1) DISENGAGE ALL CLUTCHES SO THAT FRONT SPACING FEED PAWL IS IN LOWER POSITION (AS SHOWN IN FIG. 2-21). POSITION SPACING DRUM SO THAT REFERENCE TABULATOR STOP, AS DETERMINED IN PRELIMINARY TABULATOR PAWL ADJUSTMENT (FIG. 2-21), IS IMMEDIATELY TO LEFT OF PAWL. OPERATING LEVER SLIDE ARM SHOULD BE FORWARD IN UNBLOCKED POSITION. DISENGAGE FEED PAWLS AND ALLOW DRUM TO ROTATE ONE SPACE COUNTER-CLOCKWISE. BOTH FEED PAWLS SHOULD BE FULLY ENGAGED. MOVE SLIDE ARM TO REAR TO BLOCKED POSITION.

(2) TRIP SPACING CLUTCH STOP LEVER AND SLOWLY ROTATE MAIN SHAFT UNTIL BLOCKING LEVER IS JUST TRIPPED. TAKE UP PLAY IN SPACING SHAFT TOWARD REAR.

## REQUIREMENT

SOME PORTION OF CLUTCH DISK STOP LUG SHOULD BE ALIGNED WITH REAR SURFACE OF SPACING SHAFT GEAR.

## TO ADJUST

REPEAT PROCEDURE SET FORTH IN PARAGRAPH (1) ABOVE. TRIP SPACING CLUTCH AND ROTATE SHAFT UNTIL MIDDLE OF STOP LUG IS IN LINE WITH REAR SURFACE OF GEAR. IF BLOCKING LEVER TRIPPED TOO SOON, WITH LEFT MOUNTING SCREW LOOSENED, POSITION PAWL ADJUSTING PLATE TO LEFT UNTIL SLIDE ARM CAN BE BLOCKED. SLOWLY MOVE PLATE TO RIGHT UNTIL BLOCKING LEVER JUST TRIPS. WHEN ADJUSTING TRIP-OFF POINT, CARE SHOULD BE TAKEN THAT BLOCKING LEVER IS CAMMED DOWN BY STOP AND NOT MANUALLY MOVED OUT OF BLOCKED POSITION BY ACCIDENT. RECHECK REQUIREMENT.

## NOTE:


AFTER OBTAINING TRIP-OFF POINT, CONTINUE ROTATING MAIN SHAFT UNTIL SPACING CLUTCH IS DISENGAGED. PAWL SHOULD BE TO RIGHT OF STOP. WHEN SLIDE ARM IS MOVED TO REAR, BLOCKING LEVER SHOULD MOVE TO BLOCKED POSITION. IF TIP OF PAWL SHOULD REST ON END OF STOP, READJUST PLATE TO RIGHT SO THAT CLEARANCE BETWEEN PAWL AND STOP IS:

MIN. 0.003

MAX. 0.008

FIGURE 2-23 TYPING UNIT, HORIZONTAL TABULATOR MECHANISM, FRONT VIEW

## 6. HORIZONTAL TABULATOR MECHANISM

TABULATOR STOP SETTINGS

## NOTE:

FOR INSTRUCTIONS ON HOW TO MOVE TABULATOR STOPS, SEE TABULATOR PAWL PRELIMINARY ADJUSTMENT, FIGURE 2-21, PARAGRAPH 2

## (1) COLUMNAR TABULATOR STOPS

PLACE CARRIAGE IN POSITION TO PRINT FIRST CHARACTER IN COLUMN. PLACE STOP IN SLOT IMMEDIATELY TO LEFT OF PAWL. TO FACILITATE INSERTING STOPS, MARK DESIRED SLOT AND ROTATE DRUM TO MORE ACCESSIBLE POSITION. FOR SETTINGS NEAR LEFT MARGIN, COUNT NUMBER OF SPACING OPERATIONS FROM LEFT MARGIN AND PLACE STOP CORRESPONDING NUMBER OF SLOTS COUNTERCLOCKWISE FROM ROLLER.

NOTE: WHEN PRINTING FORMS, CHECK STOP SETTINGS IN RELATION TO COLUMNS. CORRESPONDING STOPS ON ALL MACHINES ON A CIRCUIT MUST BE THE SAME NUMBER OF SLOTS FROM LEFT MARGIN.

## (2) RIGHT MARGIN TABULATOR STOP (WITH WIDE SHELF)

NOTE: BEFORE MAKING THIS ADJUSTMENT, CHECK RIGHT MARGIN AND TABULATOR PAWL ADJUSTMENTS.

POSITION PRINTING CARRIAGE AT RIGHT MARGIN (SPACING CUTOUT OPERATED). INSERT STOP WITH WIDE SHELF IN SLOT IMMEDIATELY TO LEFT OF PAWL. SHELF SHOULD EXTEND TO RIGHT SO THAT PAWL RESTS ON IT.

FIGURE 2-24 TYPING UNIT, HORIZONTAL TABULATOR MECHANISM, FRONT VIEW

## 6. HORIZONTAL TABULATOR MECHANISM

## NOTE

THE FOLLOWING TWO HORIZONTAL TABULATOR MECHANISM ADJUSTMENTS SHOULD BE CHECKED BEFORE MAKING THE TRANSMITTER CONTROL

ADJUSTMENTS SHOWN BELOW.

1. OPERATING LEVER SLIDE ARM (FIGURE 2-17)
2. OPERATING LEVER ADJUSTING PLATE (FIGURE 2-17)

IF EITHER OF THE ABOVE ADJUSTMENTS ARE CHANGED, THE TRANSMITTER CONTROL ADJUSTMENTS SHOULD BE RECHECKED.

TRANSMITTER CONTROL CONTACT  
SPRING TENSION

REQUIREMENT

OPERATING LEVER IN UNOPERATED POSITION.



MIN. 3-1/2 OZS.

MAX. 4-1/2 OZS.

TO JUST OPEN CONTACTS.

TO ADJUST

BEND THE LONG CONTACT SPRING



REQUIREMENT

OPERATING LEVER SLIDE ARM PULLED TO REAR UNTIL BLOCKED BY BLOCKING LEVER. CLEARANCE BETWEEN CONTACTS

MIN. 0.010 INCH

MAX. 0.020 INCH

TO ADJUST

POSITION THE CONTACT ASSEMBLY BRACKET WITH THE MOUNTING SCREW LOOSENED. THE BRACKET PIVOTS ABOUT A PIN AT THE UPPER END OF THE BRACKET.

FIGURE 2-25 TYPING UNIT, HORIZONTAL TABULATOR MECHANISM

## 7. PAGE FEED OUT MECHANISM




FIGURE 2-26 TYPING UNIT, PAGE FEED-OUT MECHANISM


## 7. PAGE FEED-OUT MECHANISM

**(F) POINTER****REQUIREMENT**

LINE FEED CLUTCH DISENGAGED,  
INDEX PLATE ADJACENT TO BAIL  
AS SHOWN IN FIGURE 2-26. POINTER  
SHOULD LINE UP WITH NOTCH IN INDEXING  
DISK AND CLEAR DISK BY APPROXIMATELY  
1/16 INCH.

**TO ADJUST**

POSITION POINTER WITH MOUNTING  
SCREW LOOSENED.

**(C) BLOCKING ARM****REQUIREMENT**

BAIL ON PEAK OF INDEX  
PLATE. CLEARANCE  
MIN. 0.010 INCH  
MAX. 0.025 INCH

**TO ADJUST**

POSITION ADJUSTABLE ARM  
WITH MOUNTING SCREWS  
LOOSENED.

**NOTE**

IF REQUIREMENT CANNOT  
BE MET FOR EACH PLATE,  
REPOSITION PLATE WITH  
MOUNTING SCREW LOOSENED.

**(H) BLOCKING ARM SPRING TENSION****REQUIREMENT**


BLOCKING ARM IN UNBLOCKED  
POSITION.  
MIN. 3 OZS.  
MAX. 5 OZS  
TO PULL SPRING TO OPERATING  
LENGTH.

FIGURE 2-27 TYPING UNIT, PAGE FEED-OUT MECHANISM

*Suppressor bar should be spring to front*

8. SELECTIVE CALLING MECHANISM

**TYPE BOX CLUTCH TRIPLEVER**  
(SELECTIVE-CALLING UNITS WITH OR WITHOUT  
OFF-LINE SHIFT SOLENOID)  
CLEARANCE BETWEEN TYPE BOX CLUTCH TRIP  
LEVER AND CLUTCH DISK STOP LUG SHOULD BE  
MIN. 0.030 INCH      MAX. 0.065 INCH  
SEE FIG. 1-33



**SUPPRESSOR CODE BAR SPRING**  
REQUIREMENT  
SUPPRESSOR CODE BAR TO LEFT.  
MIN. 4 1/2 OZS.      MAX. 7 1/2 OZS.  
TO START CODE BAR MOVING.  
CODE BAR SHOULD BE FREE OF BINDS.

NOTE: TO CHECK REQUIREMENTS (A,B, AND D), SET  
FUNCTION CLUTCH IN STOP POSITION AND ALL CODE  
BARS TO THE RIGHT.

**A. CODE BAR SHIFT MECHANISM**

REQUIREMENTS

1. WITH FUNCTION CLUTCH IN STOP POSITION, LATCH FUNCTION LEVER (SHIFT MECH.) ON ITS LOWER RELEASING LATCH. NOTCH IN SUPP. CODE BAR SHOULD ALIGN WITH NOTCHES IN OTHER CODE BARS WHEN ALL CODE BARS ARE SHIFTED TO THE RIGHT.

TO ADJUST

POSITION UPPER OR LOWER GUIDE PLATE (FIG. 1-43) WITH ITS CLAMP NUTS LOOSE

2. REPEAT FOR EACH STUNT CASE CODE BAR SHIFT MECHANISM.

NOTE - - - POSITION THE ASSOCIATED GUIDE PLATE SO THAT THE MOVEMENT OF THE FORK IS NOT RESTRICTED WITHIN THE RANGE OF ADJUSTMENT


**D. OFF LINE SHIFT BRACKET ASSEMBLY ( OFF LINE ONLY)**

REQUIREMENT

NOTCH IN SUPPRESSION CODE BAR SHOULD ALIGN WITH NOTCHES IN OTHER CODE BARS WHEN ALL CODE BARS ARE SHIFTED TO THE RIGHT.

TO ADJUST

POSITION THE SOLENOID BRACKET ASSEMBLY WITH ITS MOUNTING SCREWS LOOSE.



**B. CONDITION CODE ( ZERO ) CODE BAR SHIFT MECHANISM**

REQUIREMENT

WITH FUNCTION CLUTCH IN STOP POSITION, LATCH FUNCTION LEVER (SHIFT MECH). THE NOTCH IN CONDITION CODE (ZERO) CODE BAR SHOULD ALIGN WITH NOTCHES IN OTHER CODE BARS WHEN ALL CODE BARS ARE SHIFTED TO THE RIGHT.

TO ADJUST

POSITION THE UPPER OR LOWER GUIDE PLATE (FIG. 1-43) WITH ITS CLAMP NUTS LOOSE

NOTE - - - POSITION THE ASSOCIATED GUIDE PLATE SO THAT THE MOVEMENT OF THE FORK IS NOT RESTRICTED WITHIN THE RANGE OF ADJUSTMENT.

FIGURE 2-28 TYPING UNIT, CODE BAR SHIFT MECHANISM

*can cause function and type 204/mot to keep going*  
*Clutch*  
 217B

8. SELECTIVE CALLING MECHANISM

C. TYPE BAR CLUTCH SUPPRESSION ARM (WITH OR WITHOUT SOLENOID SHIFT)

REQUIREMENT

SUPPRESSION ARM IN <sup>blocking</sup> BLOCKING POSITION. SHAFT ROTATED UNTIL THE FUNCTION CLUTCH SHOE LEVER IS OPPOSITE THE FUNCTION CLUTCH TRIP LEVER.

1. AT LEAST 0.003 INCH CLEARANCE BETWEEN TRIP ARM EXTENSION AND CLUTCH TRIP LEVER.
2. AT LEAST 0.006 INCH CLEARANCE BETWEEN THE FUNCTION CLUTCH SHOE LEVER AND FUNCTION CLUTCH TRIP LEVER. *ON TYPE BAR CLUTCH*

TO ADJUST


POSITION SUPPRESSION ARM WITH ITS MOUNTING SCREWS LOOSENED.

SOLENOID BRACKET MOUNTING SCREWS

OFF LINE STUNT SHIFT SOLENOID SPRING

REQUIREMENT

WITH SOLENOID UNOPERATED  
 MIN. 2 OZS. MAX. 4 1/2 OZS.  
 TO PULL SPRING TO ITS INSTALLED LENGTH.



*ensure that suppression arm will not be mark*

BLOCKING BAIL REQUIREMENT

1. LATCH FUNCTION LEVER OF ANY STUNT CASE CODE BAR SHIFT MECHANISM AND ROTATE MAIN SHAFT UNTIL LOWER SURFACE OF THE SUPPRESSION ARM IS ALIGNED (APPROX) WITH BOTTOM SURFACE OF BLOCKING BAIL EXTENSION. CLEARANCE BETWEEN SUPPRESSION ARM AND BLOCKING BAIL EXTENSION, WITH PLAY TAKEN UP TO PRODUCE MINIMUM CLEARANCE.  
 MIN. 0.008 INCH \_\_\_\_\_ MAX. 0.035 INCH


TO ADJUST

POSITION EXTENSION WITH ITS MOUNTING SCREW LOOSENED. REFINE THE ADJUSTMENT IF NECESSARY, AND RECHECK EACH SHIFT MECHANISM.


2. REFINE THE STUNT CASE CODE BAR SHIFT MECHANISM ADJUSTMENT OF ANY SHIFT MECHANISM THAT DOES NOT MEET THE ABOVE REQUIREMENT.

FIGURE 2-29 TYPING UNIT, OFF LINE STUNT SHIFT SOLENOID MECHANISM

8. SELECTIVE CALLING MECHANISM



CONDITION CODE SHIFT FORK SPRING REQUIREMENT  
 WITH CONDITION CODE SHIFT IN ITS UNOPERATED POSITION.  
 MIN. 1 OZ.  
 MAX. 3 OZS.  
 TO PULL SPRING TO ITS INSTALLED POSITION.



AUTOMATIC CARRIAGE RETURN - LINE FEED BLOCKING SLIDE SPRING REQUIREMENT  
 WITH CONDITION CODE SHIFT FORK IN ITS UNOPERATED POSITION.  
 MIN. 1 OZ.  
 MAX. 3 OZS.  
 TO PULL SPRING TO ITS INSTALLED LENGTH.

FIGURE 2-30 TYPING UNIT, STUNT BOX MECHANISM



9. LOCAL BACK SPACE MECHANISM

NOTE: FOR EARLIER DESIGN SEE FIGURE 4-46





FIGURE 2-31 KEYBOARD, BACK SPACE MECHANISM

## 9. LOCAL BACK SPACE MECHANISM



NOTE: FOR EARLIER DESIGN SEE FIGURE 4-47

FIGURE 2-32 KEYBOARD, BACK SPACE MECHANISM

9. LOCAL BACK SPACE MECHANISM




FIGURE 2-33 TYPING UNIT, BACKSPACE MECHANISM

10. REVERSE LINE FEED MECHANISM





FIGURE 2-34 LOCAL REVERSE LINE FEED MECHANISM, LEFT VIEW

## 10. REVERSE LINE FEED MECHANISM

LINE FEED CLUTCH SPUR GEAR  
REQUIREMENT

LINE FEED CLUTCH DISENGAGED. SLIDE LINK RAISED UPWARD SO AS TO FULLY ENGAGE THE END OF THE LOWER LINE FEED BAR, SLIDE HELD FORWARD BY ITS SPRING CLEARANCE BETWEEN SLIDE LINK AND LOWER LINE FEED BAR.

MIN. 0.005 INCH

MAX. 0.040 INCH

## TO ADJUST

SET LINE FEED CLUTCH SPUR GEAR AT CENTER OF ADJUSTING RANGE  
DISENGAGE LINE FEED CLUTCH,  
LOOSEN ECCENTRIC ASSEMBLY BEARING POST. MESH THE TWO GEARS SO THAT THE FORWARD EDGES OF THE LOWER ENDS OF THE LINE FEED BARS ARE IN LINE WITH EACH OTHER WITHIN 0.040 INCH. ROTATE THE LINE FEED CLUTCH SPUR GEAR RELATIVE TO ITS MOUNTING PLATE WITH THE GEAR MOUNTING SCREWS LOOSENED. CHECK BOTH BARS FOR THE REQUIRED CLEARANCE AT EACH STOP POSITION OF THE CLUTCH




FIGURE 2-35 TYPING UNIT, LINE FEED MECHANISM, LEFT SIDE VIEW

## 10. REVERSE LINE FEED MECHANISM




FIGURE 2-36 TYPING UNIT, LINE FEED MECHANISM, RIGHT SIDE VIEW

10. REVERSE LINE FEED MECHANISM




FIGURE 2-37 TYPING UNIT, LINE FEED MECHANISM, RIGHT SIDE VIEW

## 11. MOTOR CONTROL RELAY MECHANISM


(D)

SWITCH POSITION (IF UNIT IS SO EQUIPPED)  
REQUIREMENT

WHEN THE SOLENOID PLUNGER IS DEPRESSED SLOWLY, THE SWITCH SHOULD OPERATE WHEN THE PLUNGER IS WITHIN MAX. 0.005 INCH FROM THE END OF ITS TRAVEL

TO ADJUST

LOOSEN THE SWITCH MOUNTING SCREWS. HOLD THE PLUNGER DOWNWARD AND MOVE THE SWITCH TOWARD THE PLUNGER UNTIL IT OPERATES. TIGHTEN THE SCREWS.



(A)


MIDDLE CONTACT SPRING TENSION

REQUIREMENT

WITH SOLENOID PLUNGER UNOPERATED  
MIN. 2 OZS.  
MAX. 3 OZS.  
TO BREAK CONTACT WITH INNER CONTACT

TO ADJUST

BEND MIDDLE CONTACT SPRING



(B)

OUTER CONTACT SPRING TENSION

REQUIREMENT

HOLD SOLENOID PLUNGER OPERATED  
MIN. 12 OZS.  
MAX. 16 OZS.  
TO BREAK CONTACT WITH THE MIDDLE CONTACT SPRING.

TO ADJUST

BEND OUTER CONTACT SPRING.

(C) INNER CONTACT SPRING GAP

REQUIREMENT

HOLD SOLENOID PLUNGER OPERATED  
CLEARANCE BETWEEN INNER AND MIDDLE CONTACT SPRING CONTACT SURFACE  
MIN. 0.025 INCH  
MAX. 0.030 INCH

TO ADJUST

BEND THE INNER CONTACT SPRING.

FIGURE 2-38 ELECTRICAL SERVICE UNIT, MOTOR CONTROL RELAY



## 12. END-OF-FORM ALARM MECHANISM (CABINET)

END-OF-FORM LEVER

## REQUIREMENT

THE END-OF-FORM LEVER SHOULD MOVE FREELY BETWEEN THE TYPING UNIT AND THE PAPER GUIDE ON THE CABINET. CHECK WITH THE DOME CLOSED AND THE SMALL DOOR OPEN.

## TO ADJUST

POSITION THE END-OF-FORM LEVER WITH ITS CLAMP SCREWS LOOSENED.






FIGURE 2-39 CABINET, END-OF-FORM ALARM MECHANISM

## 13. OFF-SET COPYHOLDER



## 14. DIRECTORY HOLDER (TWX)



15. PRINT SUPPRESSION DURING SELECTION







FIGURE 2-42 TYPING UNIT, PRINT SUPPRESSION MECHANISM

## 16. CONTINUOUS SPACING

FUNCTION CLUTCH TRIP LEVER

## REQUIREMENT

WITH THE SOLENOID DE-ENERGIZED AND THE FUNCTION CLUTCH DISENGAGED, THE FUNCTION CLUTCH TRIP LEVER SHOULD ENGAGE THE CLUTCH SHOE LEVER BY THE FULL THICKNESS OF THE SHOE LEVER (CHECK AT LUG WITH LEAST BITE ON TWO STOP CLUTCHES).

## TO ADJUST

POSITION THE SOLENOID MOUNTING PLATE WITH ITS MOUNTING SCREWS LOOSENED. IN POSITIONING THE PLATE MOVE EACH END EQUALLY TO AVOID BINDS IN THE SOLENOID PLUNGER AND FUNCTION CLUTCH TRIP LEVER.

FIGURE 2-43 TYPING UNIT, CONTINUOUS SPACING AND TRIPLE LINE FEED MECHANISM

16. CONTINUOUS SPACING




FIGURE 2-44 TYPING UNIT, CONTINUOUS SPACING AND TRIPLE LINE FEED MECHANISM

17. LINE TEST KEY




FIGURE 2-45. LINE TEST KEY

18. PAPER-OUT ALARM




FIGURE 2-46. TYPING UNIT, PAPER-OUT ALARM MECHANISM

## 19. OFF-LINE CONTACT





FIGURE 2-47. KEYBOARD, OFF-LINE CONTACTS AND EXTERNAL TAPE BACKSPACE MECHANISM

## 19. OFF-LINE CONTACT



OPERATIONAL CHECK: WITH A TYPING UNIT ON THE BASE, AND AC POWER APPLIED (SELECTOR MAGNETS ENERGIZED), DEPRESS LOCAL BACKSPACE KEYLEVER. CUT OFF AC POWER. RELEASE THE LOCAL BACKSPACE KEYLEVER SO THAT THE BACKSPACE LINK CLEARS THE SOLENOID OPERATED BAIL EXTENSION AND LATCHES UP UNDER IT BY AT LEAST 0.010 INCH CLEARANCE. WITH AC POWER APPLIED THE BACKSPACE SOLENOID SHOULD BECOME ENERGIZED. IF NECESSARY, REFINE THE SOLENOID OPERATED SWITCH PLATE POSITION.

FIGURE 2-48. KEYBOARD, EXTERNAL TAPE BACKSPACE AND OFF-LINE CONTACT MECHANISM



## SECTION 3 - LUBRICATION

## 1. GENERAL

1.01 The printer set should be lubricated as directed in this section. The figures indicate points to be lubricated and the kind and quantity of lubricant to be used. Lubricate the printer just prior to placing it in service. After a few weeks in service, re-lubricate to make certain that all points receive lubrication. The following lubrication schedule should be followed thereafter.

<u>OPERATING SPEED</u> (Words per Minute)	<u>LUBRICATING INTERVAL</u> (Whichever occurs first)
60 - - - - -	3000 hrs. or 1 yr.
75 - - - - -	2400 hrs. or 9 mo.
100 - - - - -	1500 hrs. or 6 mo.

1.02 Use Teletype KS-7470 oil at all locations where the use of oil is indicated. Use KS-7471 grease on all surfaces where grease is indicated except the motor bearings. Apply two drops of KS-7470 oil to motor bearings every four months (depress oiler with metal object). If the motor is disassembled at any time, repack the bearings with KS-7471 grease.

1.03 All spring wicks and felt oilers should be saturated. The friction surfaces of all moving parts should be thoroughly lubricated. Overlubrication should be avoided. Special care must be taken to prevent any oil or grease from getting between the selector armature and its magnet pole faces or between

electrical contacts.

1.04 Apply a thick film of grease to all gears and the spacing clutch reset cam plate.

1.05 Apply oil to all cams, including the camming surfaces of each clutch disk.

1.06 The photographs show the paragraph numbers referring to particular line drawings of mechanisms and where these mechanisms are located on the unit. Parts in the line drawings are shown in an upright position unless otherwise specified.


1.07 The illustration symbols indicate the following lubrication directions:

- 0 Apply 1 drop of oil.
- 02 Apply 2 drops of oil.
- 03 Apply 3 drops of oil.
- 020 Apply 20 drops of oil, etc.
- G Apply thin film of grease.
- SAT Saturate (Felt oilers, washer, wicks) with oil.

NOTE: During each lubrication period, check the following adjustments:

1. PRINTING CARRIAGE POSITION
2. PRINTING HAMMER BEARING STUD
3. PRINTING HAMMER STOP BRACKET  
(Also see note after "Printing Arm" adjustment)
4. CARRIAGE WIRE ROPE


2. DISASSEMBLY  
2.01 CABINET DISASSEMBLY




PERFORM OPERATIONS IN NUMERICAL SEQUENCE

- 1 DISCONNECT THE PLUG ON THE CABLE FROM THE RECEPTACLE ON THE RIGHT SIDE OF THE TYPING UNIT
- 2 DISCONNECT THE PLUG ON THE CABLE FROM THE RECEPTACLE ON THE LEFT SIDE OF THE KEYBOARD.
- 3 REMOVE THE CROSS BAR FROM THE FRONT OF THE CABINET BY LOOSENING THE TWO KNURLED THUMB SCREWS.

2.02 BASE DISASSEMBLY




2.03 KEYLEVER COVER DISASSEMBLY




- 4 REMOVE THE FOUR SCREWS HOLDING THE KEYBOARD TO THE CRADLE ASSEMBLY AND REMOVE THE KEYBOARD WITH TYPING UNIT ATTACHED.
- 5 REMOVE THE FOUR SCREWS HOLDING THE TYPING UNIT TO THE KEYBOARD AND REMOVE TYPING UNIT.
- 6 REMOVE THE SCREW HOLDING THE PLASTIC WINDOW (RIGHT AND LEFT) TO THE KEYLEVER GUIDE PLATE. REMOVE THE TWO SCREWS HOLDING THE KEYLEVER COVER (RIGHT AND LEFT) AND REMOVE KEYLEVER COVER.

3. CABINET




3.01 ELECTRICAL SERVICE UNIT




4. KEYBOARD (EARLIER DESIGN)

4.01 REST KEYBOARD BOTTOM SIDE UP.




(BOTTOM VIEW)


4.02 CODE LEVER MECHANISM




4.03 LOCAL CARRIAGE RETURN MECHANISM




4.04 LOCAL LINE FEED MECHANISM




4.05 KEYBOARD LOCK MECHANISM




4.06 REST KEYBOARD IN UPRIGHT POSITION



4.07 MARGIN INDICATING MECHANISM




4.08 CONTACT BOX



DISASSEMBLY: REMOVE NUT AND LOCK WASHER SECURING CONTACT BOX COVER AND REMOVE COVER.

G ENGAGING SURFACE CONTACT TOGGLE


4.09 CODE BAR MECHANISM



SAT FELT WICK  
 0 HOOKS—EACH END  
 02 GUIDING SURFACE  
 G ENGAGING SURFACE  
 02 GUIDING SURFACES (2 PLACES)  
 02 BEARING

SPRING WICK  
 SPRING  
 CODE LEVER BAIL LATCH LEVER  
 CODE LEVER BAIL  
 NON-REPEAT BELL CRANKS  
 CODE LEVER BAIL LATCH LEVER


4.10



02 BEARING SURFACES (2 PLACES)  
 0 HOOKS—EACH END

NON-REPEAT BELL CRANKS  
 SPRING


4.11




0 HOOKS—EACH END  
 02 BEARING SURFACES (RIGHT AND LEFT)

SPRING  
 CODE LEVER BAIL


4.12 CODE BAR MECHANISM (Continued)




4.13



4.14 KEYBOARD SELECTOR MECHANISM




4.15 SIGNAL GENERATOR MECHANISM  
REST KEYBOARD IN UPRIGHT POSITION




(FRONT VIEW)

4.16



(REAR VIEW)

4.17




- 02 OILER—EACH END (RIGHT AND LEFT)
- G TEETH (2 GEARS)
- 02 BALL BEARING


- MOTOR SHAFT
- INTERMEDIATE GEARS
- INTERMEDIATE GEAR SHAFT




4.18 SIGNAL GENERATOR MECHANISM (Continued)




4.19




4.20 SIGNAL GENERATOR MECHANISM (Continued)




4.21




4.22 TIME DELAY MECHANISM




5. TYPING UNIT  
5.01 REST TYPING UNIT IN UPRIGHT POSITION




5.02 PRINTING MECHANISM



5.03 PRINTING MECHANISM (Continued)




5.04 TYPE BOX CARRIAGE MECHANISM




5.05 CODE BAR MECHANISM  
ALSO LOCATION OF PAPER FEED MECHANISM (5.09)

REST TYPING UNIT IN UPRIGHT POSITION




(FRONT VIEW)

5.06




5.07 CODE BAR MECHANISM (Continued)

REST TYPING UNIT IN UPRIGHT POSITION



5.08




02 BEARING BALLS  
(9 BALLS)


CODE BAR DETENT

(LEFT SIDE VIEW)

5.09 PAPER FEED MECHANISM (FRONT VIEW)




(LEFT SIDE)



(RIGHT SIDE)

- |    |   |   |
|----|---|---|
| 0  | HOOKS—EACH END                            | SPRING  |
| 02 | BEARING SURFACE                           | PLATEN DETENT BAIL                                    |
| 02 | BEARING SURFACES<br>(EACH END)            | PAPER FINGER SHAFT                                    |
| 6  | TEETH (2 GEAR)                            | PLATEN GEARS  |
| 02 | BEARINGS<br>(EACH END)                    | PLATEN SHAFT  |
| 0  | BEARING SURFACES—<br>EACH END (6 ROLLERS) | PAPER PRESSURE ROLLER SHAFTS<br>(WIPE OFF EXCESS OIL) |
| 02 | BEARING SURFACES<br>(EACH END)            | PAPER STRAIGHTENER SHAFT                              |
| 02 | BEARING SURFACES<br>(RIGHT AND LEFT)      | PAPER STRAIGHTENER LEVERS                             |
| 0  | HOOKS—EACH END                            | SPRING  |
| 02 | BEARING SURFACE                           | RELEASE LEVER   |
| 02 | BEARING SURFACES<br>(EACH END)            | RELEASE LEVER LINK                                    |

5.10 REST TYPING UNIT IN UPRIGHT POSITION




(LEFT SIDE VIEW)

5.15

5.16

5.17

5.11




5.12

5.13

5.14

5.12 RIBBON FEED MECHANISM (RIGHT SIDE)



(RIGHT SIDE VIEW)

02 BEARING SURFACE

02 BEARING SURFACE

SAT FELT WASHER

0 HOOKS—EACH END

02 ENGAGING SURFACE

0 HOOKS—EACH END

G TEETH

(RIGHT SIDE VIEW)

RIBBON ROLLER SHAFT

RIBBON SPOOL TOGGLE


RIBBON SPOOL SHAFT

RIBBON FEED LEVER SPRING

RIBBON DETENT LEVER

RIBBON RATCHET WHEEL SPRING

RIBBON RATCHET WHEEL



(REAR VIEW)

SAT FELT WASHERS  
(2 WASHERS)

02 BEARING SURFACE

0 HOOKS—EACH END

02 BEARING SURFACES  
(2 PLACES)

02 BEARING SURFACE  
(2 PLACES)


RIBBON FEED LEVER BAIL

RIBBON LEVER  
SPRING


RATCHET FEED LEVER SHAFT

RIBBON DETENT LEVER SHAFT

5.13 RIBBON FEED MECHANISM (Continued)





5.14 VERTICAL POSITIONING MECHANISM (RIGHT SIDE)







5.15 RIBBON FEED MECHANISM (LEFT SIDE)




5.16 RIBBON FEED MECHANISM (Continued)



5.17 VERTICAL POSITIONING MECHANISM (LEFT SIDE)




5.18 REST TYPING UNIT IN UPRIGHT POSITION




(RIGHT SIDE VIEW)


5.19 CODE BAR MECHANISM




5.20 SELECTOR MECHANISM



5.21 SELECTOR MECHANISM (Continued)




5.22 REST TYPING UNIT IN UPRIGHT POSITION




(REAR VIEW)

5.23




(REAR VIEW)


5.24 STUNT BOX MECHANISM




5.25




5.26 RIBBON REVERSE MECHANISM




5.27 SHIFT MECHANISM




5.28 FUNCTION ROCKER SHAFT MECHANISM



5.29 REST TYPING UNIT ON ITS BACK




5.30 SPACING DRUM DRIVE MECHANISM (EARLIER DESIGN)




(SEE PARAGRAPH 6-08)


5.31 CARRIAGE RETURN MECHANISM



5.32




5.33






5.34 REST TYPING UNIT ON ITS BACK




(FRONT VIEW)

5.35 HORIZONTAL POSITIONING MECHANISM (FRONT VIEW)




(RIGHT SIDE)




(LEFT SIDE)


5.36 HORIZONTAL POSITIONING MECHANISM (Continued)



- 0 HOOKS—EACH END SPRING
- SAT FELT WASHER CODE BAR BELL CRANK
- 02 ENGAGING SURFACES (3 SLIDES) HORIZONTAL MOTION STOP SLIDES



5.37




- 02 ENGAGING SURFACES DECELERATING SLIDE (SEE NOTE 1)
- 0 HOOKS—EACH END (2 SPRINGS) SPRING
- 02 BEARING SURFACES (2 BELL CRANKS) DECELERATING SLIDE BELL CRANKS
- 02 ENGAGING SURFACES (2 SLIDES) DECELERATING SLIDES (SEE NOTE 2)
- SAT FELT WASHERS (3 WASHERS) SHIFT SLIDE DRIVE LINKS
- 0 BEARING SURFACES (8 PLACES) SHIFT SLIDE DRIVE LINKS

NOTES


1. WITH SPRINGS LOCATED ON REAR SIDE OF SLIDE
2. WITH SPRINGS LOCATED ABOVE THE SLIDE

5.38 HORIZONTAL POSITIONING MECHANISM (Continued)




- 02 GUIDING SURFACE HORIZONTAL POSITIONING LOCK LEVER
- 02 BEARING SURFACE HORIZONTAL LOCK LEVER ARM
- SAT FELT WICK ROLLER
- 0 HOOKS—EACH END SPRING WICK
- SAT FELT WASHER SPRING
- HORIZONTAL POSITIONING LOCK LEVER

5.39 REST TYPING UNIT IN UPRIGHT POSITION




(FRONT VIEW)


5.40 LETTERS-FIGURES SHIFT MECHANISM



5.41 LETT S FIGURES SHIFT MECHANISM (Continued)




(RIGHT SIDE)




(LEFT SIDE)


5.42 OSCILLATING MECHANISM




5.43 OSCILLATING MECHANISM (Continued)




5.44 REST TYPING UNIT IN BOTTOM UPWARD POSITION




5.45 MAIN SHAFT (CLUTCHES, GEARS, ETC.)




5.46




5.47 SELECTOR CAM+CLUTCH ASSEMBLY



5.48 MAIN SHAFT (CLUTCHES, GEARS, ETC.)—Continued




5.49 REST TYPING UNIT IN BOTTOM UPWARD POSITION




(BOTTOM VIEW)


5.50 SPACING MECHANISM



5.51




5.52 SPACING MECHANISM (Continued)






5.53 REST TYPING UNIT IN BOTTOM UPWARD POSITION




(REAR VIEW)

5.54 LINE FEED MECHANISM




6. VARIABLE FEATURES

6.01 REST KEYBOARD IN UPRIGHT POSITION.




( REAR VIEW)

6.02 REPEAT ON SPACE MECHANISM




( REAR VIEW)

6.03 SIGNAL LINE BREAK MECHANISM ( ELECTRICAL)




( REAR VIEW)


6.04 REST TYPING UNIT IN UPRIGHT POSITION.




6.05 SPROCKET FEED-LINE FEED MECHANISM




6.06 SPROCKET FEED-PAPER GUIDE MECHANISM




6.07 REST TYPING UNIT IN UPRIGHT POSITION.




6.08 UNIVERSAL DRUM MECHANISM (NEW DESIGN)




6.09 HORIZONTAL TABULATOR - TABULATOR SHAFT MECHANISM (EARLIER DESIGN)



6.10 HORIZONTAL TABULATOR - SPACE SUPPRESSION MECHANISM




6.11 REST TYPING UNIT BOTTOM SIDE UP.




( BOTTOM VIEW )

6.12 HORIZONTAL TABULATOR – OPERATING LEVER MECHANISM (EARLIER DESIGN)




( LEFT SIDE VIEW )

6.13 HORIZONTAL TABULATOR – SPACING CLUTCH MECHANISM (EARLIER DESIGN)




6.14 REST TYPING UNIT IN UPRIGHT POSITION




( REAR VIEW)

6.15 SELECTIVE CALLING - STRIPPER BAIL MECHANISM



( LEFT SIDE VIEW )


6.16 SELECTIVE CALLING - SHIFT AND STRIPPER BAIL MECHANISMS




( REAR VIEW )




6.17 REST TYPING UNIT IN UPRIGHT POSITION.  
REMOVE STUNT BOX (SEE PAGE 1-90).



6.18 SELECTIVE CALLING - SINGLE -  
DOUBLE LINE FEED MECHANISM




6.19 SELECTIVE CALLING – FUNCTION RESET BAIL MECHANISM




( LEFT SIDE VIEW )

6.20 REST TYPING UNIT IN UPRIGHT POSITION.




( LEFT SIDE VIEW )

6.21 SELECTIVE CALLING - CLUTCH SUPPRESSION MECHANISM




( LEFT SIDE VIEW )

6.22 REST KEYBOARD IN UPRIGHT POSITION




( TOP VIEW ) 6.23


6.23 LOCAL BACK SPACE MECHANISM




6.24 LOCAL REVERSE LINE FEED MECHANISM




6.25 REST TYPING UNIT IN UPRIGHT POSITION




6.26 LOCAL BACK SPACE MECHANISM




6.27 REST TYPING UNIT BOTTOM SIDE UP




6.28 LOCAL REVERSE LINE FEED MECHANISM



6.29 LOCAL BACK SPACE MECHANISM



6.30 REST TYPING UNIT IN UPRIGHT POSITION  
 6.31 PAPER SPINDLE LATCH MECHANISM



6.32


6.31

O LATCH (2 PLACES)

PAPER SPINDLE LATCH


( REAR VIEW)

6.32 LOCAL REVERSE LINE FEED MECHANISM



( RIGHT SIDE VIEW)


6.33 REST TYPING UNIT IN UPRIGHT POSITION.



6.33

( LEFT SIDE VIEW)


6.34 PAGE FEED-OUT MECHANISM





(LEFT SIDE)




6.35 SIGNAL LINE BREAK MECHANISM (BASE)




6.36 REST BASE IN UPRIGHT POSITION




6.37 PAPER FEED OUT MECHANISM (KEYBOARD)




6.38 CABINET DOME OPEN




6.39 END-OF-FORM ALARM MECHANISM (CABINET)




6.40 PAPER-OUT ALARM MECHANISM





6.41 CONTINUOUS SPACING MECHANISM



6.42




6.43




6.44 REST TYPING UNIT IN UPRIGHT POSITION


6.45 REST TYPING UNIT IN UPRIGHT POSITION




6.46 REST TYPING UNIT BOTTOM SIDE UP




6.47 HORIZONTAL TABULATOR - BLOCKING LEVER



6.48 HORIZONTAL TABULATOR - SLIDE ARM




6.49 HORIZONTAL TABULATOR - OPERATING LEVER




- 02 ENGAGING SURFACE WITH BLOCKING LEVER AND BRACKET OPERATING LEVER SLIDE ARM
- 0 HOOKS - EACH END SLIDE ARM SPRING
- 02 BEARING SURFACE OPERATING LEVER SLIDE ARM
- 02 CONTACTING SURFACE WITH ADJUSTING PLATE OPERATING LEVER
- 02 BEARING SURFACE TRIP LEVER ARM LATCH BAIL
- 02 BEARING SURFACE OPERATING LEVER

6.50 HORIZONTAL TABULATOR - LATCH BAIL




0 HOOKS - EACH END LATCH BAIL SPRING

6.51 HORIZONTAL TABULATOR - OPERATING LEVER




02 GUIDE SURFACES OPERATING LEVER  
 02 CONTACT WITH SLIDE ARM OPERATING LEVER  
 0 HOOKS - EACH END SLIDE ARM SPRING  
 02 BEARING SURFACE OPERATING LEVER  
 SAT FELT WICK SPRING  
 02 SLOT CAMMING SURFACE OPERATING LEVER  
 02 BRACKET CONTACT SURFACE OPERATING LEVER  
 SAT FELT WASHERS STRIPPER BAIL SHAFT  
 G CAMMING SURFACE SPACING CLUTCH RESTORING CAM

6.52 HORIZONTAL TABULATOR - INTERMEDIATE BAIL




0 CONTACT SURFACE TRIP LEVER ARM INTERMEDIATE BAIL  
 02 CONTACTING SURFACE SPACING TRIP LEVER ARM  
 0 CONTACT SURFACE SPACING TRIP LEVER INTERMEDIATE BAIL

6.53




SAT FELT WASHER TRIP LEVER ARM SHAFT  
 02 BEARING SURFACE SPACING CUTOUT TRANSFER BAIL  
 02 BAIL CONTACTING SURFACE SPACING CUTOUT TRANSFER BAIL  
 SAT FELT WASHER TRANSFER BAIL STUD

6.54




0 HOOKS - EACH END SPACE SUPPRESSION BY PASS SPRING.  
 02 BEARING SURFACE BAIL EXTENSION ARM  
 02 CONTACT SURFACE WITH SPACING CUT-OUT LEVER BAIL EXTENSION ARM

6.55 OFF-LINE CONTACTS




6.56 KEYBOARD - TOP VIEW




7. NEW DESIGN KEYBOARD

7.01 REST KEYBOARD BOTTOM SIDE UP




BOTTOM VIEW

7.02 SPACE BAR MECHANISM




7.03 KEYLEVER MECHANISM






7.04 BREAK LEVER MECHANISM




- 0 ENGAGING SURFACE BREAK KEYLEVER
- 0 BEARING SURFACE FUNCTION LEVER
- G CONTACT SURFACE BREAK LEVER

7.05 CODE LEVER MECHANISM




- G CONTACTING SURFACE (32 LEVERS) CODE LEVER UNIVERSAL BAIL
- 0 GUIDE SLOTS (32 LEVERS) CODE LEVERS
- SAT FELT WASHERS (6 WASHERS) CODE LEVER SHAFT
- 0 BEARING SURFACE (32 WEDGES) LOCK BALL TRACK
- 0 HOOKS-EACH END (40 SPRINGS) SPRING

7.06 KEYBOARD LOCK MECHANISM




- 0 GUIDE SLOT KEYBOARD LOCK PLUNGER
- 0 HOOKS-EACH END SPRING
- 0 BEARING SURFACE KEYBOARD LOCK LEVER
- G ENGAGING SURFACE KEYBOARD LOCK FUNCTION LEVER
- 0 BEARING SURFACE FUNCTION BAIL

7.07 REST KEYBOARD IN UPRIGHT POSITION




TOP VIEW


7.08 CODE BAR MECHANISM



7.09 LOCAL CARRIAGE RETURN MECHANISM




7.10 SIGNAL GENERATOR MECHANISM REST KEYBOARD IN UPRIGHT POSITION




REAR VIEW


7.11 NON-REPEAT LEVER MECHANISM



7.12 TRANSFER LEVER MECHANISM




7.13 CONTACT BOX




- G ENGAGING SUR- CONTACT TOGGLE  
FACE
  - 0 HOOKS-EACH END SPRING
- DISASSEMBLY: REMOVE NUT AND LOCK WASH-  
ER SECURING CONTACT BOX  
COVER AND REMOVE COVER.

7.14 TRANSFER BAIL MECHANISM




- SAT FELT WASHERS LATCHES  
(2 WASHERS)
- G ENGAGING SUR- TRANSFER BAIL  
FACE
- 0 HOOKS-EACH END SPRING  
(2 SPRINGS)
- 02 BEARING SURFACE TRANSFER BAIL
- SAT OIL WICK TRANSFER BAIL

7.15 FUNCTION CLUTCH MECHANISM




- 02 LATCHING SUR- CLUTCH STOP LEVER  
FACE AND CLUTCH LATCH  
LEVER
- 0 HOOKS-EACH END SPRING  
(2 SPRINGS)
- SAT FELT WASHERS (2 CLUTCH TRIP BAIL  
FRONT & REAR)


7.16 MARGIN INDICATING MECHANISM




7.17 LOCAL LINE FEED MECHANISM




7.18 SHAFT MECHANISM



7.19 INTERMEDIATE GEAR MECHANISM




7.20 SIGNAL GENERATOR MECHANISM (continued) REST KEYBOARD IN UPRIGHT POSITION




RIGHT SIDE VIEW


7.21 LOCKING BAIL MECHANISM




7.22 CODE BAR BAIL MECHANISM




7.23 UNIVERSAL BAIL LATCH LEVER




7.24 NEW DESIGN KEYBOARD AND VARIABLE FEATURES  
 REST KEYBOARD IN UPRIGHT POSITION




7.25 ELECTRICAL LINE BREAK MECHANISM




7.26 CODE LEVER UNIVERSAL BAIL MECHANISM



7.27 LOCK BAR LATCH MECHANISM



7.28 LOCAL PAPER FEED-OUT MECHANISM





SECTION 4 - EARLIER DESIGN MECHANISM ADJUSTMENTS

1. KEYBOARD

NOTE

IN ORDER TO PERFORM ALL SIGNAL GENERATOR ADJUSTMENTS, IT WILL BE NECESSARY TO REMOVE GENERATOR FROM THE KEYBOARD. SEE DISASSEMBLY AND REASSEMBLY PARAGRAPH 10.b.(1)




FIGURE 4-1 KEYBOARD, SIGNAL GENERATOR, FRONT VIEW

*check this clearance between marking and spacing projections on front selector lever.*

217B


**TRANSFER LEVER SPRING TENSION**

**REQUIREMENT**

TRANSFER LEVERS IN MARKING POSITION.  
 CODE BAR BAIL LATCH SPRING REMOVED  
 START TRANSFER LEVER (5TH FROM FRONT)  
 MANUALLY MOVED TO MARKING POSITION.

	TRANSFER LEVERS	START LEVER
MIN.	5 1/2 OZS.	7 1/2 OZS.
MAX.	8 OZS.	10 OZS.

TO START LEVER MOVING.



**ROCKER BAIL DETENT**

**REQUIREMENT**

CLEARANCE BETWEEN THE ROCKER BAIL ARM AND BOTH THE MARKING AND THE SPACING PROJECTIONS OF THE SELECTOR LEVERS SHOULD BE EQUAL WITHIN 0.005 INCH

**TO CHECK**


ROTATE THE CAM SLEEVE UNTIL THE FRONT SELECTOR LEVER HAS COME DOWN OFF THE PEAK OF ITS CAM AND IS OPPOSITE THE LOW PART OF ITS CAM. WITH THE FRONT SELECTOR LEVER IN THE MARKING (LEFT) POSITION, AND THE ROCKER BAIL ARM AGAINST THE LOWER STOP OF ITS DETENT, HOLD THE SELECTOR LEVER LIGHTLY UP AGAINST THE ROCKER BAIL AND GAUGE THE CLEARANCE BETWEEN THE SELECTOR LEVER AND THE CAM. SHIFT THE ROCKER BAIL ARM AGAINST THE UPPER STOP OF ITS DETENT AND HOLD FRONT SELECTOR LEVER TO THE RIGHT AND UP SO THAT THE SPACING PROJECTION TOUCHES THE ROCKER BAIL. GAUGE THE CLEARANCE BETWEEN THE SELECTOR LEVER AND THE CAM. THESE TWO CLEARANCES SHOULD BE EQUAL WITHIN 0.005 INCH.

**TO ADJUST**

EQUALIZE CLEARANCES BY ROTATING THE ECCENTRIC PIVOT STUD OF THE DETENT WITH ITS LOCK NUT LOOSENED. KEEP THE HIGH PART OF THE ECCENTRIC TOWARD THE GENERATOR SHAFT.

FIGURE 4-2 KEYBOARD, SIGNAL GENERATOR, FRONT VIEW

NOTE: REMOVE MECHANICAL BREAK LEVER AND SPRING OR ELECTRICAL BREAK LEVER SPRING AND SWITCH, IF EQUIPPED. SEE FIGURE 4-45



INTERMEDIATE LEVER SPRING TENSION

REQUIREMENT

CLUTCH DISENGAGED. PULL HORIZONTALLY,  
PARALLEL TO INTERMEDIATE LEVER'S PATH  
MIN. 2 OZS.  
MAX. 4 OZS.  
TO START LEVER MOVING.  
CHECK SPACING AND MARKING LEVERS.

ROCKER EXTENSION  
REQUIREMENT

EQUAL CLEARANCE ( WITHIN 0.005 INCH)  
BETWEEN THE ROCKER EXTENSION  
AND BOTH THE MARKING AND THE  
SPACING INTERMEDIATE LEVERS WHEN  
SELECTED INDIVIDUALLY.


TO CHECK

ROTATE THE SHAFT UNTIL THE MARKING  
INTERMEDIATE LEVER IS SELECTED AND  
THE FLUTTER LEVER IS ON LOW PART  
OF CAM. GAUGE CLEARANCE IN LEFT FIG.  
REPEAT PROCEDURE FOR SPACING INTERMEDIATE  
LEVER. GAUGE CLEARANCE IN RIGHT FIGURE.

TO ADJUST

EQUALIZE CLEARANCES BY POSITIONING  
THE ROCKER EXTENSION WITH ITS  
MOUNTING SCREWS LOOSENED.

FIGURE 4-3 KEYBOARD, SIGNAL GENERATOR, REAR VIEW


**TO CHECK**

FRONT SELECTOR LEVER IN MARKING POSITION, GENERATOR SHAFT ROTATED UNTIL FRONT SELECTOR LEVER IS ON PEAK OF ITS CAM. MOVE OSCILLATING LEVER TOWARD MARKING INTERMEDIATE LEVER AND GAUGE THE GAP. THEN WITH FRONT SELECTOR LEVER IN SPACING POSITION AND ON PEAK OF ITS CAM, MOVE OSCILLATING LEVER TOWARD SPACING INTERMEDIATE LEVER AND CHECK GAP.

**TO ADJUST**

EQUALIZE THE CLEARANCES BY POSITIONING THE STOP BRACKET WITH ITS MOUNTING SCREWS LOOSENED.

FIGURE 4-4 KEYBOARD, SIGNAL GENERATOR, REAR VIEW



NOTE: REPLACE THE BREAK LEVER AND ASSOCIATED PARTS

FIGURE 4-5 KEYBOARD, SIGNAL GENERATOR, REAR VIEW

**(A) FLUTTER LEVER SPRING TENSION****REQUIREMENT**

WITH SIGNAL GENERATOR CLUTCH DISENGAGED  
AND SPACING INTERMEDIATE LEVER HELD  
AWAY FROM FLUTTER LEVER, INSERT SCALE  
BETWEEN CASTING AND BREAK ROD  
MIN. 1 OZ.  
MAX. 2 1/4 OZS.  
TO START FLUTTER LEVER MOVING.

**(B) FLUTTER LEVER****(1) REQUIREMENT**

WITH THE FLUTTER LEVER ON EACH  
LOW PORTION OF ITS CAM AND THE  
MARKING AND SPACING INTERMEDIATE  
LEVERS ALTERNATELY SELECTED,  
THE CLEARANCE BETWEEN THE  
FLUTTER LEVER AND LATCHING  
SURFACE OF SELECTED INTERMEDIATE  
LEVER SHOULD BE

MIN. 0.005 INCH  
MAX. 0.018 INCH

WITH THE CLUTCH ENGAGED AND  
THE SELECTOR LEVERS (FIG. 2)  
TO MARKING (LEFT), ROTATE THE  
GENERATOR SHAFT TO CHECK CLEAR-  
ANCE ON MARKING INTERMEDIATE  
LEVERS. HOLD SELECTOR LEVERS  
TO SPACING (RIGHT) AND ROTATE  
SHAFT TO CHECK SPACING INTER-  
MEDIATE LEVERS.

**TO ADJUST**

POSITION THE FLUTTER LEVER MOUNTING  
STUD IN THE ELONGATED MOUNTING HOLE  
WITH THE LOCK NUT LOOSENEED.

**(2) REQUIREMENT**

AFTER REQUIREMENT (1) HAS BEEN  
MET, SELECT THE MARKING AND  
SPACING INTERMEDIATE LEVERS  
ALTERNATELY AND ROTATE THE  
GENERATOR SHAFT UNTIL THE  
FLUTTER LEVER IS ON SUCCESS-  
IVE HIGH PORTIONS OF ITS CAM.  
UNDER THESE CONDITIONS THERE  
SHOULD BE SOME CLEARANCE  
BETWEEN THE OSCILLATOR AND THE  
SELECTED INTERMEDIATE LEVER.

**TO ADJUST**

REFINE THE FLUTTER LEVER ADJUST-  
MENT AND RECHECK REQUIREMENT (1).





FIGURE 4-6 KEYBOARD, SIGNAL GENERATOR. REAR VIEW

83  
25  
113

FOR CLUTCH SHOE LEVER SPRING TENSION AND CLUTCH SHOE SPRING TENSION SEE FIGURE 1-35



REQUIREMENT


CLEARANCE WHEN CLUTCH IS DISENGAGED SHOULD BE 0.055 INCH TO 0.085 INCH LESS THAN WHEN CLUTCH IS ENGAGED.

TO CHECK

LATCH CLUTCH IN DISENGAGED POSITION AND MEASURE CLEARANCE. ROTATE GEAR UNTIL OIL HOLE IS UPWARD. ENGAGE CLUTCH AND MEASURE CLEARANCE.

TO ADJUST

LOOSEN THE TWO ADJUSTING DISK CLAMP SCREWS TO POSITION DISK.



NOTE  
 AFTER ABOVE ADJUSTMENT IS MADE, CHECK FOR DRAG ON DRUM AS FOLLOWS: DISENGAGE CLUTCH. HOOK SPRING SCALE ON TOP TOOTH OF GEAR AND PULL AT RIGHT ANGLE TO RADIUS OF GEAR. IF PULL OF 8 OZS. OR MORE IS REQUIRED TO MOVE THE DRUM, REFINE ABOVE ADJUSTMENT.

115  
90

FIGURE 4-7 KEYBOARD, CLUTCH MECHANISM, TOP VIEW






FIGURE 4-8 KEYBOARD, CLUTCH MECHANISM



**NOTE**

REPLACE SIGNAL GENERATOR ON THE KEYBOARD. MAKE CERTAIN THAT THE CODE BAR BAIL LATCH LEVER (FIG. 4-11) IS UNDER CODE LEVER BAIL LATCH LEVER (FIG. 4-13), THAT (IF EQUIPPED) BREAK KEY ROD, ATTACHED TO BREAK LEVER (FIG. 4-45) IS IN ITS GUIDE HOLE IN CODE LEVER GUIDE, AND THAT THE CLUTCH TRIP BAIL EXTENSION (FIG. 4-8) IS IN THE NOTCH PROVIDED IN THE CLUTCH TRIP BAR (REAR) AND THAT THE CODE BAR BAIL (FIGURE 4-11) IS RESTING IN THE NOTCHES OF THE FIVE CODE BARS, THE CLUTCH TRIP BAR AND THE KEYLEVER UPSTOP BAR. SEE DISASSEMBLY AND REASSEMBLY PARAGRAPH 10.b.(1).

FIGURE 4-9 KEYBOARD, CLUTCH MECHANISM



(TOP VIEW)

(A) GENERATOR CONTACT REQUIREMENT

THE MARKING AND SPACING CONTACT GAPS SHOULD BE EQUAL

TO CHECK


REMOVE THE COVER FROM THE CONTACT BOX. FIRST, MOVE THE DETENT TOGGLE AGAINST ITS SPACING STOP AND GAUGE THE MARKING CONTACT GAP. THEN MOVE THE DETENT TOGGLE AGAINST ITS MARKING STOP AND GAUGE SPACING CONTACT GAP.

TO ADJUST

ROTATE THE CONTACT BOX ADJUSTING SCREW WITH ITS LOCK NUT LOOSENED AND WITH THE CONTACT BOX MOUNTING SCREWS FRICTION TIGHT. REPLACE CONTACT BOX COVER.

NOTE

CHECK BY MEANS OF A SIGNAL CHECKING DEVICE WHERE POSSIBLE AND CAREFULLY REFINE THE ADJUSTMENT TO ELIMINATE ALL BIAS FROM THE SIGNALS BY EQUALIZING THE CURRENT-ON AND CURRENT-OFF INTERVALS.



(REAR VIEW)


(B) CONTACT BOX SPRING TENSION REQUIREMENT

CONTACT BOX COVER REMOVED. DETENT LEVER SPRING DISCONNECTED.

MIN. 2 OZS.  
MAX. 4 OZS.

TO BREAK CONTACT

FIGURE 4-10 KEYBOARD, CONTACT ASSEMBLY



RESET LEVER SPRING TENSION

REQUIREMENT

CLUTCH DISENGAGED.  
 MIN. 2 OZS.  
 MAX. 4 OZS.  
 TO START THE RESET LEVER  
 MOVING.

CODE BAR BAIL ADJUSTING SCREW

REQUIREMENT

CLUTCH ENGAGED. LTRS. COMBINATION SELECTED  
 CLUTCH ROTATED 1/2 TURN UNTIL RESET  
 LEVER IS IN EXTREME LEFT HAND POSITION.  
 CLEARANCE BETWEEN THE CODE BAR BAIL  
 LATCH LEVER AND CODE BAR BAIL ROLLER.  
 MIN. 0.004 INCH  
 MAX. 0.008 INCH

TO ADJUST

POSITION THE CODE BAR BAIL ADJUSTING  
 SCREW WITH ITS LOCK NUT LOOSENED.

FIGURE 4-11 KEYBOARD, CODE BAR BAIL MECHANISM, FRONT VIEW




FIGURE 4-12 KEYBOARD, CODE BAR BAIL, FRONT VIEW

**CODE LEVER BAIL LATCH LEVER SPRING**


**REQUIREMENT**

SIGNAL GENERATOR CLUTCH DISENGAGED  
 CODE BAR BAIL LATCH TRIPPED. CODE LEVER BAIL  
 EXTENSION HELD AWAY FROM LATCHING SURFACE  
 OF CODE LEVER BAIL LATCH LEVER.

MIN. 3 OZS.

MAX. 5 OZS.

TO START CODE LEVER BAIL LATCH LEVER MOVING.



**NON-REPEAT LEVER**

**REQUIREMENT**

ANY KEYLEVER DEPRESSED, SIGNAL GENERATOR SHAFT ROTATED  
 UNTIL CLUTCH IS DISENGAGED. CLEARANCE BETWEEN CODE LEVER  
 BAIL EXTENSION AND CODE LEVER BAIL LATCH LEVER


MIN. 0.020 INCH

MAX. 0.030 INCH

LET UP ON KEYLEVER UNTIL SURFACES TO BE MEASURED  
 ARE IN LINE.

**TO ADJUST**

POSITION NON-REPEAT BELL CRANK SHOULDER PIVOT SCREW  
 IN ITS ELONGATED HOLE WITH LOCK NUT LOOSENED.



**NON-REPEAT SPRING TENSION**

**REQUIREMENT**

GENERATOR CLUTCH DISENGAGED.


ANY KEYLEVER DEPRESSED.

MIN. 1/2 OZ.

MAX. 1 1/2 OZS.

TO START NON-REPEAT LEVER  
 MOVING DOWNWARD.

FIGURE 4-13 KEYBOARD, NON-REPEAT MECHANISM



KEYLEVER LOCK-BALL CHANNEL AND LOCK BALL END PLAY

REQUIREMENT

GENERATOR SHAFT ROTATING, CLUTCH SHOULD TRIP CONSISTENTLY WHEN TWO KEYLEVERS ARE DEPRESSED ALTERNATELY. CLUTCH SHOULD NOT TRIP WHEN TWO KEYLEVERS ARE DEPRESSED SIMULTANEOUSLY. WHEN EITHER Q OR P KEYLEVER IS FULLY DEPRESSED, CLEARANCE SHOULD BE  
 MIN. SOME CLEARANCE  
 MAX. 0.015 INCH  
 BETWEEN TIP OF WEDGELOCK AND BOTTOM OF CHANNEL.

TO ADJUST

POSITION CHANNEL WITH MOUNTING SCREWS LOOSENED. POSITION LOCK BALL ADJUSTING SCREW APPROXIMATELY 0.060 INCH ABOVE BOTTOM OF BALL CHANNEL.

FIGURE 4-14 KEYBOARD, KEYLEVER LOCKING MECHANISM

CODE LEVER BAIL LATCH LEVER ECCENTRIC

(1) REQUIREMENT

KEYLEVER WITH SHORTEST DOWNWARD STROKE FULLY DEPRESSED. CLEARANCE BETWEEN FRONT VERTICAL SURFACE OF THE CODE LEVER BAIL EXTENSION AND THE STOP ON THE REAR END OF THE CODE LEVER BAIL LATCH LEVER.

MIN. 0.025 INCH  
MAX. 0.040 INCH

(2) REQUIREMENT

GENERATOR CLUTCH DISENGAGED. CLEARANCE BETWEEN CODE LEVER BAIL LATCH LEVER AND THE CODE BAR BAIL LATCH  
MIN. 0.005 INCH  
MAX. 0.035 INCH

TO ADJUST

ROTATE THE CODE LEVER BAIL LATCH LEVER ECCENTRIC.




FIGURE 4-15 KEYBOARD CODE LEVER BAIL LATCH MECHANISM, LEFT SIDE VIEW

CODE LEVER BAIL SPRING TENSION

REQUIREMENT

GENERATOR CLUTCH DISENGAGED. NON-REPEAT LEVER HELD AWAY.

MIN. 1-3/4 OZS.  
MAX. 3 OZS.

TO START THE BAIL MOVING.

CODE BAR GUIDES

REQUIREMENT

CLEARANCE BETWEEN CODE BARS AND CODE BAR GUIDES  
MIN. SOME CLEARANCE  
MAX. 0.010 INCH

TO ADJUST

POSITION THE TWO CODE BAR GUIDES WITH THEIR MOUNTING SCREWS LOOSENED.




FIGURE 4-16 KEYBOARD, CODE BAR MECHANISM, LEFT SIDE VIEW


CODE LEVER BAIL NON-REPEAT EXTENSION

REQUIREMENT

GENERATOR CLUTCH DISENGAGED. CODE LEVER BAIL ROTATED UNTIL CODE LEVER BAIL LATCH LEVER JUST TRIPS. WITH BAIL LATCHING EXTENSION RESTING AGAINST VERTICAL SURFACE OF LATCH LEVER AND SHAFT ROTATED UNTIL NON-REPEAT LEVER IS FULLY LATCHED ON CODE BAR BAIL EXTENSION  
 MIN. SOME CLEARANCE  
 MAX. 0.015 INCH  
 BETWEEN ADJUSTABLE EXTENSION AND NON-REPEAT LEVER.

TO ADJUST

POSITION ADJUSTABLE EXTENSION WITH CLAMP SCREW LOOSENED.



CODE LEVER SPRING TENSION

REQUIREMENT

(OPERATING UNDER POWER)  
 WITH THE GENERATOR  
 CLUTCH DISENGAGED  
 MIN. 3 1/2 OZS.  
 MAX. 8 OZS.  
 TO OPERATE A KEY.




FIGURE 4-17 KEYBOARD, NON-REPEAT MECHANISM



LOCK BAR SPRING TENSION

REQUIREMENT

GENERATOR CLUTCH DISENGAGED.  
 KEYBOARD LOCK KEY HELD DEPRESSED.  
 MIN. 5 OZS.  
 MAX. 9 OZS.  
 TO START LOCK BAR MOVING.

CODE BAR SPRING TENSION


REQUIREMENT

LETTERS KEYLEVER DEPRESSED.  
 GENERATOR CLUTCH ENGAGED.  
 MIN. 3 OZS.  
 MAX. 4 OZS.  
 TO START A CODE BAR MOVING.

CLUTCH TRIP BAR SPRING TENSION

REQUIREMENT

LETTERS KEYLEVER DEPRESSED.  
 GENERATOR CLUTCH ENGAGED  
 CLUTCH TRIP BAIL EXTENSION HELD  
 AWAY FROM CLUTCH TRIP BAR  
 MIN 5 OZS.  
 MAX. 9 OZS.  
 TO START CLUTCH TRIP BAR (REAR)  
 MOVING.



REQUIREMENT

LETTERS SELECTION APPLIED TO CODE BAR.  
 CLEARANCE BETWEEN SHOULDER ON CLOSEST  
 CODE BAR AND ENGAGING FACE OF CODE BAR BAIL.  
 MIN. 0.010 INCH  
 MAX. 0.020 INCH

TO ADJUST

POSITION BUMPER WITH MOUNTING SCREWS.  
 LOOSENED.

FIGURE 4-18 KEYBOARD, CODE BAR MECHANISM

CODE LEVER GUIDE


REQUIREMENT

CR KEYLEVER HELD DEPRESSED WHILE DISENGAGING CLUTCH. CLEARANCE BETWEEN CR FUNCTION LEVER AND STOPPING EDGE OF NUMBER 5 CODE BAR

MIN. 0.005 INCH  
MAX. 0.015 INCH

TO ADJUST

POSITION THE CODE LEVER GUIDE WITH ITS FOUR MOUNTING SCREWS LOOSENED.



CODE BAR BOUNCE SUPPRESSOR BRACKET SUPPORT SCREW

REQUIREMENT

GENERATOR CLUTCH DISENGAGED, LETTERS SELECTION APPLIED TO CODE BARS, BOUNCE SUPPRESSOR BAIL HELD AGAINST RESET LEVER WITH PRESSURE OF 3 OZS. APPLIED VERTICALLY TO BAIL BETWEEN NO. 2 AND NO. 3 CODE BAR LATCH, CLEARANCE BETWEEN BOUNCE SUPPRESSOR BAIL AND NO. 5 CODE BAR LATCH SHOULD BE  
MIN. SOME CLEARANCE  
MAX. 0.010 INCH


TO ADJUST

POSITION SUPPORT SCREW WITH ITS LOCK NUT LOOSENED

CODE BAR LATCH SPRING

REQUIREMENT

GENERATOR CLUTCH COMPLETELY DISENGAGED  
MIN. 1/4 OZ.  
MAX. 1 1/4 OZS.  
TO START LATCH MOVING.



CODE BAR LATCH

(1) REQUIREMENT

LETTERS SELECTION APPLIED TO THE CODE BARS AND THE CODE BARS AGAINST THEIR STOP. CLEARANCE BETWEEN CODE BAR AND LATCH  
MIN. 0.010 INCH  
MAX. 0.025 INCH

(2) REQUIREMENT

BOUNCE SUPPRESSOR BAIL SHOULD RIDE CENTRALLY ON RESET LEVER.

TO ADJUST

POSITION BOUNCE SUPPRESSOR BRACKET WITH MOUNTING SCREWS LOOSENED

FIGURE 4-19 KEYBOARD, CODE BAR MECHANISM, FRONT VIEW





FIGURE 4-20 KEYBOARD, CODE LEVER BAIL , SPACE BAR

(A) INTERMEDIATE GEAR BRACKET

(2) REQUIREMENT

THERE SHOULD BE A BARELY PERCEPTIBLE AMOUNT OF BACKLASH BETWEEN THE INTERMEDIATE DRIVING GEAR AND THE INTERMEDIATE DRIVEN GEAR AT THE POINT WHERE THE BACKLASH IS THE LEAST.

TO ADJUST


RAISE OR LOWER THE FRONT END OF THE INTERMEDIATE GEAR BRACKET BY MEANS OF THE FILISTER HEAD ADJUSTING AND CLAMPING SCREWS LOCATED AT THE FRONT END OF THE BRACKET. REFINE REQUIREMENTS IF NECESSARY

(1) REQUIREMENT

THERE SHOULD BE A BARELY PERCEPTIBLE AMOUNT OF BACKLASH BETWEEN THE TYPING UNIT DRIVEN GEAR AND THE TYPING UNIT DRIVING GEAR AT THE POINT WHERE BACKLASH IS THE LEAST

TO ADJUST

POSITION THE COMPLETE INTERMEDIATE GEAR MECHANISM BRACKET BY UTILIZING THE ADJUSTING SLOTS WITH THE THREE HEXAGON HEAD SCREWS LOOSENED. ALIGN THE GEARS AT THIS TIME



NOTE: OVERLOAD MECHANISM SPRING ADJUSTMENT  
APPLIES ONLY TO UNITS SO EQUIPPED

OVERLOAD CLUTCH LEVER

(B) OVERLOAD MECHANISM SPRING

REQUIREMENT

OVERLOAD CLUTCH LEVER IN ITS NOTCH


MIN. 40 OZS.

MAX. 64 OZS.

TO START LEVER MOVING

LEVER MUST NOT JUMP FROM NOTCH WITH LESS THAN 64 OZS.

FIGURE 4-21 KEYBOARD OR BASE, MOTOR, AND TYPING UNIT GEARING, LEFT SIDE VIEW



\* APPLIES TO KEYBOARD ONLY

FIGURE 4-22 KEYBOARD LOCK, LOCAL LINE FEED, AND CARRIAGE RETURN MECHANISM, LEFT SIDE VIEW.


MARGIN INDICATOR SPRING TENSION

REQUIREMENT

MIN. 9 OZS.

MAX. 14 OZS.

TO MOVE THE CONTACT LEVER FROM THE CONTACT PLUNGER.



PAPER-FEED-OUT MOTOR START

MECHANISM SPRING (KEYBOARD)

REQUIREMENT

MIN. 6 OZS.

MAX. 10 OZS.

TO START THE LEVER MOVING




FIGURE 4-23 KEYBOARD, MARGIN INDICATING AND PAPER FEED-OUT MECHANISMS

## 2. TYPING UNIT




FIGURE 4-24 TYPING UNIT, SELECTOR CLUTCH MECHANISM, RIGHT SIDE VIEW





FIGURE 4-25 TYPING UNIT, CODE BAR SHIFT MECHANISM



**REQUIREMENT**

MOTION OF FRONT AND REAR CODE BAR SHIFT LEVERS SHOULD BE EQUALIZED WITH RESPECT TO CODE BAR TRAVEL.

**TO CHECK (FRONT)**

SELECT BLANK COMBINATION AND ROTATE MAIN SHAFT UNTIL CODE BAR SHIFT LEVER LINK REACHES HIGHEST TRAVEL. TAKE UP PLAY FOR MAXIMUM CLEARANCE. CLEARANCE BETWEEN FRONT CODE BAR SHIFT LEVER AND SHOULDER ON NEAREST CODE BAR SHIFT BAR.

MIN. 0.002 INCH  
MAX. 0.025 INCH

**TO CHECK (REAR)**

SELECT LETTERS COMBINATION. CHECK CLEARANCE BETWEEN REAR CODE BAR SHIFT LEVER AND SHOULDER OF CODE BAR SHIFT BAR IN SAME WAY.

MIN. 0.002 INCH  
MAX. 0.025 INCH

**TO ADJUST**

POSITION CODE BAR SHIFT LEVER LINK BRACKET BY MEANS OF MOUNTING SCREWS (3).

FIGURE 4-26 TYPING UNIT, CODE BAR SHIFT MECHANISM





FIGURE 4-27 TYPING UNIT, SPACING MECHANISM

- NOTE: 1. THIS ADJUSTMENT APPLIES ONLY TO UNITS WITH NON-ADJUSTABLE GUIDE PLATES  
 2. FOR UNITS WITH ADJUSTABLE GUIDE PLATES AND ONE STOP FUNCTION CLUTCHES SEE FIG. 1-43  
 3. FOR UNITS WITH ADJUSTABLE GUIDE PLATES AND TWO STOP FUNCTION CLUTCHES SEE FIG. 1-43  
 CHANGE FIRST SENTENCE IN REQUIREMENT TO: "DISENGAGE FUNCTION CLUTCH AT STOP GIVING LEAST CLEARANCE" THEN PROCEED AS SPECIFIED.



#### SHIFT CODE BAR OPERATING MECHANISM

REQUIREMENT: ( FOR TWO STOP FUNCTION CLUTCH)

DISENGAGE FUNCTION CLUTCH AT POSITION GIVING LEAST CLEARANCE. ROTATE TYPE BOX CLUTCH 1/2 REVOLUTION. HOLD FIGURES FUNCTION LEVER IN REARWARD POSITION WITH TENSION OF 32 OZS.

CLEARANCE BETWEEN THE FUNCTION PAWL SHOULDER AND FACE OF FUNCTION BAR

MIN. 0.002 INCH

MAX. 0.015 INCH

WHEN PLAY IN PAWL IS TAKEN FOR MAXIMUM CLEARANCE.

DISENGAGE FIGURES FUNCTION PAWL. CHECK LETTERS FUNCTION PAWL IN SAME MANNER.


#### TO ADJUST

POSITION SHIFT ASSEMBLY WITH CLAMP SCREWS LOOSENED. TAKE UP PLAY IN MOUNTING HOLES TO REAR.

CAUTION: MANUALLY OPERATE LETTERS AND FIGURES FUNCTION LEVER ALTERNATELY LEVERS SHOULD BE FREE OF BINDS.

FIGURE 4-28 TYPING UNIT, SHIFT MECHANISM

- NOTE: 1. THIS ADJUSTMENT APPLIES ONLY TO UNITS WITH TWO STOP FUNCTION CLUTCHES.  
2. FOR UNITS WITH ONE STOP FUNCTION CLUTCHES SEE FIG. 1-44



#### FUNCTION RESET BAIL BLADE

##### (1) REQUIREMENT

FUNCTION CLUTCH DISENGAGED AT STOP POSITION GIVING LEAST CLEARANCE. TYPE BOX CLUTCH DISENGAGED. ALL FUNCTION PAWLS UNLATCHED FROM THEIR FUNCTION BARS. FUNCTION BAR HELD IN MAXIMUM REARWARD POSITION. CLEARANCE BETWEEN FUNCTION BAR AND RESET BAIL BLADE  
MIN. 0.018 INCH                      MAX. 0.035 INCH

##### TO CHECK

MEASURE CLEARANCE AT BARS LOCATED IN STUNT BOX SLOTS. 1, 4, 11, 18, 23, 33, 38, AND 41. IF THERE IS NO BAR IN A DESIGNATED SLOT, USE NEAREST BAR. IF THERE IS A BAR ON EACH SIDE OF A DESIGNATED VACANT SLOT, USE BAR IN HIGHEST NUMBERED SLOT. (NOTE: FACING REAR OF UNIT, SLOTS ARE NUMBERED FROM LEFT TO RIGHT)

##### TO ADJUST

POSITION BLADE ON RESET BAIL WITH BLADE MOUNTING SCREWS FRICTION TIGHT.

##### (2) REQUIREMENT

TYPE BOX CLUTCH ROTATED 1/2 REVOLUTION, FUNCTION LEVER HELD IN REARMOST POSITION WITH 2 LBS. MAXIMUM TENSION. LATCH ASSOCIATED PAWL ONLY ONE AT A TIME WITH 32 OZS. TENSION APPLIED TO FUNCTION PAWL, IT SHOULD OVERTRAVEL ITS BAR  
MIN. 0.002 INCH

TO ADJUST  
REFINE REQUIREMENT (1)




FIGURE 4-29 TYPING UNIT, FUNCTION BAR RESET MECHANISM


NOTE: THESE ADJUSTMENTS APPLY ONLY TO HORIZONTAL POSITIONING DRIVE MECHANISMS EQUIPPED WITH TENSION SPRINGS

NOTE THE LOOPS OF THIS SPRING ARE OFF-SET FROM CENTER IN THE SAME DIRECTION. THE SPRING MUST BE HOOKED ON ITS ANCHORS SO THAT THE SIDE OF THE SPRING, ON WHICH THE LOOPS ARE LOCATED, IS TOWARD THE REAR OF THE MACHINE. WHEN REMOVING EITHER SPRING EXERCISE CARE TO AVOID KINKS IN LOOPS.

#### HORIZONTAL POSITIONING DRIVE LINKAGE SPRING TENSION

##### REQUIREMENT

SPRING UNHOOKED FROM ITS POST.  
LINKAGE IN ITS UNBUCKLED POSITION.  
MIN. 14 OZS.  
MAX. 18 OZS.  
TO PULL SPRING TO INSTALLED LENGTH.



#### HORIZONTAL POSITIONING DRIVE LINKAGE

##### REQUIREMENT

TYPE BOX CLUTCH DISENGAGED. CODE BARS 4 AND 5 TO SPACING (RIGHT).  
CLEARANCE BETWEEN EACH SIDE OF CENTER HORIZONTAL STOP SLIDE AND DECELERATING SLIDES ON SIDE WHERE KNEE LINK IS STRAIGHT, SHOULD BE EQUAL (WITHIN 0.005 INCH)  
MIN. 0.020 INCH  
MAX. 0.040 INCH

##### TO ADJUST

LOOSEN BEARING STUD MOUNTING SCREWS AND CONNECTING STRIP MOUNTING SCREWS FRICTION TIGHT. POSITION ONE OR BOTH BEARING STUDS ON THE CONNECTING STRIP TO PROVIDE 0.025 INCH TO 0.035 INCH BETWEEN THE CENTER HORIZONTAL SLIDE AND THE DECELERATING SLIDE ON THE SIDE WHERE THE LINKAGE IS NOT BUCKLED. TIGHTEN THE TWO INNER MOUNTING SCREWS. CHANGE POSITION OF REVERSING SLIDE AND CHECK OPPOSITE CLEARANCE. EQUALIZE BY SHIFTING BOTH STUDS AND CONNECTING STRIP AS A UNIT. HOLD THE DRIVE LINKAGE HUB AGAINST THE LOWER VERTICAL LINK OF THE DRIVE LINKAGE. TIGHTEN THE TWO OUTER BEARING STUD MOUNTING SCREWS. CHECK THE LINKAGE FOR FREEDOM THROUGHOUT A COMPLETE CYCLE.

FIGURE 4-30 TYPING UNIT, HORIZONTAL POSITIONING DRIVE MECHANISM, FRONT VIEW




FIGURE 4-31 TYPING UNIT, CARRIAGE RETURN MECHANISM




FIGURE 4-32 TYPING UNIT, RIGHT MARGIN AND DECELERATING SLIDE MECHANISM, FRONT VIEW




FIGURE 4-33 TYPING UNIT, PRINTING AND TYPE BOX CARRIAGE




FIGURE 4-34 TYPING UNIT, SHIFT MECHANISM



**(A) PRINTING HAMMER STOP BRACKET**  
 (FOR THICK TYPE BOX WITH DUMMY PALLETS)  
 REQUIREMENT

TYPE BOX IN BLANK OR CR POSITION  
 (WHICHEVER DOES NOT PRINT) AND NEAR  
 CENTER OF PLATEN. PRINTING TRACK IN  
 ITS DOWNWARD POSITION. PRINTING HAMMER  
 HELD AGAINST ITS STOP WITH 8 OZS. OF  
 PRESSURE. CLEARANCE BETWEEN PRINTING  
 HAMMER AND DUMMY TYPE PALLET

FRICTION FEED	SPROCKET FEED
MIN. 0.008 INCH	SOME
MAX. 0.020 INCH	0.020 INCH


TO ADJUST

POSITION THE STOP BRACKET WITH ITS  
 MOUNTING SCREW AND THE PRINTING  
 HAMMER BAIL PIVOT STUD LOOSENED.

FOR SPROCKET FEED UNITS, SEE FIGURE 2-9)

**(C) TYPE PALLET SPRING TENSION**  
 REQUIREMENT

TYPE BOX REMOVED FROM THE  
 UNIT. 8 OZ. SCALE APPLIED  
 VERTICALLY TO THE END OF  
 THE PALLET SHANK.  
 MIN. 1/4 OZ.  
 MAX. 3/4 OZ.  
 TO START PALLET MOVING.



**(B) PRINTING ARM**

**(1) REQUIREMENT**

PRINTING TRACK IN MAXIMUM DOWNWARD  
 POSITION.

PRINTING HAMMER OPERATING BAIL  
 AGAINST ITS STOP.

SOME CLEARANCE BETWEEN SECONDARY  
 PRINTING ARM AND FORWARD EXTENSION  
 OF HAMMER OPERATING BAIL.

MAX. 0.015 INCH

WHEN PRINTING ARM SLIDE IS HELD  
 DOWNWARD OVER EACH PRINTING TRACK  
 MOUNTING SCREW FOR MAXIMUM CLEARANCE.

**(2) REQUIREMENT**

PRINTING TRACK IN UPPERMOST  
 POSITION. LATCHING EXTENSION  
 OF PRINTING HAMMER OPERATING  
 BAIL SHOULD OVERTRAVEL LATCHING  
 SURFACE OF OPERATING BAIL LATCH BY

MIN. 0.006 INCH

CHECK RIGHT AND LEFT POSITION  
 TO ADJUST

POSITION SECONDARY PRINTING ARM  
 WITH CLAMP SCREWS LOOSENED.

**NOTE**

THE PRINTING ARM ADJUSTMENT SHOULD ALWAYS BE MADE  
 WITH THE PRINTING HAMMER OPERATING BAIL  
 SPRING BRACKET (FIGURE 1-49) IN THE NO. 1 POSITION  
 POSITIONS NO. 2 AND NO. 3 ARE TO BE USED ONLY FOR  
 MAKING MULTIPLE COPIES.

FIGURE 4-35 TYPING UNIT, PRINTING MECHANISM




FIGURE 4-36 TYPING UNIT, RIBBON REVERSE MECHANISM




FIGURE 4-37 TYPING UNIT, FUNCTION PAWL STRIPPER MECHANISM




FIGURE 4-38 TYPING UNIT, HORIZONTAL MOTION STOP AND AUTOMATIC CARRIAGE RETURN MECHANISM

NOTE: THIS ADJUSTMENT APPLIES ONLY TO UNITS WITH A TWO-STOP FUNCTION CLUTCH




FIGURE 4-39 TYPING UNIT, SINGLE-DOUBLE LINE FEED MECHANISM





FIGURE 4-40 TYPING UNIT, FUNCTION CONTACT



CAUTION: CARE SHOULD BE EXERCISED IN SOLDERING TO CONTACT SPRINGS SINCE EXCESSIVE HEAT WILL ANNEAL THE SPRINGS. CONTACT SPRINGS ONCE SOLDERED SHOULD NOT BE USED AGAIN.




FIGURE 4-41 TYPING UNIT, FUNCTION CONTACTS




FIGURE 4-42 BASE AND TYPING UNIT, MARGIN INDICATING MECHANISM

3. VARIABLE FEATURES





FIGURE 4-43 KEYBOARD, REPEAT-ON-SPACE MECHANISM



**TIME DELAY DISABLING DEVICE****REQUIREMENT**

DISABLE THE TIME DELAY MECHANISM  
 WHEN NOT REQUIRED.

**TO ADJUST**

RAISE THE PILOT SCREW (LOCK NUT  
 LOOSENED) AND ECCENTRIC FOLLOWER  
 PAWL UNTIL THE PAWL CLEARS THE  
 RATCHET WHEEL.

FIGURE 4-44 KEYBOARD OR BASE, TIME DELAY DISABLING DEVICE





FIGURE 4-45 KEYBOARD, SIGNAL LINE BREAK MECHANISMS




FIGURE 4-46 KEYBOARD, BACK SPACE MECHANISM




FIGURE 4-47 KEYBOARD, BACKSPACING MECHANISM

(A)  
OPERATING LEVER SLIDE ARM

## NOTE

PRIOR TO THIS ADJUSTMENT CHECK FUNCTION  
RESET BAIL BLADE ADJUSTMENT (FIGURE 54)

## REQUIREMENT

ON UNITS WITH TWO-STOP FUNCTION CLUTCHES.  
FUNCTION CLUTCH DISENGAGED. TYPE BOX CLUTCH  
ROTATED 1/2 REVOLUTION PAST STOP POSITION ON UNITS  
WITH ONE-STOP FUNCTION CLUTCH, ROTATE CLUTCH  
UNTIL FUNCTION PAWL STRIPPER BLADE IS IN ITS  
LOWER POSITION AND THE FUNCTION RESET BAIL ROLLER  
IS ON THE HIGH PART OF CAM. HORIZONTAL TABULATOR  
FUNCTION PAWL PULLED TO REAR AND LATCHED OVER  
FUNCTION BAR. CLEARANCE

MIN. 0.020 INCH

MAX. 0.030 INCH

## TO ADJUST

POSITION SLIDE ARM ON OPERATING LEVER WITH  
MOUNTING STUD FRICTION TIGHT.

(D) TABULATOR SHAFT SPRING  
(TORSION)

## NOTE

FOR LOCATION OF SPRING  
SEE FIGURE 4-51

## REQUIREMENT

OPERATING LEVER IN  
UNOPERATED POSITION.

(AS IN LOWER FIGURE)

MIN. 1 1/2 OZS.

MAX. 3 1/2 OZS.

TO START SLIDE ARM  
MOVING.

(C)  
OPERATING LEVER EXTENSION  
LINK SPRING

## REQUIREMENT

TRIP ARM LATCH BAIL SPRING  
UNHOOKED, OPERATING LEVER  
IN OPERATED POSITION.  
SLIDE ARM AGAINST  
BLOCKING LINK.

MIN. 8 3/4 OZS.

MAX. 10 3/4 OZS.

TO START LINK MOVING.

(B)  
OPERATING LEVER ADJUSTING PLATE

## REQUIREMENT

OPERATING LEVER IN UNOPERATED  
POSITION. CLEARANCE

MIN. 0.070 INCH

MAX. 0.085 INCH

## TO ADJUST

POSITION ADJUSTING PLATE ON  
BRACKET WITH MOUNTING  
SCREWS LOOSE.





FIGURE 4-48 TYPING UNIT, HORIZONTAL TABULATOR MECHANISM (LEFT VIEW)



**TRIP ARM LATCH BAIL ADJUSTING PLATE REQUIREMENT**  
 SPACING CLUTCH AND TYPE BOX  
 CLUTCH DISENGAGED.  
 OPERATING LEVER SLIDE ARM  
 TO REAR AND LATCHED ON BLOCKING  
 ARM. LATCH BAIL IN FULLY LATCHED  
 POSITION. SPACING TRIP ARM  
 DOWN AND BEARING UP AGAINST LATCHING  
 SURFACE OF LATCH BAIL . CLEARANCE  
 MIN. SOME  
 MAX. 0.008 INCH  
 TO ADJUST  
 POSITION LATCH BAIL ADJUSTING  
 PLATE WITH MOUNTING SCREW  
 FRICTION TIGHT.




FIGURE 4-49 TYPING UNIT, HORIZONTAL TABULATOR MECHANISM, LEFT VIEW




FIGURE 4-50 TYPING UNIT, HORIZONTAL TABULATOR MECHANISM





FIGURE 4-51 TYPING UNIT, HORIZONTAL TABULATOR MECHANISM.





PAWL MOUNTING ARM OPERATING RANGE (PRELIMINARY)

NOTE - - - PRIOR TO THIS ADJUSTMENT, CHECK THE FOLLOWING: OSCILLATING RAIL SLIDE (FIGURE 51), PRINTING CARRIAGE POSITION (FIG. 1-57) AND PRINTING CARRIAGE LOWER ROLLER (FIG. 1-56).

REQUIREMENT (UNITS WITH FRICTION FEED PLATENS)

SPACING CLUTCH DISENGAGED. SPACING PAWL, WHICH IS FARTHEST ADVANCED, ENGAGING TOOTH IMMEDIATELY ABOVE CUTAWAY SECTION OF RATCHET. TABULATOR PAWL RIDING UP ON FIXED STOP. HIGH PART OF ECCENTRIC TOWARD FORK OF MOUNTING ARM. CLEARANCE

MIN. 0.070 INCH                      MAX. 0.090 INCH


REQUIREMENT (UNITS WITH SPROCKET FEED PLATENS)

HIGH PART OF ECCENTRIC TOWARD LOWER ROLLER MOUNTING SCREW.

TO ADJUST

POSITION ECCENTRIC.

FIGURE 4-52 TYPING UNIT, HORIZONTAL TABULATOR MECHANISM.



PAWL MOUNTING ARM OPERATING RANGE (FINAL)  
REQUIREMENT

— CLEARANCE MIDWAY BETWEEN MINIMUM AND MAXIMUM LIMITS OF OPERATING RANGE.

#### TO CHECK

TO DETERMINE MAXIMUM LIMIT. . . (A) SET FIVE TABULATOR STOPS AS SHOWN IN FIGURE. (B) POSITION PAWL IMMEDIATELY TO RIGHT OF STOP NO. 1. (C) POSITION ECCENTRIC TO SET CLEARANCE APPROXIMATELY 0.030 INCH. (NOTE . . . MEASURE ALL CLEARANCES AT STOP NO. 1. WITH PLAY TAKEN UP IN CARRIAGE TO REDUCE GAP TO MINIMUM.) (D) MARK COLUMN LOCATION BY PRINTING A CHARACTER ON PAPER. (E) POSITION PAWL IMMEDIATELY TO RIGHT OF STOP NO. 2. AND MARK COLUMN LOCATION AS IN STEP (D). (F) REPEAT STEP (E) FOR OTHER THREE STOPS. (G) GRADUALLY INCREASE CLEARANCE UNTIL CARRIAGE STOPS ONE SPACE BEFORE ANY COLUMN WHILE RECEIVING FIGURES G LETTERS X FROM TRANSMITTER DISTRIBUTOR. (NOTE . . . IF UNIT IS NOT EQUIPPED WITH XD CONTROL, PUT FILL-IN CHARACTERS OF LETTERS OR FIGURES IN TAPE TO DELAY PRINTING UNTIL CARRIAGE COMPLETES TRAVEL.) (H) DECREASE CLEARANCE UNTIL TEN LINES OF TABULAR OPERATION CAN BE MADE WITHOUT ERROR. (I) GAGE AND RECORD VALUES OF CLEARANCE. (2) GAGE ALL CLEARANCES WITH FRONT FEED PAWL FARTHEST ADVANCED.

TO DETERMINE MINIMUM LIMITS . . . (A) REPEAT STEPS (B) AND (C) ABOVE. (B) GRADUALLY DECREASE CLEARANCE UNTIL CARRIAGE STOPS ONE SPACE AFTER ANY COLUMN. (C) INCREASE CLEARANCE UNTIL TEN LINES OF TABULAR OPERATION CAN BE MADE WITHOUT ERROR. (I) GAGE AND RECORD VALUE OF CLEARANCE.

#### TO ADJUST

IF MINIMUM LIMIT IS POSITIVE, ADD IT TO MAXIMUM LIMIT AND DIVIDE THE SUM BY TWO. SET RESULTANT AMOUNT AS MIDPOINT OF RANGE. IF MINIMUM LIMIT IS ZERO OR LESS, DIVIDE MAXIMUM LIMIT BY TWO AND SET THIS AMOUNT AS MIDPOINT OF RANGE. THE DIFFERENCES BETWEEN LIMITS NORMALLY IS NOT LESS THAN 0.045 INCH.

#### TABULATOR STOP SETTING (NOT ILLUSTRATED)

##### RIGHT MARGIN TABULATOR STOP (WITH WIDE SHELF)

NOTE: PRIOR TO THIS ADJUSTMENT, CHECK THE FOLLOWING: RIGHT MARGIN (FIGURE 4-51 AND PAWL MOUNTING ARM OPERATING RANGE (FIGURE 4-52 AND 4-53).

POSITION PRINTING CARRIAGE AT RIGHT MARGIN (SPACING CUTOUT OPERATED). INSERT STOP WITH WIDE SHELF IN SLOT IMMEDIATELY TO LEFT OF TABULATOR PAWL.

##### COLUMNAR TABULATOR STOPS

PLACE CARRIAGE IN POSITION TO PRINT FIRST CHARACTER IN COLUMN. INSERT STOP IN SLOT IMMEDIATELY TO LEFT OF TABULATOR PAWL. STORE EXTRA STOPS IN SLOTS BEYOND PRINTING LINE AT EITHER END OF SHAFT.

NOTE . . . WHEN PRINTING FORMS, CHECK STOP SETTINGS WITH RELATION TO COLUMNS. CORRESPONDING STOPS ON ALL MACHINES CONNECTED IN A CIRCUIT MUST BE THE SAME NUMBER OF SPACING OPERATIONS FROM LEFT MARGIN.

FIGURE 4-53 TYPING UNIT HORIZONTAL TABULATOR MECHANISM