

**BULLETIN 318B
VOL 3**

**TECHNICAL MANUAL
MODEL 37
AUTOMATIC SEND-RECEIVE (ASR)
TELETYPEWRITER SET
FOR SWITCHED NETWORK SERVICE**

CONTENTS

**DISASSEMBLY AND REASSEMBLY
LUBRICATION**



**TELETYPE[®]
CORPORATION**
5555 TOUHY AVENUE, SKOKIE, ILLINOIS



318B
Volume 3

INTRODUCTION

Bulletin 318B is a technical manual that provides general and specific technical information about the Model 37 Automatic Send-Receive (ASR) Teletypewriter Set and its component units. This bulletin contains adjustment and lubrication sections for the late design typing unit and early and late design answer-back units. The bulletin consists of three volumes.

Volume 1 contains sections for description, installation, and principles of operation. Volume 2 provides the adjustments for the components and troubleshooting for the set. Volume 3 includes information for lubrication and disassembly and reassembly.

Each volume is made up of a group of appropriate independent sections. Each section is complete within itself --- it is separately identified by a title and section number, and the pages are numbered consecutively.

Each individual section is identified by a 9-digit section number which appears at the top of each page of a section. The section number appears on the left corner of left-hand pages and on the right corner of right-hand pages. In addition, the section number contains the suffix TC which identifies it as a Teletype Corporation section. All sections are placed in the technical manual in ascending numerical order.

To locate specific information, refer to the table of contents on the following page. In the first column, under "Equipment," find the name of the component unit or set in question. Move across the page to the second column and locate the title being sought. The applicable 9-digit section number can then be found in the third column. Turn to Page 1 of the applicable section, and the contents of that section will be found.

The sections comprising this bulletin, and sections on earlier units not included, are stocked separately and may be ordered individually if the entire bulletin is not required.




TABLE OF CONTENTS

<u>Equipment</u>	<u>Content</u>	<u>Section</u>	<u>Issue</u>
Teletypewriter Set (ASR)	Removal and Replacement of Components	574-302-702TC	1
Typing Unit	Lubrication	574-320-704TC	1
Typing Unit	Disassembly and Reassembly	574-320-705TC	1
Keyboard Unit	Lubrication	574-321-704TC	2
Keyboard Unit	Disassembly and Reassembly	574-321-705TC	2
Answer-Back Unit - Early Design	Lubrication	574-325-701TC	3
Answer-Back Unit - Late Design	Lubrication	574-325-704TC	1
Typing Unit Cover and Pan	Lubrication	574-326-704TC	2
Reperforator-Transmitter Cabinet	Lubrication	574-327-701TC	2
Nontyping Reperforator Unit	Lubrication	574-329-701TC	2
Nontyping Reperforator Unit	Disassembly and Reassembly	574-329-702TC	2
Typing Reperforator	Lubrication	574-330-701TC	1
Typing Reperforator	Disassembly and Reassembly	574-330-702TC	1
Tape Reader Unit	Lubrication	592-801-701TC	5
Tape Reader Unit	Disassembly and Reassembly	592-801-702TC	5

Note: Motor unit information is contained in Bulletin 295B.



37 AUTOMATIC SEND-RECEIVE (ASR) TELETYPEWRITER SET

REMOVAL AND REPLACEMENT OF COMPONENTS

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL	1	RT ELECTRICAL SERVICE UNIT	23
2. KEYBOARD SEND-RECEIVE UNIT REMOVAL AND REPLACEMENT OF COMPONENTS.....	3	RT MODULE CABINET	25
TYPING UNIT.....	3	1. GENERAL	
CONTROL PANEL.....	6	1.01 This section provides removal and re- placement of component information for the 37 Automatic Send-Receive (ASR) Teletype- writer Set (Figure 1).	
KEYBOARD	7		
MOTOR UNIT	9		
INTERMEDIATE GEAR ASSEMBLY..	9		
KEYBOARD RESET MECHANISM ..	11		
BASE.....	11		
TYPING UNIT COVER AND PAN...	11		
ELECTRICAL SERVICE UNIT.....	13		
ANSWER-BACK ASSEMBLY	14		
UTILITY STRIP.....	16		
TABLE.....	16		
3. REPERFORATOR-TRANSMITTER (RT) MODULE REMOVAL AND REPLACEMENT OF COMPONENTS..	17		
REPERFORATOR MOUNTING PLATE.....	17		
REPERFORATOR UNIT	19		
REPERFORATOR MOTOR.....	19		
HIGH SPEED TAPE READER.....	21		
READER MOTOR	22		




Figure 1 - 37 Automatic Send-Receive
 (ASR) Teletypewriter Set

SECTION 574-302-702TC

1.02 Photographs and line drawings are used to identify the mechanisms and specific parts mentioned in the procedures. Refer to the appropriate parts section for illustrations and part numbers of parts and assemblies.

1.03 References in the procedures to left or right, up or down, top or bottom, etc, refer to the unit viewed with the keytops and controls facing the front (Figure 1).

1.04 Most maintenance, lubrication, and adjustments can be accomplished after a component has been removed with no further disassembly. If possible, disassembly should be confined to subassemblies which do not require adjustment, or which can be removed without disturbing adjustments. When reassembling the subassemblies, all requirements for adjustments, clearances, and spring tensions must be observed.




Figure 2 - Typing Unit and Control Panel


1.05 The loss of retaining rings and springs should be avoided during disassembly by holding the items with one hand while it is released with the other. Springs should not be stretched or distorted more than is necessary for removal or their effective spring tension may be altered.

2. KEYBOARD SEND-RECEIVE UNIT REMOVAL AND REPLACEMENT OF COMPONENTS

TYPING UNIT


- 2.01 To remove the typing unit from the base, proceed as follows (Figures 2 through 4).
- (1) Depress the cover latches on both sides of the typing unit cover and tilt the cover back until it rests on the table.

CAUTION: REMOVE POWER BEFORE DISASSEMBLING THE SET.



(Right Side View)

Figure 3 - Typing Unit



KEYBOARD RESET
COUPLER

Figure 4 - Typing Unit

- (2) Remove the paper roll from the typing unit.
- (3) Disconnect electrical cable plugs P306 and P308 from the selector and function box connectors at the upper right rear corner of the typing unit.
- (4) Remove four typing unit mounting screws from the feet at the bottom front and rear corners of the left and right sides of the typing unit.

Note: Steps (5) and (6) may be omitted unless the control panel is to be replaced.

- (5) Remove two screws securing the control panel trim plate to the top of the control panel and remove the plate. Be careful not to drop the screws into the base.
- (6) Loosen the control panel retaining screws at the right and left upper rear corners of the control panel. Raise the control panel upward and forward.

- (7) Look straight down along the front plate of the typing unit and locate the keyboard reset coupler. The lug on the coupler must be located at the top facing forward. If it is not in this position, turn the motor fan counterclockwise until alignment is obtained.
- (8) Grasp the typing unit under the curve at the top rear of the left side frame, and in the rectangular opening at the right top corner of the front plate. Lift the typing unit straight up away from the base. Be careful that the keyboard reset coupling guard clears the control panel components. Set the typing unit aside in a protected area.

CAUTION: REMOVE THE TYPING UNIT ONLY IN THE MANNER DESCRIBED IN 2.08(8).


2.02 To replace the typing unit, proceed as follows (Figures 2 through 5).

- (1) Locate the selector clutch on the right end of the typing unit main shaft, and the keyboard reset coupler at the lower center

Note: The typing unit must be installed on the base and secured to make these adjustments, and the keyboard housing must be removed.

To Check

Engage clutch. Rotate shaft until reset bail roller peaks on one of the high points of the cam. Note position of top edge of trip arm relative to scribed lines. Rotate the shaft until reset bail roller peaks on other high point of cam and note the trip position again.



Requirement

The lowest of the two trip arm positions obtained should be between the scribed lines.

To Adjust

Loosen the clamp screw friction tight. Insert screwdriver blade between the pry point and the appropriate arm of the adjusting plate and position trip arm to meet requirement. Tighten clamp screw.




Figure 5 - Keyboard Trip Arm Adjustment

front. Facing the right end of the typing unit, rotate the selector clutch in a counterclockwise direction until the lugs on the keyboard reset coupler are vertical.

Note: Use handwheel TP161430, part of tool kit TP151940, to turn the selector shaft.

- (2) Viewing the keyboard from the right side, rotate the mechanical reset shaft in a clockwise direction until the open slots in the plastic universal joint member are vertical to the base.
- (3) Loosen the control panel retaining screws at the right and left upper rear corners of the control panel. Raise the control panel upward and forward.
- (4) Grasp the typing unit under the curve at the top rear of the left side of the frame, and in the rectangular opening at the right top corner of the front plate. Raise the typing unit and position it directly over the base. Tilt the typing unit slightly forward (toward the keyboard) from a normal level attitude. Align the reset coupler with the slot in the plastic universal joint member, and carefully lower the typing unit onto the locating studs and tilt back to engage the intermediate gear assembly. Be certain that the main shaft driven gear and the intermediate gear mesh properly.
- (5) Secure the typing unit to the base with the four typing unit mounting screws, beginning with the left rear screw.

Note: If a replacement typing unit (other than the original) is installed, the following adjustments are required.

- (6) Adjust keyboard trip arm following the procedures given in Figure 5.
- (7) Remove the two screws and lockwashers holding the intermediate gear guard to the typing unit base and remove the guard. Loosen the five motor mounting screws and move the motor away from engagement with the intermediate gear assembly.
- (8) Using the pry points at the rear of the intermediate gear assembly, adjust the intermediate gear assembly from front to rear until there is a barely perceptible backlash between the main shaft driven gear and the intermediate drive gear. This backlash

can be from 0.004 inch to 0.015 inch. Tighten the three intermediate gear assembly mounting screws.

- (9) Using the back left edge of the motor cradle and the rear flange of the base as a pry point, move the motor forward to fully engage the motor pinion and the intermediate driven gear. Then using the pry point located forward of the left rear mounting screw, ease the motor unit back to establish a barely perceptible backlash. Tighten the five motor mounting screws. Make sure the fan guard does not interfere with free rotation of fan.
- (10) Install the gear guard over the intermediate gear assembly with the two screws and lockwashers taken out during the removal procedures. Align guard to clear gears and motor unit, and tighten.
- (11) Install the keyboard housing at this time by aligning it with the keyboard cover and sliding it back against the housing brackets.
- (12) Secure keyboard housing with one keyboard housing mounting screw, lockwasher, and flat washer inserted from the rear center of the right and left housing brackets. Check housing for proper fit and secure screws.
- (13) The remaining replacement procedures are the reverse of the removal procedures.

CONTROL PANEL

2.03 To remove the control panel, proceed as follows (Figures 2, 3, 6, and 7).

- (1) Detach the control panel cable clamps from the rear of the keyboard by taking out the screw, lockwasher, and flat washer securing each (one clamp for each switch assembly).
- (2) Disconnect the control panel cable plugs from the control panel by pulling them straight out, using care to avoid bending the connector pins. Wrap the plugs with a protective covering and tape it securely to protect the plug.
- (3) Take out the control panel mounting screw, lockwasher, and flat washer at the upper right and left sides of the control panel securing the panel to the arc slides.

(4) Lift the control panel free from the keyboard and store it in a closed container to protect the switch and connector contacts.


2.04 To replace the control panel, reverse the procedures used for removal.

Note: After installing and attaching the cable clamps on the control panel cables closest to the plugs, position the lower cable clamp 4 inches down the cable to allow a loop in the cable before securing the lower clamp.

KEYBOARD

2.05 To remove the keyboard from the base assembly, proceed as follows (Figures 2, 3, and 6).

(1) Remove the keyboard housing mounting screws, lockwashers and flat washers from the rear center of the left and right housing brackets. Slide the keyboard housing straight forward to remove.



(Right Rear View)

Figure 6 - Control Panel and Keyboard




Figure 7 - Keyboard, Control Panel, Reset Mechanism, and Motor Unit

Note: Do not loosen or remove the two bracket retaining screws in the housing brackets that secure the brackets to the keyboard, unless removal is necessary. If the brackets are disturbed, they will require realignment during reassembly to properly align the keyboard housing.

(2) Disconnect electrical plug P307 from the keyboard connector.

(3) Support the lower front of the keyboard and remove the two keyboard mounting screws, lockwashers, and flat washers from each side securing the keyboard to the base.

(4) Lift the keyboard up very slowly, tilting the right side up slightly, and moving the keyboard a little to the right until the H-plate disengages from the trip arm in the keyboard. Holding the H-plate to the left as the keyboard is lifted will assist the disengagement process.

(5) Store the keyboard in a protected area.

2.06 To replace the keyboard, reverse the procedures used for removal.

Note: Use great care to assure the H-plate is properly engaged in the front and rear slots of the trip arm before lowering the keyboard and moving it to the left to its proper position on the base.

MOTOR UNIT

2.07 To remove the motor unit from the base, proceed as follows (Figure 7).

- (1) Remove typing unit as described in 2.01.
- (2) Disconnect the two motor leads from the two leads originating from the bottom of connector J304 mounted on the left rear of the base.
- (3) Remove the fan guard by taking out the motor mounting screws securing it in the right rear corner of the base.
- (4) Take out the remaining four motor mounting screws and lift the motor unit from the base. Set motor unit aside.

2.08 To replace the motor unit, reverse the procedures used for removal. Adjust the motor to the intermediate gear assembly as described in 2.02(8).

INTERMEDIATE GEAR ASSEMBLY

2.09 To remove the intermediate gear assembly from the base, proceed as follows (Figures 7 and 8).

- (1) Remove typing unit as described in 2.01.
- (2) Remove two screws and lockwashers securing the gear guard to the base.
- (3) Remove the gear guard.
- (4) Remove the three intermediate gear assembly mounting screws, lockwashers, and flat washers securing the intermediate gear assembly to the base.
- (5) Lift the intermediate gear assembly from the base and set aside.





Figure 8 - Keyboard, Control Unit, Reset Mechanism, and Intermediate Gear Assembly



(Top View)

Figure 9 - Pan Cable Routing

2.10 To replace the intermediate gear assembly, reverse the procedures used during removal. If original intermediate gear assembly is installed, make sure there is a barely perceptible amount of backlash between the motor and intermediate gear assembly before tightening screws. If other than original intermediate gear assembly is installed, replace the typing unit and follow the adjustment information described in 2.02(7) and 2.02(8). Replace the gear guard.

KEYBOARD RESET MECHANISM

2.11 To remove the keyboard reset mechanism from the base, proceed as follows (Figure 6 and 7).

- (1) Remove the typing unit as described in 2.01.
- (2) Remove the control panel cables as described in 2.03(3) and 2.03(4).
- (3) Remove the keyboard as described in 2.05.
- (4) Pull the two push-on lead terminals straight off from the auxiliary contacts on the top rear of the keyboard reset mechanism.
- (5) Remove the three reset mechanism frame mounting screws, lockwashers, and flat washers securing the reset mechanism to the base.
- (6) Pull the keyboard reset mechanism forward until the frame extension clears the base. Set the keyboard reset mechanism aside in a protected area.

2.12 To replace the keyboard reset mechanism, reverse the procedures used for removal.

Note: Route the leads down through the first hole in the left front corner of the base, bring them back up through the front center hole, then pass leads back down through the second hole from the right front of the base, and finally bring them up through the hole in the right front center before attaching them to the auxiliary contacts.

BASE

2.13 To remove the base from the typing unit cover and pan, proceed as follows (Figure 8).

(1) Remove the typing unit (2.01), control panel cables (2.03(3) and (4)), and keyboard (2.05).

(2) Remove the two base retainers by taking out the retainer screws and lockwashers securing each to the pan.

Note: If the screw and lockwasher attaching each base retainer to the base for immobility during shipment are still in place, they should be removed and discarded at this time.

(3) Lift base retainers from the pan through holes in base.

(4) Remove the ground strap from the base by pulling the push-on ground terminal straight off from the terminal tab mounted on the right side of the base.

(5) Lift the base free from the pan one corner at a time. The shock mounts may hold the base firmly due to a suction formed in the cup in the base. A little force will break the base loose.

Note: No further disassembly of the base is recommended unless parts require replacement.

2.14 To replace the base, reverse the procedures used during removal.

TYPING UNIT COVER AND PAN

2.15 To remove the typing unit cover and pan, from the table, proceed as follows (Figures 9 and 11).


(1) Remove the typing unit pan (2.13).

(2) Disconnect the copyright cable plug P302 from the 2-pin connector in the cover.

(3) Pull the push-on ground terminal free from the ground terminal tab in the cover.

(4) Use a screwdriver blade or needle nose pliers to spring the upper speed clip at the rear of the pan inward, and pull the base cable free. In a similar manner release the control panel cable from the lower speed clip.

(5) Release the control cable(s) from the speed clips on the left side of the pan.



(Left Oblique Front View)

Figure 10 - Table

- (6) Release the control cable and keyboard cable from the speed clips on the right side of the pan.
- (7) Open the front panel of the table by pressing upward on the panel catch while pulling outward on the door pull. The panel will be stopped by the spring stop, but can be released by pressing upward on the strip. Lower the panel until the door pull rests on the floor.
- (8) Locate the copyright cable under the table. Draw the cable down and carefully feed the plug P302 and ground terminal through the oblong slots in the pan and table.
- (9) Draw the base cable down and feed its plug P304 through the slots.
- (10) Draw the selector cable and its plug P306, and the function box cable and its plug P308 down through the hole.
- (11) Draw the keyboard cable and its plug P307 back and down through the table slot.
- (12) Very carefully work the control panel cables and connector plugs down through the slot.

(13) Remove the four pan shoulder screws and lockwashers from the grommets in the lower side of the table to release the typing unit pan and cover.

(14) Lift the typing unit pan and cover out of the recess in the table and set aside.

2.16 To replace the typing unit pan and cover, reverse the procedures used during removal.

ELECTRICAL SERVICE UNIT

2.17 To remove the electrical service unit from the left compartment in the base of the table proceed as follows (Figures 10 through 13).

(1) Open the front panel of the table and draw all electrical service unit cables back through the oblong slot in the table as directed in 2.15.




Figure 11 - Cable Routing Above Table

- (2) Disconnect the power cord plug from the utility strip.
- (3) Remove three service unit retaining screws, lockwashers, and flat washers from the retaining flanges at the front top and bottom of the unit.
- (4) If the shipping bracket secured to the floor of the left table compartment for shipment has not been removed, take out the mounting screw and lockwasher holding it in place and discard this hardware.
- (5) Lift the electrical cables out of the cable hanger at the top rear wall of the compartment.
- (6) Pull the electrical service unit straight forward out of the table.


2.18 To replace the electrical service unit, reverse the removal procedures.

ANSWER-BACK ASSEMBLY

2.19 To remove the answer-back assembly from the electrical service unit, proceed as follows (Figure 11).

- (1) Carefully pull plug connectors from the top of the printed circuit card on the answer-back assembly.
- (2) Remove four answer-back mounting screws, lockwashers, and flat washers from the corners of the answer-back mounting plate.
- (3) Lift the answer-back assembly out of the electrical unit, and set aside.

2.20 To replace the answer-back assembly, reverse the removal procedures.



(Right Oblique Cut-Away View of Table)

Figure 12 - Electrical Service Unit





Figure 13 - Electrical Service Unit



(Left Cut-Away View of Table)

Figure 14 - Utility Strip

UTILITY STRIP

2.21 To remove the utility strip from the left compartment in the base of the table, proceed as follows (Figures 8 and 12).

- (1) Open the front panel of the table by pressing upward on the panel catch, and pull forward on the door pull.
- (2) Press upward on the spring stop, and continue to swing the panel outward and downward until the door pull rests on the floor.
- (3) Disconnect the utility strip power cord plug, if it is connected to power.

- (4) Remove two utility strip mounting screws, lockwashers, and flat washers securing the utility strip to the top and bottom angle members of the table on the right side of the left compartment.

- (5) Remove the utility strip from the table and store.

2.22 To replace the utility strip, reverse the removal procedures.

TABLE

2.23 No removal or replacement procedures are required for the table since all areas are accessible through the front panel and the right pedestal door.

3. REPERFORATOR-TRANSMITTER (RT) MODULE REMOVAL AND REPLACEMENT OF COMPONENTS

- (2) Raise the cover until the cover slide safety latch passes the stop, and the slide drops into the upstop position.

REPERFORATOR MOUNTING PLATE

CAUTION: IF THE COVER IS NOT PROPERLY LATCHED, IT MAY DROP DURING REMOVAL OR REPLACEMENT PROCEDURES CAUSING INJURIES.

3.01 To remove the nontyping reperforator unit (reperforator unit), reperforator motor, and reperforator mounting plate from the RT module cabinet as an assembly, proceed as follows (Figures 15 and 16).

- (3) Remove tape from the reperforator unit.
- (4) Disconnect plug P315 from the connector located on the bracket above the drive gear hub.

- (1) Depress the cover latches in the recess on both sides of the cover assembly near the front.





Figure 15 - RT Module



(Top Front View)

Figure 16 - RT Module (Cabinet Opened)

(5) Disconnect power plug P314 from the 9-pin connector at the rear center of the reperforator mounting plate.

(6) Pull the cable out of the spring clip attaching it to the rear hand lift bracket.

(7) Turn the three slotted mounting posts to align the flats on the posts with the edges of the squared mounting holes in the reperforator mounting plate.

(8) Lift the reperforator mounting plate with the reperforator and reperforator motor attached straight up out of the cabinet, lifting by means of the front and rear hand lift brackets. Use care to avoid damaging the chad chute.

3.02 To replace the reperforator mounting plate with the reperforator unit and the reperforator motor attached, reverse the removal procedures. Use great care in guiding the chad chute in place to avoid damaging the chute.

REPERFORATOR UNIT

3.03 To remove the reperforator unit from the reperforator mounting plate, proceed as follows (Figures 16 through 18).

(1) Remove the two pilot screws from the feet at the front of the reperforator unit.

(2) Remove the reperforator mounting screw and flat washer from the left rear of the unit casting, and the lockwasher and nut from the channel in the center bottom of the reperforator mounting plate.

(3) Remove the punch mounting screw, lockwasher, and flat washer from the right of the front punch plate.

(4) Remove the two chad chute mounting screws, lockwashers, and flat washers from the upper front right, and pull the chad chute away from the punch block assembly.

(5) Loosen the gear guard retaining screws, and slide the gear guard to the left until it clears the screw heads. Lift the gear guard free from the reperforator mounting plate and store.

(6) Lift the reperforator unit straight away from the reperforator mounting plate. Store in a protected area.

3.04 To replace the reperforator unit, reverse the removal procedures, except that the motor pinion and reperforator gear engagement must be checked for a barely perceptible backlash, and there must be some clearance between the motor pinion retainer and the reperforator gear. If necessary, proceed as follows (Figure 17).

(1) With the front motor plate mounting screws loose, loosen the locknuts and adjust the threaded bushings to obtain the required backlash.

(2) If there is any interference between the pinion and gear, loosen the two rear motor plate mounting screws, position the plate, and tighten the screws.

(3) Replace the gear cover and adjust it to clear the reperforator gear at all points.

(4) Tighten both gear guard retaining screws.

(5) Complete replacement procedures in reverse of removal procedures.

REPERFORATOR MOTOR

3.05 To remove the reperforator motor from the reperforator mounting plate proceed as follows (Figures 16 through 18).

(1) Detach the green motor ground lead from the ground terminal tab on the reperforator mounting plate by pulling the push-on terminal straight off.

(2) Disconnect the two motor leads from the two pendant leads originating from the base of the 9-pin connector mounted in the rear center of the reperforator mounting plate.

(3) Remove the five motor mounting screws, lockwashers, and flat washers, and lift the reperforator motor from the reperforator mounting plate.

(4) If the motor mounting plate requires removal from the reperforator mounting plate, take out the two front motor plate mounting screws, two lockwashers, and two flat washers; and the two rear motor plate mounting screws, and two flat washers. Lift the motor mounting plate out of the reperforator mounting plate. Do not disturb the threaded bushings or locknuts.




Figure 17 - Reperforator Motor Pinion and Gear Mesh




Figure 18 - Reperforator, Mounting Plate, and Motor

3.06 To replace the reperforator motor, reverse the removal procedures, except, do not tighten the motor plate mounting screws at this time.

HIGH SPEED TAPE READER

3.07 To remove the high speed tape reader (tape reader) from the RT module cabinet, proceed as follows (Figures 16, 19 and 20).

(1) Pull the reader cover straight off from the reader and set it aside.

(2) Take out the three reader mounting screws, lockwashers, and flat washers. The left side screw can be reached by lifting the coverplate of the reader. The two screws on the right are located under the overhanging tape guideplate and may require a wrench or offset screwdriver for removal.

READER DRIVE BELT TENSION

Requirement

Belt should deflect

Min 3/8 inch---Max 5/8 inch
with 5 oz force applied at center of belt span.

To Adjust

Loosen motor mounting screws. Position motor to meet requirement. Tighten mounting screws.




Figure 19 - Reader Drive Belt Tension




Figure 20 - Reader Motor Removal

- (3) Remove the reader drive belt.
- (4) Lift the reader straight up to separate it from the electrical connector P311, and the reader mounting bracket. Set the reader aside in a protected area.

3.08 To replace the reader, reverse the removal procedure. Adjust the position of the reader motor to the left in the reader mounting bracket until a deflection of 3/8 to 5/8 inch is obtained when a 5-ounce force is applied to the center of the belt, then tighten the four reader motor mounting screws (Figure 19).

READER MOTOR

3.09 To remove the reader motor from the reader mounting bracket, proceed as follows (Figures 19 and 20).

- (1) Depress the latch button on the left side of the cabinet and swing the cabinet door open.
- (2) Remove the cover insulator from the terminal block TB202 by taking out the two screws and lockwashers.

- (3) Disconnect the blue and white motor leads, and the incoming RT electrical service unit leads from terminal block TB202. Replace screws and cover.

- (4) Pull the rubber boot off the capacitor.

- (5) Detach the red and black motor lead push-on terminals from the capacitor terminal tabs.

- (6) Remove the four reader bracket adjustment screws, lockwashers, and flat washers from the right and left isolation brackets.

- (7) Remove the two screws, lockwashers, and nuts attaching the reader connector P311 to the connector mounting bracket in the front of the reader mounting bracket.

- (8) Lift the reader mounting bracket with the reader motor attached, and tilt it upward as it is pulled forward out of the RT module cabinet. Be sure the reader connector and cable drop free without hanging up on the motor or bracket.

- (9) Remove the reader motor from the reader mounting bracket by taking out the four reader motor mounting screws, lockwashers, and flat washers.

3.10 To replace the reader motor in the RT module cabinet, reverse the procedures used for removal. In addition, after the reader mounting bracket has been attached to the right and left isolation brackets with the four reader bracket adjustment screws, lockwashers, and flat washers, adjust the bracket so the front face of the rear reader side plate is aligned with the front face of the top front cabinet member before tightening the screws.

RT ELECTRICAL SERVICE UNIT

3.11 Remove the RT electrical service unit from the RT module cabinet as follows (Figures 21 and 23).

(1) Disconnect the interface cable plug P310, and the power cable plug from their mating connectors in the KSR table. Be sure that power has been removed.

(2) Pull the interface and power cables back into the lower equipment compartment of the cabinet.

(3) Detach the pushbutton control switch P316, that is mounted through the slot in the front left of the cabinet cover, by taking out the four switch mounting screws and lockwashers. Do not disturb the two central alignment screws, or the three height adjustment screws that position the switch in the slot.

(4) Detach the control switch cable from the cabinet cover by removing the nut, lockwasher and cable clamp securing the cable in the cover.

(5) Remove door power plug P312.

(6) Remove four remaining cable clamps by taking off the nuts and lockwashers attaching them.




Figure 21 - Pushbutton Switch Removal




Figure 22 - RT Module Cable Routing




Figure 23 - 37 RT Electrical Service Unit

(7) Remove the four screws, lockwashers, and flat washers from the top and bottom angle brackets on the front of the RT electrical service unit.

(8) Pull the RT electrical service unit forward out of the RT module cabinet, at the same time feeding the cables down through the opening at the front of the perforator shelf in the cabinet, into the lower equipment compartment.

RT MODULE CABINET

3.12 No removal or replacement procedures are required for the RT module cabinet since all areas are accessible through the cover and door. Any further removal is obvious, and alignment procedures are obvious. The intent of any alignment of cabinet parts is to keep edges, corners, and sides of the cover, door, etc, flush, parallel, and in alignment with the adjacent surfaces.



37 TYPING UNIT
 LUBRICATION

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL	2	Vertical clutches, gears, and bell cranks	26
2. BASIC UNIT	4	Vertical linkage, shafts, and slides	26
LUBRICATION AREAS —		Vertical positioning rack	27
BOTTOM	13	LUBRICATION AREAS — REAR ...	18
Line feed bail, levers, and gears ...	17	Function bar and pawl	22
Local line feed trip lever	16	Function stripper blade	21
Main shaft clutches and gears	14	Line feed bars	23
Reset bail and shaft	15	Paper guide bracket shaft and latch (sprocket feed)	20
Trip shaft cam and levers	15	Paper release (friction feed)	20
Vertical detent	16	Paper straightener (friction feed) ...	19
LUBRICATION AREAS — FRONT... ..	4	Platen hubs and pins (sprocket feed)	20
Backspace bail, lever, link, and pawl (located behind spacing drum)	11	Platen shaft and rollers (friction feed)	19
Carriage return and backspace levers	10	Single-double line feed lever	23
Codebars	7	Suppression function lever	22
Horizontal clutches, gears, levers, and links	10	Trip shaft bearings and springs	21
Horizontal detent (located behind spring drum)	9		
Local line feed lever	8		
Oscillating rail	8		
Platen pressure bail (friction feed)	4		
Print hammer and levers	6		
Print hammer carriage	6, 7		
Spacing drum	12		
Spring drum	9		
Typebox	5		
LUBRICATION AREAS —			
LEFT SIDE	24		
Codebar detent	27		
Line feed gears	28		
Retraction slide and pawls	25		
Ribbon feed bracket and ratchet - (early design)	29		
Ribbon feed bracket and ratchet - (late design)	30		
Ribbon feed drive arm	28		




Figure 1 - 37 Typing Unit (Late Design)

CONTENTS	PAGE
LUBRICATION AREAS —	
RIGHT SIDE	31
Printing drive arm and link	35
Ribbon feed bracket and ratchet - (early design)	32
Ribbon feed bracket and ratchet - (late design)	33
Selector cam lubricator and marking locklever	40
Selector cams and clutch	38
Selector levers	38
Selector range finder and levers	39
Shiftbars and shift levers	36
Transfer levers	37
Vertical positioning rack	34
3. VARIABLE FEATURES	40
LUBRICATION AREA — BOTTOM	40
Horizontal tabulator cam and levers	41
LUBRICATION AREA — FRONT	41
Horizontal tabulator stops and pawls	42
LUBRICATION AREA —	
LEFT SIDE	43
Vertical tabulation and form-out gears and levers	43
LUBRICATION AREA — REAR	44
Paper-out alarm switch (sprocket feed)	44

1. GENERAL

1.01 This section provides lubrication procedures for the late design 37 typing unit (Figure 1). For similar information about the early design 37 typing unit, refer to Section 574-320-701TC.

1.02 Lubrication of the 37 typing unit is presented by areas with the procedures arranged counterclockwise around the typing unit. Following the procedures in this manner minimizes shifting and handling of the unit.

1.03 Figures are used to show the lubrication areas. Paragraph numbers on the figures refer to the lubrication points. References made to front, bottom, rear, left, or right apply to the typing unit in its normal position as shown in 2.01.

1.04 Lubricate the 37 typing unit before placing it in service and just prior to putting it in storage. The mechanism of the typing unit should be relubricated after 200 hours of operation or four weeks, whichever comes first. Thereafter, lubricate all mechanisms of the typing unit according to the following schedule:

- 100 wpm 2000 hours or 9 months*
- 150 wpm 1500 hours or 6 months*

*Whichever occurs first.

CAUTION: DISCONNECT ALL AC POWER CORDS BEFORE PERFORMING ANY PROCEDURE.

1.05 The general lubrication requirements consist of oil locations on hollow shafts, oil cups, felt washers, and in most locations where parts rub or move with respect to each other. Grease should be used on gears, rollers, points of heavy pressure, and some ball bearings. Lubrication areas for the typing unit are outlined as follows.

Pivot points require two or three drops of oil.

Coil springs require one drop of oil for each end and one to two drops on the coil.

Felt washers are saturated with oil.

Cams and sliding surfaces require a film of oil.

Note: Refer to the appropriate section for ordering information on lubricants. A list of maintenance tools can be found in Section 570-005-800TC.

1.06 Oil should be applied by means of an oiler to points where it will adhere or where pressure is nominal. In lubricating small parts, a minimum amount of oil should be applied so that the oil remains on the part and does not run off. Excessive lubricants should be removed with a dry lint-free cloth. Keep all electrical contacts free of oil or grease. If the surface between the selector relay armature and magnet

pole piece have oil or foreign matter, proceed as follows.

1. Place a piece of clean paper between the armature and pole piece.
2. Energize the magnet.
3. Pull the paper through the armature and pole piece and check to insure that lint or pieces of paper do not remain.

Note: Closed ball bearings do not require lubrication. All open ball bearings should be packed with grease (KS7471).

1.07 Symbols O1, O2, O3, etc, refer to 1, 2, 3, etc, drops of oil. The following list of symbols apply to the lubrication instructions:

- O Oil KS7470
- G Grease KS7471
- D Keep dry, no lubricant permitted.

1.08 Over lubrication which would allow oil to drip or grease to be thrown on other parts should be avoided. Capillary action and vaporization tend to keep a thin film of oil on the mechanisms. This prevents rust and provides sufficient lubrication to many points.


Note: Maintenance pad TP124828 is available to protect furniture and floor coverings from oil, grease, and dirt while lubricating the unit.

1.09 When replacing lubricating wicks or felt oilers, proceed as follows.


1. Thoroughly saturate with oil.
2. Remove all excess oil by pressing oiler or wick between a clean cloth.
3. Place the saturated wick or felt oiler in its proper position on the mechanism.

2. BASIC UNIT


LUBRICATION AREAS — FRONT



2.01 Platen Pressure Bail (Friction Feed)



2.02 Typebox




(Left Front View)

O1 Contact Surface Typebox Carriage Latch

O2 Pivot Typebox Carriage Latch

O1 Bearing Roller




(Right Front View)

O1 Bearing Rollers (Each End)

O1 Pivot Point Typebox Carriage Link


2.03 Print Hammer and Levers



(Left Front View)

- | | | |
|----|--------------------------------|--------------------|
| O | Thin Film on Engaging Surface | Plunger |
| O | Thin Film on Engaging Surface | Spring Tension |
| O3 | Pivot | Lever |
| O | Thin Film on Engaging Surface | Print Hammer |
| O1 | Hooks (Each End) | Springs (2) |
| O3 | Pivot | Print Hammer |
| O | Thin Film | Rail |
| O | Thin Film on Engaging Surfaces | Accelerating Lever |
| O3 | Pivot | |
| O | Thin Film on Engaging Surface | Latchlever |
| O3 | Pivot | Latchlever |


2.04 Print Hammer Carriage



(Top View)


- | | | |
|---|----------------------|--------|
| O | Saturate Felt Oilers | Roller |
|---|----------------------|--------|

2.05 Print Hammer Carriage (continued)




- | | | |
|----|--------------------------------|----------------------------|
| O2 | Bearings | Rollers (2) |
| O | Thin Film on Engaging Surfaces | Carriage Frame and Bracket |
| O | Saturate Felt Oilers | Print Hammer Shaft |
| O2 | Bearings | Rollers (2) |

2.06 Codebars



- | | | |
|----|---|----------|
| O | Thin Film on Guide Slots (Right, Center, and Left — 9 Bars) | Codebars |
| O1 | Hooks (Each End) | Spring |

2.07 Oscillating Rail



Thin Film on Engaging Surfaces


Oscillating Rail and Typebox Rail

Saturate Felt Oilers (2)

Pulleys (Left and Right Sides)

(Left Front View)

2.08 Local Line Feed Lever




Pivot Points

Local Line Feed Lever

(Front View)


2.09 Spring Drum



(Front View)

- | | | |
|----|------------------------------------|---------------------------|
| O | Saturate Felt Oilers | Left and Right Pulleys |
| O1 | Cable Grooves | Spring Drum |
| O | Thin Film Between Layers | Carriage Return Spring |
| G | Thin Coat on Camming Surface | Margin Indicator Cam Disc |
| O3 | Bearing (Outer and Inner) | Spring Drum Shaft |
| O | Saturate Felt Oilers (Behind Drum) | |


2.10 Horizontal Detent (Located Behind Spring Drum)




(Front View)

- | | | |
|----|-----------------------|------------------------|
| O | Saturate Felt Oilers | Oscillating Arm |
| O | Thin Film on Shaft | Pinion Gear |
| G | Thin Film on Detent | Horizontal Detent Disc |
| G | Thick Coat on Teeth | Pinion Gear |
| G | Thick Coat on Bearing | Detent Roller |
| O | Saturate Felt Oiler | Horizontal Detent Arm |
| O1 | Hooks (Each End) | Horizontal Detent Arm |


2.11 Horizontal Clutches, Gears, Levers, and Links



2.12 Carriage Return and Backspace Levers




2.13 Backspace Bail, Lever, Link, and Pawl (Located Behind Spacing Drum)




(Front View)

2.14 Spacing Drum



(Front View)


- | | | |
|----|---------------------------------------|-----------------------|
| O1 | Engaging Surface | Spacing Feed
Pawls |
| G | Thin Coat on
Teeth | Ratchet |
| O2 | Pivot Point
Saturate
Felt Oiler | Spacing Drum
Shaft |
| O | Thin Film on
Cable Grooves | Spacing Drum |
| O1 | Hooks (Each End) | Springs |
| O2 | Pawls | Spacing Eccentric |




(Front View)

- | | | |
|----|------------------------------------|--------------------------------|
| O1 | Pivot Points | Local Carriage
Return Lever |
| O | Thin Film on
Contacting Surface | Feed Pawl,
Release Link |
| O1 | Pivot Points | Feed Pawl,
Release Link |
| O1 | Engaging Surfaces | Feed Pawl
Release Link |
| O1 | Hooks (Each End) | Spring |
| O | Thin Film on
Contacting Surface | Carriage Return
Latch Bail |
| O1 | Bearing Surface | Roller |
| O | Thin Film on
Engaging Surface | Transfer Slide |
| O3 | Pivot Point | Carriage Return
Latch Bail |

LUBRICATION AREAS — BOTTOM




2.15 Main Shaft Clutches and Gears



(Bottom View)


- G Pack Ball Bearing
- G Main Shaft Bearing
- G Thick Coat on Teeth
- O1 Main Shaft Gears (3)
- O Internal Mechanism Saturate Felt Wick
- O Clutch Assembly
- O Thin Film on Camming Surface
- O Clutch Disc




(Bottom View)

- O Thin Film on Camming Surfaces
- O Clutch Discs and Eccentric Cams
- G Pack Ball Bearing
- G Main Shaft Bearing
- G Thick Coat on Teeth
- O1 Main Shaft Gear
- O Internal Mechanism Saturate Felt Wick
- O Clutch Assemblies


2.16 Trip Shaft Cam and Levers



2.17 Reset Bail and Shaft




2.18 Local Line Feed Trip Lever




(Left Side View)

2.19 Vertical Detent





(Left Side View)

2.20 Line Feed Bail, Levers, and Gears




(Right Side View)

LUBRICATION AREAS — REAR




2.21 Platen Shaft and Rollers (Friction Feed)



(Right Side View)

- | | | |
|----|--------------------------------|--|
| O2 | Pivots | Paper Finger Shaft |
| O1 | Hooks (Each End) | Springs (2) |
| O1 | Bearing Surfaces (Each End) | Platen Shaft |
| O1 | Pivots | Pressure Rollers (Wipe Off Excess Oil) |
| O | Thin Film on Engaging Surfaces | Pressure Rollers |
| O | Thin Film on Engaging Surface | Compression Springs (2) |


2.22 Paper Straightener (Friction Feed)




(Right Side View)

- | | | |
|----|-----------------------------|-------------------------------|
| O1 | Bearing Surfaces (Each End) | Paper Straightener Shaft (2) |
| O2 | Pivots (Each End) | Paper Straightener Levers (2) |
| O1 | Hooks (Each End) | Springs (2) |


2.23 Paper Release (Friction Feed)



2.24 Paper Guide Bracket Shaft and Latch (Sprocket Feed)



2.25 Platen Hubs and Pins (Sprocket Feed)




Note: See the disassembly and reassembly instructions given in the appropriate section before attempting to disassemble the platen hub.

G Thin Coat on Sprocket Pins
Contacting Surface
(11 Places,
Left and
Right Hubs)

Note: Do not pack notch of sprocket pins with grease.

G Thick Coat on Platen Hub
Cavity
(11 Places,
Left and
Right Hubs)


2.26 Trip Shaft Bearings and Springs



Hooks
(Each End)

Springs

2.27 Function Stripper Blade



Bearings

Trip Shaft

Bearings

Drive Shaft

Bearing
Surface
(Each End)


Stripper Blade
Drive Arm

Thick Coat on
Edge of
Engaging
Surfaces
(Each End)

Drive Arm
(Each End)

Thin Film on
Engaging
Surfaces

Stripper Blade



Saturate
Felt Oilers

Drive Link
(Each End)

Pivot

Cam Follower
Arm

Pack
Bearings

Cam Follower


Thin Film on
Engaging
Surfaces

Stripper Blade
Cam

(Rear View)

SECTION 574-320-704TC

2.28 Suppression Function Lever




(Top View)

Thin Film on Engaging Surfaces

Suppression Function Lever

2.29 Function Bar and Pawl



(Right Side View)

Thin Film on Engaging Surfaces

Function Bar, Lever, and Pawl

Note: Contact clips and arms on function switches must be kept dry.


Hooks (Each End)

Springs


Engaging Surfaces

Function Bar


2.30 Single-Double Line Feed Lever




2.31 Line Feed Bars



LUBRICATION AREAS — LEFT SIDE




32 Retraction Slide and Pawls



(Right Side View)

2.33 Vertical Linkage, Shafts, and Slides




(Left Side View)

O2 Bearing Surfaces Trip Linkage

O Thin Film on Sliding Surfaces Clutch Trip Slides (3)

O1 Bearing Driven Gear Shaft

2.34 Vertical Clutches, Gears, and Bell Cranks



(Right Front View)

O Thin Film on Pivots Guide Positioning Trip Levers, Codebar Bell Cranks

O Bearing Surface Output Bearing

O1 Hooks (Each End) Springs (13)


G Thick Coat on Teeth Gears (7)

O Thin Film on Camming Surface Clutch Discs (3)

O1 Internal Mechanism Saturate Felt Wick Clutch Assembly (3)

O2 Track Surface Track

2.35 Codebar Detent




(Left Side View)

Bearings and
Compression
Springs

Codebar
Detents

2.36 Vertical Positioning Rack




Saturate
Felt Oiler

Spacer
Guide

Thin Film
on Engaging
Surface

Spacer
Upper Rack
Guide




(Left Side View)

Thick Coat on
Teeth, Engaging
Surfaces, and
Bearings


Lower Rack
Guide Arm,
Pinion, and
Drive Shaft
Bearings

2.37 Line Feed Gears




(Left Side View)

2.38 Ribbon Feed Drive Arm




(Left Side View)

2.39 Ribbon Feed Bracket and Ratchet — Early Design




(Left Side View)




(Top View, Left Side)

2.40 Ribbon Feed Bracket and Ratchet - Late Design




(Top Left View)




(Left Side View)


LUBRICATION AREAS — RIGHT SIDE



2.41 Ribbon Feed Bracket and Ratchet — Early Design




(Right Side View)




(Top Right View)

2.42 Ribbon Feed Bracket and Ratchet - Late Design




(Top Right View)



(Right Side View)

2.43 Vertical Positioning Rack



(Right Front View)

Thin Film on Engaging Surfaces

Upper Rack Guide


Thick Coat on Teeth, Engaging Surfaces, Bearings

Lower Rack Guide Arm, Pinion, Drive Shaft Bearings

Saturate Felt Oiler


Drive Shaft

2.44 Printing Drive Arm and Link




(Right Front View)

2.45 Shiftbars and Shift Levers




(Right Front View)

2.46 Transfer Levers



(Right Front View)


2.47 Selector Levers



(Right Front View)

- | | | |
|----|------------------------|--|
| O1 | Hooks
(Each End) | Springs (11) |
| O1 | Engaging
Surfaces | Push Levers |
| O1 | Guide Slots | Start and Locklevers,
Selector and Push
Levers |
| O1 | Hooks
(Each End) | Springs (10) |
| O2 | Bearing
Guide Slots | Push and Selector
Lever Guide
Bearings |


2.48 Selector Cams and Clutch



(Right Front View)


- | | | |
|----|--|-------------------|
| O | Saturate
Felt Oiler | Selector Camshaft |
| O1 | Camming
Surface | Clutch Disc |
| O1 | Internal
Mechanism
Saturate
Felt Wick | Selector Clutch |
| O1 | Camming
Surface
(Each Cam) | Selector Cams |

2.49 Selector Range Finder and Levers



(Right Side View)


2.50 Selector Cam Lubricator and Marking Locklever




(Right Side View)

3. VARIABLE FEATURES

LUBRICATION AREA — BOTTOM




3.01 Horizontal Tabulator Cam and Levers




(Right Side View)

LUBRICATION AREA — FRONT




3.02

3.02 Horizontal Tabulator Stops and Pawls




LUBRICATION AREA — LEFT SIDE




3.03

3.03 Vertical Tabulation and Form-Out Gears and Levers




(Left Side View)

LUBRICATION AREA — REAR



(Sprocket Feed)

3.04 Paper-Out Alarm Switch (Sprocket Feed)



37 TYPING UNIT
DISASSEMBLY AND REASSEMBLY

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL	1	ON-LINE CONTROL OF TAB-STOP POSITIONS FOR VERTICAL TABULATION MECHANISM	15
2. SUBASSEMBLIES	3	VERTICAL TABULATION MECHANISM	16
TYPEBOX	3		
TYPEBOX CARRIAGE	4	1. GENERAL	
RIBBON FEED MECHANISM	4	1.01 This section describes the procedures for the disassembly and reassembly of the principal sub- assemblies which comprise the late design Model 37 Typing Unit (Figure 1).	
PRINT HAMMER CARRIAGE	5	1.02 Photographs and line drawings are used to identify mechanisms and specific parts. Refer to parts Section 574-320-801TC for exploded views, for detailed disassembly and reassembly illustrations, and for identifying parts.	
FRONT PLATE ASSEMBLY	5	1.03 Refer to maintenance tools Section 570-005-800TC for information on tools necessary to perform the disassembly and reassembly procedures.	
HORIZONTAL POSITIONING MECHANISM	7		
FUNCTION BOX	7		
VERTICAL POSITIONING MECHANISM	9		
CODEBAR ASSEMBLY	9		
SELECTOR CAM SLEEVE ASSEMBLY AND CLUTCH	10		
SELECTOR ASSEMBLY	10		
MAIN SHAFT ASSEMBLY	10		
CODEBAR POSITIONING MECHANISM	12		
PLATEN	12		
TRIP SHAFT ASSEMBLY	12		
SPACING CABLE	14		
COORDINATING CABLE	14		
SPRINGS OR CONTACT ARMS IN SWITCH ASSEMBLY	14		




Figure 1 - 37 Typing Unit

SECTION 574-320-705TC

1.04 Use maintenance pad TP124828 to protect furniture and floor coverings from oil, grease, and dirt, during the disassembly and reassembly of the typing unit.

1.05 After disassembly and reassembly of certain mechanisms, specific adjustments must be rechecked. These adjustments are listed in appropriate paragraphs in the text. See Section 574-320-703TC for all adjustment requirements to insure that the unit is operating properly.

1.06 Lubricate the typing unit according to lubrication Section 574-320-704TC, before placing unit back in service. Make a visual inspection of the unit for general lubrication requirements. Check oil locations on felt washers, oil cups, and in locations where parts rub or move with respect to each other. Apply grease to gears, rollers, points of heavy pressure, and on some ball bearings.

1.07 If a part is mounted on shims, the number of shims used at each mounting screw must be noted; when the part is remounted, the same shim pile-up must be used.

1.08 Retaining rings are made of spring steel and have a tendency to release suddenly on removal. To minimize loss of these retainers, use the following removal procedures.

- (1) Hold the retainer in one hand to prevent it from rotating.
- (2) Place the blade of a screwdriver in one of the slots of the retainer.
- (3) Rotate the screwdriver in a direction to increase the diameter of the retainer, allowing easy removal of the retainer.




Figure 2 - 37 Typing Unit (Friction Feed)

1.09 Avoid loss of springs in disassembly by holding one spring loop with one hand while gently removing the opposite loop with a spring hook. Do not stretch or distort springs.

1.10 Reference in the procedures to left or right, up or down, top or bottom, etc, refer to the unit as viewed facing the front plate assembly (Figures 1 and 2).

CAUTION: DISCONNECT POWER BEFORE REMOVING THE TYPING UNIT FROM THE KEYBOARD AND BASE ASSEMBLY.

2. SUBASSEMBLIES

2.01 In removing a subassembly from the unit, the procedure followed and the location from where the part is removed must be carefully noted, so that proper reassembly can be accomplished. For reassembly, reverse the procedure used in removing the subassembly, except when different instructions are stated.

TYPEBOX

2.02 To remove the typebox from the carriage (Figure 3), trip the typebox latch toggle to the right. Lift the right end of the typebox up to an angle of 45 degrees, and pull the typebox toward the right to disengage it from the left hand bearing stud.

CAUTION: DO NOT OPERATE TYPING UNIT WITH TYPEBOX REMOVED, UNLESS TYPEBOX LATCH TOGGLE IS CAMMED OVER THE TYPEBOX CARRIAGE.

Typebox Disassembly

2.03 If it is necessary to replace the pallet or pallet spring TP157238, the typebox must be disassembled (Figure 3). The method used is as follows.

- (1) Remove both screws and nuts that secure the front plate to the rear plate assembly. Separate the two plates and the typebox cover TP326183.




Figure 3 - Typebox, Typebox Carriage and Oscillating Rail

(2) To remove the pallet spring TP157238 from the pallet, compress the pallet spring slightly and pull the formed-end (hooked-end) out of the slot in the pallet.

(3) Remove the pallet from the typebox.

Note: Discard the pallet spring TP157238 once it has been removed.

(4) Replace the pallet (raised mark indicates top of pallet).

(5) Install a new pallet spring; make certain that the formed-end (hooked-end) of the pallet spring extends through the slot in the pallet and hooks onto the other side.

Typebox Reassembly

2.04 After replacing the pallet or pallet spring TP157238, the typebox must be reassembled (Figure 3). The method used is as follows.

(1) Line up the front plate with the rear plate assembly and draw the two plates together until the head of the pallet leaves the rear plate by 1/16 inch. Use two 6-40 screws (11/32-inch long) and nuts, in place of the two screws and nuts removed in 2.03(1) and tighten them only enough to hold the pallets as specified above. Do not clamp the plates together until all the pallets have been moved into their correct position.

(2) Manipulate the pallets until they fall into their respective openings in the front plate. Press the plates together.

(3) Replace the aligning screws and nuts used in 2.04(1) with the mounting screws and nuts removed in 2.03(1). Rebuilt typeboxes must be dipped in KS7470 oil; all excess oil must be drained before installing.

2.05 To replace the typebox (Figure 3), reverse the procedure used for removal.

CAUTION: TO AVOID SPRINGING THE TYPEBOX LATCH, THE TYPEBOX SHOULD BE FIRMLY SEATED ON THE BEARING STUDS AND THE POINT OF THE LATCH TOGGLE SHOULD BE PLACED IN THE NOTCH OF THE TYPEBOX PLATE BEFORE MOVING THE TOGGLE TO ITS LATCHED POSITION.

TYPEBOX CARRIAGE

2.06 To remove the typebox carriage from the unit proceed as follows (Figure 3).

(1) Set all codebars to the marking position and turn the main shaft until the typebox is in the uppermost position.

(2) Remove the shoulder screw, lockwasher, and nut which are used to connect the oscillating rail slide to the typebox arm.

(3) Loosen the screw, which mounts the upper left ball bearing roller, and slide it upward in its slots; then remove the carriage from the track.

2.07 To replace the typebox carriage (Figure 3), reverse the procedure used for removal. Check Carriage Roller adjustment.

RIBBON FEED MECHANISM

2.08 To remove the ribbon feed mechanism (Figure 2) from the unit – left side, proceed as follows.

(1) Remove the two ribbon spools from the ribbon feed mechanism.

(2) Loosen the ribbon feed drive arm clampscrew on the left side.

(3) Remove one locknut and sleeve from the left blocking lever and connecting rod connection.

(4) Remove the left ribbon bracket mounting screws and lift assembly.

2.09 To replace the ribbon feed mechanism – left side (Figure 2), reverse the procedure used in removal. Check the following adjustments:

(a) Ribbon Feed Main Brackets Left and Right

(b) Ribbon Feed Lever Left and Right

(c) Ribbon Reversing Connecting Rod

2.10 To remove the ribbon feed mechanism from the unit – right side (Figure 2), remove the retaining ring from the post on the drive arm. Remove one locknut and sleeve from the right blocking lever and connecting rod connection.

Note: If the left ribbon mechanism has been removed, it is not necessary to remove the locknut and sleeve from the right blocking lever and connecting rod connection.

Remove the right ribbon bracket mounting screws and lift assembly from unit.

2.11 To replace the ribbon feed mechanism — right side (Figure 2), reverse the procedure used in removal. Check Ribbon Reversing Connecting Rod adjustment.

PRINT HAMMER CARRIAGE

2.12 To remove the print hammer carriage from the unit (Figure 2), proceed as follows.

- (1) Remove the two screws which mount the ribbon positioning bracket to the print hammer carriage; the bracket does not have to be removed from the unit. Loosen the print hammer carriage cable clampscrew and disconnect the cable; remove the left ribbon feed mechanism as described in 2.08.
- (2) Remove the right ribbon bracket mounting screws. Take off the retaining ring from the print hammer lower drive arm and link connection. Separate the link and arm. Loosen the coordinating cable spring adjustment arm clamp nut to reduce tension on the pulleys. Also reduce carriage return spring tension to a minimum by loosening the nut on the front of the spring drum bearing post and then operating the ratchet escape lever. Remove the four print carriage guideplate mounting screws and then remove the guideplate. The left bearing bracket is now removed, and the print carriage is removed from the square shaft.

2.13 To replace the print hammer carriage (Figure 2), reverse the procedure used in removal. Check the following adjustments:

- (a) Carriage Return Spring
- (b) Coordinating Cable Spring Tension and Equalization
- (c) Vertical Print Hammer Alignment
- (d) Print Hammer Latch
- (e) Print Hammer Position
- (f) Spacing Rope Alignment
- (g) Print Point Indicator
- (h) Pointer Clearance
- (i) Ribbon Feed Main Brackets Left and Right
- (j) Ribbon Feed Lever Left and Right
- (k) Ribbon Guide Alignment.

FRONT PLATE ASSEMBLY

2.14 To remove the front plate assembly from the unit, proceed as follows (Figures 2, 4, 5, and 6).

- (1) Set all codebars to the marking position and turn the main shaft until the typebox is in the upper most position. Remove the shoulder screw, lockwasher, and nut used to connect the oscillating rail slide to the typebox arm. Remove the two screws used to mount the ribbon positioning bracket to the print hammer carriage; the bracket does not have to be removed from the unit. Take off the retaining ring from the print hammer lower drive arm and link connection. Separate the link and arm. Disconnect the line feed cable at the back of the unit by loosening the screw at the end of the line feed clutch trip support post and remove bracket and lever (Figure 5).
- (2) Loosen the screw (under the printer) used to mount the print hammer lower drive shaft bearing clamp (Figure 4); rotate clamp to the left side. Center the bearing under the clamp when replacing the clamp. Remove the horizontal dampener spring TP78823, located at the lower left hand corner of the front plate (Figure 6).
- (3) If the unit has horizontal tab-stop control, disconnect the horizontal control cables from the function levers in slots 15 and 16. Loosen the cable clamp on the codebar assembly and slip the cables from under the cable clamp. When the unit is equipped with horizontal tab-stop control, remove the horizontal tab connecting link; also remove the retaining ring which connects the link to the horizontal tab arm. Remove the four front plate mounting screws and remove the front plate.

2.15 To replace the front plate assembly (Figures 2, 4, 5, and 6), reverse the procedure used in removal. The carriage return lever must be in the slot in the carriage return link assembly. The horizontal positioning slide trip levers must be connected to their respective codebars.

Note: Make sure the horizontal dampener spring TP78823 has been replaced.

Before tightening the plate mounting screws, there must be some backlash in the horizontal drive gears and in the spacing drive gears. Check the following adjustments:

- (a) Ribbon Guide Alignment
- (b) Spacing Gear Phasing.




Figure 4 - Bottom Section of Unit Used in Connection With Front Plate Assembly Removal





Figure 5 - Rear Section of Unit Used in Connection With Front Plate Assembly Removal



HORIZONTAL DAMPENING SPRING
(Front View)

Figure 6 - Horizontal Detent Dampening Assembly

HORIZONTAL POSITIONING MECHANISM

2.16 To remove the horizontal positioning mechanism (Figure 2) from the unit, proceed as follows.

- (1) Remove the front plate assembly as described in 2.14. Loosen the coordinating cable spring adjustment arm clamp nut to reduce tension on the pulleys. To reduce carriage return spring tension to a minimum, loosen the nut on the front of the spring drum bearing post and then operate the ratchet escape lever.
- (2) Check and RECORD Ribbon Feed Main Brackets Left and Right adjustment. Remove the four print hammer carriage guideplate screws to release the guideplate. Remove the screw used to connect the aggregate motion output bail to the oscillating rail. Remove the screws from the three aggregate motion drive shaft gears and remove the shaft.

Note: Thrust washers and bearing with sleeve can remain on the shaft.

- (3) Remove the eight nuts from the back and front ends of the clutch shafts. Unhook the clutch latch springs. Take off the two springs from the aggregate linkage. Remove the auxiliary plate by removing the four front auxiliary plate mounting screws. Remove the two idler gears from the clutch shafts. Check gears on the clutch drums. Remove the horizontal positioning mechanism from the front plate.

2.17 To replace the horizontal positioning mechanism (Figure 2), reverse the procedure used in removal. Make sure that the third idler gear is placed in position before mounting the horizontal positioning mechanism to the front plate. Remount print carriage guideplate; then set Ribbon Feed Main Brackets Left and Right adjustment to setting, recorded in 2.16(2), by moving the print carriage guide up or down. Check the following adjustments:

- (a) Aggregate - Dampener Synchronization
- (b) Carriage Return Spring
- (c) Coordinating Cable Spring Tension and Equalization
- (d) Ribbon Guide Alignment

FUNCTION BOX

2.18 To remove the function box from the unit, proceed as follows (Figures 7 and 8). (On units with sprocket feed, remove the paper tray.) Remove the connector mounting screws and feed connector through the side frame.

Note 1: Do not remove connector TP161238 if complete separation of function box from unit is not intended.

When the unit is equipped with horizontal and/or vertical tab-stop control, disconnect control cables from function levers in slots 15 and 16 and in slots 39 and 40. From the stripper blade drive mechanism, take off the two retaining rings, felt washers, and link. Remove the two mounting screws from the rear of the function box side plates. Remove one screw used to mount the function box brace to the trip shaft casting. Remove the function box from the unit.

Note 2: When removing function box, hold the line feed clutch trip lever in the tripped position to prevent the function box from catching on the trip arm.

Function Bar Removal

2.19 After removal of the function box (Figure 8), the function bar is removed by the following method.

- (1) Unhook the function bar spring from the function bar.




Figure 7 - Function Box and Trip Shaft Assembly Mounted in Typing Unit




Figure 8 - Function Box

- (2) Hold the function bar toward the rear of the function box and disengage the function pawl from the function bar.
- (3) Pull the function bar toward the front to remove the function bar from the function box.

Function Bar Replacement

- 2.20 Reverse the procedure used in removal (Figure 8) in 2.19.
- 2.21 To replace the function box, reverse the procedure used in removal (Figures 7 and 8).
- (1) During installation of the function box, the function clutch should be tripped and the main shaft rotated until the reset blade is toward the front of the unit. The shift forks must be in line with their respective posts on the codebar mechanism. Push the function box forward on its guide rails to 1/8 inch of its final position. Next manually disengage the function pawls from their function bars and push the function box into its final position.
 - (2) If the unit has horizontal and/or vertical tab-stop control, the bottom of the function levers in slots 17 and 41 must be inserted into the slot in their respective slides. To do this, raise the function lever to its maximum uppermost position, and push the function lever forward until it drops into the slot in the slide.

VERTICAL POSITIONING MECHANISM

2.22 To remove the vertical positioning mechanism from the unit (Figure 9), remove the retaining ring from the retraction reset arm post. Remove the screw from the upper right hand corner of the vertical positioning rear mounting plate. Remove the nuts from the bottom two posts on the inside of the left side frame. Now remove the mechanism from the unit. Notice the position of the loose gear and coupling assembly from the rear of the mechanism.

2.23 To replace the vertical positioning mechanism (Figure 9), set all codebars in the marking position. Rotate the main shaft so that the male portion of the coupling on the end of the main shaft is in the vertical position. Check that the gear and coupling on the back of the mechanism are in place and in position to line up with the main shaft coupling. Place vertical slides in the downward position and rotate clutches until aggregate is in the uppermost position. Also check that the racks and typebox rail are in the uppermost position. Replace the mechanism.

CODEBAR ASSEMBLY


2.24 To remove the codebar assembly from the unit, proceed as follows.

- (1) Remove the front plate assembly as in 2.14. Remove the two mounting screws from the rear of the function box side plates. Remove one screw used to

VERTICAL TABULATION
MECHANISM

ON-LINE CONTROL
OF TAB-STOP POSITIONS
FOR VERTICAL
TABULATION MECHANISM

VERTICAL
POSITIONING
MECHANISM



(Left Side View)

Figure 9 - Interrelated Positions of Three Vertical Movement Mechanisms

mount the function box brace to the trip shaft casting. Pull the function box toward the rear of the unit to take the pressure of the function bars off of the codebars.

(2) Remove one screw and loosen the other screw that mount the codebar shiftbar guideplate. Remove the two screws on either side frame used to mount the codebar guide castings.

(3) Pull the codebar shiftbars forward and to the right, to allow the codebar assembly to pass by the codebar shiftbars.

2.25 To replace the codebar assembly, reverse the procedure used in removal. If either tie bar mounting screw is loose, make sure both are loosened friction tight before mounting codebar assembly. Replace and tighten the four screws mounting the codebar assembly. Tighten the tie bar mounting screws. Replace the function box as described in 2.21. Replace the front plate assembly as described in 2.15.

SELECTOR CAM SLEEVE ASSEMBLY AND CLUTCH

2.26 To remove selector cam sleeve assembly and clutch from unit, remove selector clutch drum mounting nut, screw, and washers. Remove the selector clutch and cam sleeve assembly.

Note: Perform the following operations to insure easy removal of the cam sleeve assembly.

(1) Latch the pushlever reset bail up and out of the way on the notch (maintenance step) provided in the lever guide slot.

(2) Push the mark locklever to the left and insert a pin in the hole provided on the lever extension, so that the lever (and consequently the selecting levers) is held away from the cam by the mark locklever guide bracket.

(3) Hold the space locklever and start lever to the left. Hold lifter lever down. Slip the selector cam sleeve assembly off the shaft, at the same time rotating the assembly counterclockwise.

2.27 To replace the selector cam sleeve assembly and clutch, reverse the procedure used in removal, but rotate the selector cam sleeve assembly counterclockwise. To insure easy replacement when the sleeve is almost in place, pull the trip lever arm and selector clutch latchlever away from their respective cams.

SELECTOR ASSEMBLY

2.28 To remove the selector assembly from the unit, proceed as follows (Figure 10).

(1) Remove the selector cam sleeve assembly and clutch as in 2.26. Next remove the screw that secures the selector assembly to the intermediate bracket on the code positioning mechanism.

(2) Remove the retract arm cam follower spring TP90260 from the cam follower. Disconnect the cam follower arm from the retract oscillating shaft.

(3) Remove the three remaining selector assembly mounting nuts and lift the selector assembly from the main shaft bearing housing.


2.29 To replace the selector assembly (Figure 10), reverse the procedure used in removal. Replace the selector cam sleeve assembly and clutch as in 2.27. Check the following adjustments:

- (a) Selector Magnet Bracket
- (b) Intermediate Arm Latch Bail
- (c) Intermediate Arm Back Stop Bracket

MAIN SHAFT ASSEMBLY

2.30 To remove the main shaft assembly from the unit, proceed as follows (Figures 11 and 12).

(1) Remove the selector cam sleeve assembly and clutch as in 2.26. Remove the vertical positioning mechanism as in 2.22.



SELECTOR ASSEMBLY

(Right Lower Side View)

Figure 10 - Selector Assembly Mounted in Typing Unit

- (2) Next engage all clutches; then remove all main shaft clutch drum mounting screws. From the selector end of the main shaft, remove screw and collar.
- (3) Remove the screws from the two collars at the center of the main shaft. Remove the main shaft drive gear mounting screw and loosen the two setscrews. Take out the screw from the bearing collar at the left end of the main shaft.
- (4) Take off the retaining ring used to connect the codebar shift lever link and separate the link and arm. Remove the retaining ring that connects the print hammer lower drive shaft arm to the square shaft drive links and separate the link and arm.
- (5) Take off the print hammer cam follower spring TP334339 and codebar positioning cam follower arms spring TP82861. Tap the right end of the shaft with the handle of a screwdriver or soft hammer, until

the shaft loosens up from the bearing in the right side frame.

- (6) Pull the shaft out of the left end of the unit, leaving the clutches in their plate. Remove all clutches that are required.

Note: When removing cams from clutches, note that the round circle stamped on the face of the cam should face toward the left end of the unit.

2.31 To replace the main shaft assembly (Figures 11 and 12), reverse the procedure used in removal. Do not disengage the clutch drum from the shoes when feeding the clutch onto the shaft. Replace the selector cam sleeve assembly and clutch as in 2.27. Replace the vertical positioning mechanism as in 2.23. Check the following adjustments:

- (a) Main Shaft Clutch Disc End Play
- (b) Line Feed Clutch Phasing




Figure 11 - Main Shaft Assembly Mounted in Typing Unit




Figure 12 - Main Shaft Assembly

CODEBAR POSITIONING MECHANISM

2.32 To remove the codebar positioning mechanism from the unit, proceed as follows (Figure 13).

- (1) Remove the front plate assembly as in 2.14. Remove the two range finder plate assembly mounting screws, nut, and washers; then remove the range finder plate assembly. Remove the retaining ring from the codebar positioning drive arm and shift lever drive link connection and separate link and arm.
- (2) Remove the three mounting screws: The one on the selector, codebar positioning drive shaft casting, and side frame flange.
- (3) Manipulate the transfer levers and codebar shiftbars, while gently twisting and sliding the mechanism off of the codebar shiftbars.

2.33 Replace the codebar positioning mechanism (Figure 13) by reversing the procedure used in removal, except push the shiftbars to the marking position (left/pushed in). Manipulate the shiftbars and transfer levers so that the shiftbars line up with their respective slots in the guide bracket and slide shiftbars one at a time through the slots. Replace the front plate assembly as described in 2.15.

PLATEN

2.34 To remove the platen from the unit (Figure 2), remove the platen bearing retainers. Remove the paper finger shaft (friction feed) or the guide bracket

(sprocket feed, Figure 14). Remove driving gear. Hold off the detent and lift the platen out of the side frame.

2.35 To replace the platen (Figure 2), reverse the procedure used in removal. First put in the retainer upper screw when replacing the platen bearing retainers. Leave the retainer upper screw slightly loose. Press the lower end of the retainer down and hook it into the elongated hole in the side frame. Replace the lower screw; tighten both screws.

TRIP SHAFT ASSEMBLY

2.36 To remove the trip shaft assembly from the unit, proceed as follows (Figure 7).

- (1) Remove the function box as in 2.18. Disconnect all springs from the spring bracket which is mounted on the trip shaft casting. Remove the two screws used to mount the spring bracket and remove the spring bracket. Loosen the print hammer clutch trip clamp mounting screw.
- (2) For units equipped with horizontal tab, remove the retaining ring used to connect the horizontal tab blocking slide. Remove the screw used to mount the horizontal tab arm to the horizontal tab bail. Remove the horizontal tab arm.
- (3) Loosen the two trip shaft bearing clamp plates and remove. Lift the trip shaft assembly up and out of the unit.




Figure 13 - Codebar Positioning Mechanism


2.37 To replace the trip shaft assembly (Figure 7), proceed as follows.

- (1) Reverse the procedure used in removal. Check function clutch trip parts for their proper position.
- (2) When installing the horizontal tab arm, make sure that the "C" shaped hole is fully seated on the raised portion of the horizontal tab bail.

(3) Before tightening the screws, align the bearing clamps over the center of the bearings. Check the following adjustments:

- (a) Function Clutch Trip Arm (requirement no. 2)
- (b) Printing Clutch Trip Lever

SPROCKET
FEED
MECHANISM



(Right Front View)

Figure 14 - 37 Typing Unit (Sprocket Feed)

SPACING CABLE

2.38 To remove the spacing cable (Figures 15 and 16) from the front plate, proceed as follows.

(1) Return the carriages to the left position. Unwind the carriage return spring by loosening the nut on the front of the spring drum bearing post and operate the ratchet escapement lever. Release the cable from the clamp on the printing carriage and also from the clamp on the oscillating rail slide. Remove the cable clamp-screw used to secure the spacing cable to the spring drum and remove the cable from the drum.

(2) When equipped with horizontal tab, remove the three screws used to mount the horizontal tab ring on the spacing drum; position the horizontal tab ring to allow access to cable mounting screws. Remove the cable mounting screws from the spacing drum used to secure the ends of the spacing cable; remove the spacing cable from the drum.

2.39 To replace the spacing cable (Figures 15 and 16), reverse the procedure used in removal. Check the following adjustments:

- (a) Carriage Return Spring
- (b) Right Hand Margin
- (c) Print Hammer Position
- (d) Spacing Rope Alignment
- (e) Left Hand Margin

COORDINATING CABLE

2.40 To remove the coordinating cable from the front plate, proceed as follows (Figures 15 and 16).

(1) Loosen the coordinating cable spring adjusting arm clamp unit. Unhook the coordinating cable spring from the cable eyelets.

(2) Loosen the cam plate mounting screw on the spring drum, and rotate the cam plate to gain access to the cable clamping screw if necessary.

(3) When equipped with horizontal tab, remove the three screws used to mount the horizontal tab ring on the spacing drum; position the horizontal tab ring to allow access to the cable mounting screw. Remove the two cable mounting screws used to secure the ends of the cable to the spacing drum. Remove the coordinating cable from the drum.

2.41 To replace the coordinating cable (Figures 15 and 16), reverse the procedure used in removal.

Note: Check that the short cable is connected to the spring drum.

Check the following adjustments:

- (a) Coordinating Cable Tension and Equalization
- (b) Margin Indicator Lamp

SPRINGS OR CONTACT ARMS IN SWITCH ASSEMBLY

2.42 To remove the springs or contact arms in the switch assembly, proceed as follows.

- (1) Remove the two screws and lockwashers used to secure the switch to the function box. Unsolder any connections to the terminal and spring. When unsoldering the cable to the contact spring and when lacing or routing cables, do not tug or pull on the

contact spring, because this will cause distortion to the spring.

- (2) Remove the top plate with spring and the contact arms. To remove the spring from the top plate, clean the solder from the spring and place the end of an orange stick on the shoulder of the spring and push downward.

2.43 To replace the contact spring, proceed as follows.

- (1) Place the loop end of the spring into the required position in the terminal plate. Hook a spring hook into the loop of the spring and pull the spring into position. Before mounting the contact plate on the switch block, check that the end of the spring is on top of the formed-over contact end.
- (2) Mount the terminal plate with spring and block-in the required location on the function box; replace screws and lockwashers. Resolder the cables to their respective locations. Insert the pointed end of the contact arm between the bent up end of the spring and

the formed end of the contact; the notch of the contact arm must be in the downward position. Push the arm into position, so that the notch is engaged. Check that the contact arm insulator is in alignment with the function lever. Loosen the screws and position the switch to meet this requirement.

- (3) Also check that there is some clearance between the contact arm and the vertical face of the clip. Check both contacts if the switch is a transfer type with contact on the front and rear.

ON-LINE CONTROL OF TAB-STOP POSITIONS FOR VERTICAL TABULATION MECHANISM

2.44 To remove the on-line control of tab-stop positions for vertical tabulation mechanism, proceed as follows (Figure 9).

- (1) Remove retaining rings from function lever in slots 39 and 40. Disconnect cable eyelets from post on function lever. Remove cables from guide brackets and




Figure 15 - Spring Drum and Cables




Figure 16 - Spacing Drum

feed out gradually through hole in left side frame, until inner cable can pass through small gap into large opening.

(2) Remove nut, lockwasher, and flat washer from lower post on vertical tabulator. Remove retaining ring from upper post on vertical tabulator. Remove the assembly from the unit.

2.45 To replace the on-line control of tab-stop positions for vertical tabulation mechanism (Figure 9), reverse the procedure used in removal. Check the following adjustments:

- (a) Mounting Plate
- (b) Tab Arm Spring Tension
- (c) Tab Set Arm
- (d) Tab Clear Arm
- (e) Latch
- (f) Latch Release
- (g) Latch Spring

VERTICAL TABULATION MECHANISM

2.46 To remove the vertical tabulation mechanism (Figure 9) from the unit, remove the three screws, flat washers, lockwashers, and spacers used to hold the mounting plate assembly to the left side frame. Remove the pointer which is located between the mounting plate and the flat washer on the top mounting screw. Remove the mounting plate. Take out the vertical tabulation mechanism.

2.47 To replace the vertical tabulation mechanism (Figure 9), reverse the procedure used in removal. Check the following adjustments:

- (a) Mounting Bracket
- (b) Form Gear Play
- (c) Tab Wheel
- (d) Pointer
- (e) Blocking Levers
- (f) Sensing Arm Spring Tension
- (g) Sensing Pawl Spring Tension
- (h) Tab Wheel Synchronization

37 KEYBOARD UNIT

LUBRICATION

CONTENTS	PAGE
1. GENERAL	1
2. BASIC UNIT	3
BASE MECHANISMS	12
Intermediate gear assembly	12
Margin indicator switch	12
CONTROL PANEL MECHANISM	11
Control panel	11
KEYBOARD MECHANISM	3
Codebar sets	3
Contact wires	7
Downstop bar	4
Keylevers	4
Spacebar and space bail	5
Trip arm lever	7
Universal codebar	6
RESET MECHANISMS	8
Auxiliary contact cam	8
Clutch	10
Clutch and stop arm shaft	9
Driven coupler and driving gear shaft	10
Main shaft and gears	9
Reset bail	10

mechanism. Following the procedures in this manner minimizes shifting and handling of the mechanisms.

1.03 Figures of each mechanism are used to show the lubrication area. The paragraph numbers on the figure refer to the specific lubrication points. References made to the front, top, rear, left, or right, apply to the keyboard unit in the position normally viewed by the operator.

1.04 Lubricate the keyboard unit before placing it in service and just prior to putting it in storage.

1.05 After approximately 200 hours or four weeks of operation (whichever comes first) relubricate the keyboard unit to make certain that no mechanisms have been missed. Thereafter, lubricate the mechanisms according to the following schedule:

100 wpm	2,000 hr or 9 mo*
150 wpm	1,500 hr or 6 mo*

* Whichever occurs first.

CAUTION: WHEN THE KEYBOARD UNIT IS FUNCTIONALLY UTILIZED, REMOVE POWER FROM EQUIPMENT BEFORE ANY LUBRICATION IS PERFORMED.

1. GENERAL

1.01 This section provides lubrication procedures for the late design, 11-contact 37 keyboard unit (Figure 1). It is reissued to incorporate engineering changes and comments which were received on Issue 1. Since only a limited distribution was made on Issue 1, marginal arrows have been omitted. Refer to Section 574-321-701TC for lubrication procedures for early design, 28-contact units.

1.02 Lubrication of the keyboard unit is presented by mechanisms with the procedures arranged counterclockwise around the




Figure 1 - 37 Keyboard Unit

SECTION 574-321-704TC

1.06 The following list of symbols applies to the specific lubrication instructions given in each paragraph:

SYMBOL

- D Keep dry, no lubricant permitted.
- O Oil with KS7470 oil as instructed.
- G Apply KS7471 grease.
- L Apply Lubriplate (TP108805).

Note: In general, the symbols indicate the type of lubricant. Quantity of lubricant is normally given with the text associated with specific lubrication instructions. An exception to this method is where the exact number of drops of oil is specified. For example, O1, O2, O3, etc refer to 1, 2, 3 etc drops of oil.

1.07 Oil should be applied by means of an oiler to points where it will adhere or where pressure is nominal. In lubricating small parts,

only a single drop of oil should be applied so that the oil remains on the part and does not run off.

Note: Excessive oil tends to creep onto contacts and wiring insulation where it has a harmful effect.


1.08 In general, oil should be used in such locations as hollow shafts, wicks, and in most locations where parts rub, slide, or move with respect to each other. Grease should be used on gear teeth and points of heavy pressure. Overlubrication which would allow oil to drip or grease to be thrown on other parts should be avoided. Capillary action and vaporization tend to keep a film of oil on the mechanisms. This prevents rust and provides sufficient lubrication to many points.

Note: Protective pad TP124828 is available to protect furniture and floor coverings from oil, grease, and dirt while lubricating the unit.


1.09 To remove the keyboard unit for lubrication, refer to Section 591-801-702TC.

2. BASIC UNIT

KEYBOARD MECHANISM




2.01 Codebar Sets




SECTION 574-321-704TC



2.02 Downstop Bar



2.03 Keylevers




2.04 Spacebar and Space Bail



SECTION 574-321-704TC

2.05 Universal Codebar



(Front View)

01 Pivots and Guide Surfaces


T-Levers

D Surfaces (Both Sides)

Codebar, Tie Link

01 Engaging Surface, Pivots, Hooks

Tie Link, T-Levers, Spring



(Front View)


01 Hooks, Pivots

Springs, Latchlever, Nonrepeat Lever

03 Engaging Surfaces

Latchlever, Nonrepeat Lever


2.06 Trip Arm Lever



- O1 Engaging Surface Trip Arm
- O3 Pivot, Engaging Surfaces Trip Arm Post, H-Plate (Right Side Only)
- O1 Hooks Spring

(Right Side View)

2.07 Contact Wires



- L Thin Coat on engaging surface on disassembly and reassembly of Contact Mechanism T-Levers


CAUTION: DO NOT CLEAN CONTACT BLOCK WITH ALCOHOL, MINERAL SPIRITS, OR OTHER SOLVENTS. DO NOT USE A BURNISHING TOOL TO CLEAN CONTACTS; ALWAYS CLEAN GOLD PLATED CONTACTS USING TWILL CLOTH.

- D Contact Surfaces Contact Wires, Springs
- L Pivot Terminal Contact Wires


(Right Front View)

SECTION 574-321-704TC


RESET MECHANISM



2.08 Auxiliary Contact Cam




2.09 Clutch and Stop Arm Shaft



- O1 Camming Surface Clutch Disc
- O3 Engaging Surfaces Clutch Shoe and Stop Arm
- O3 Bearing Surfaces Stop Arm Shaft

(Rear View)

2.10 Main Shaft and Gears




- O3 Bearing Surfaces, Oil Hole Main Shaft
- G Teeth, Thin Coat Driving and Driven Gears
- D Grommets (4) Stop Arm Shaft

(Rear View)

SECTION 574-321-704TC


2.11 Driven Coupler and Driving Gear Shaft



(Top View, Left End)

- | | | |
|----|--------------------------------|--------------------|
| O3 | Bearing Surfaces | Driving Gear Shaft |
| G | Thin Coat on Engaging Surfaces | Driven Coupler |


2.12 Reset Bail



(Top View, Right End)

- | | | |
|----|-------------------|--------------------------|
| O3 | Bearing Surface | Trip Arm Post |
| O3 | Engaging Surfaces | H-Plate |
| O3 | Bearing Surfaces | Reset Bail Roller |
| O3 | Bearing Surfaces | Reset Bail Bearing Shaft |
| O3 | Bearing Surfaces | Trip Roller |


2.13 Clutch



(Internal View)


- | | | |
|----|------------------------|---------------------|
| O1 | Camming Surface, Hooks | Clutch Disc, Spring |
| O3 | Surface, Wick | Internal Mechanism |

BASE MECHANISMS




(Left Front View)

2.15 Intermediate Gear Assembly



2.16 Margin Indicator Switch



37 KEYBOARD UNIT
DISASSEMBLY AND REASSEMBLY

CONTENTS	PAGE
1. GENERAL	1
2. DISASSEMBLY AND REASSEMBLY ..	1
CONTROL PANEL	1
KEYBOARD HOUSING AND COVER ..	2
KEYBOARD	2
RESET MECHANISM	4
INTERMEDIATE GEAR ASSEMBLY .	4

1. GENERAL

1.01 This section provides disassembly and reassembly information for the late design, 11-contact 37 keyboard unit (Figure 1). It is reissued to incorporate engineering changes and other comments received on Issue 1. Since only a limited distribution was made on Issue 1, marginal arrows have been omitted.

1.02 Photographs are used to identify the mechanisms and specific parts mentioned in the procedures. Refer to the appropriate parts section for drawings showing the location of all parts and mechanisms.

1.03 Refer to Section 570-005-800TC, Maintenance Tools, for information on the tools necessary to perform the disassembly and reassembly procedures.

1.04 References in the procedures to left or right, up or down, top or bottom, etc refer to the unit viewed with the keytops and controls facing the front (Figure 1).

CAUTION: REMOVE POWER BEFORE DISASSEMBLING THE UNIT.

1.05 Most maintenance, lubrication and adjustments can be accomplished simply by removing the subject component from the cabinet. If possible, disassembly should be

confined to subassemblies, which can, in some cases, be removed without disturbing adjustments. When reassembling the subassemblies, be sure to check all associated adjustments, clearances and spring tensions.

1.06 Retaining rings are made of spring steel and have a tendency to release suddenly when being removed. Loss of these retainers can be minimized as follows: Hold the retainer with the left hand to prevent it from rotating. Place the blade of a suitable screwdriver in one of the slots of the retainer. Rotate the screwdriver in a direction to increase the diameter of the retainer for removal.

1.07 Avoid loss of springs in disassembly by holding one spring loop with the left hand while gently removing the opposite loop with a spring hook. Do not stretch or distort springs in removing them.

2. DISASSEMBLY AND REASSEMBLY

CONTROL PANEL

2.01 To remove the control panel, remove the TP151630 screws from left and right sides and lift the panel out (Figures 2 and 4).




Figure 1 - 37 Keyboard Unit

SECTION 574-321-705TC

2.02 To replace the control panel, reverse the removal procedure.

KEYBOARD HOUSING AND COVER

2.03 To remove the TP324035 keyboard housing, remove the two TP151631 screws (one on each side) and slide the keyboard housing forward (Figures 2 and 4).

2.04 To remove the TP315190 cover, proceed as follows:

(1) Pull the tab on the front of the TP315190 cover forward and remove it from the post.

(2) Slide the TP315190 cover toward the front while rotating the cover up and over keytops.

2.05 To assemble the keyboard housing and cover, reverse the removal procedure.

KEYBOARD

2.06 To remove the keyboard from the base assembly, proceed as follows (Figures 2 to 5):

(1) Loosen the four keyboard mounting screws (two on each side).

Note: Support the keyboard to prevent its falling when these screws are removed.

(2) Support the keyboard and remove the screws.

(3) Slowly lift the keyboard up and to the right side to disengage the TP315296 H-plate on the reset mechanism (or remove the TP119653 retaining ring on the H-plate and move the H-plate to the left).

(4) Refer to 2.08 through 2.10 for keyboard disassembly instructions.

2.07 To replace the keyboard, proceed as follows:

(1) Mount the keyboard to the base pan.

(2) Observe that the TP315296 H-plate on the reset mechanism engages the keyboard trip lever mechanism. (Install the TP315296 retaining if it was removed.)

(3) Secure the keyboard in place with its four mounting screws.

2.08 To remove the keytops and keylevers, proceed as follows:

Note: Before removing the SHIFT or CONTROL keylevers, remove their respective springs from the end brackets.

(1) Remove TP315190 keyboard cover (2.04).

(2) Remove the keylevers as required.

(3) Remove the keytops as required.

2.09 To remove the TP315370 contact block and TP324407 cable assembly, proceed as follows:

(1) Remove TP315190 keyboard cover (2.04).

(2) Pull the tab on the front of the keytop guide forward and remove it from the post.

(3) Rotate the TP315190 cover toward the rear and remove it.

(4) Remove the TP315484 trip arm spring.

(5) Remove the TP324414 right end bracket assembly by squeezing the frame lightly in rear assembly area or by applying slight pressure with a screwdriver inserted in the frame hole.

(6) Remove the two TP180031 compression springs from the TP315370 contact block.

(7) Remove T-lever guide from right side of the unit.

(8) Remove the contact wires by detaching their springs.

(9) Remove the TP315370 contact block and TP324407 cable assembly.

2.10 If further disassembly is required, proceed as follows to completely disassemble the keyboard.

(1) With keytops, keylevers, contact block, cable assembly and left and right end brackets removed, remove the spring from the space mechanism.




Figure 2 - 37 Keyboard Unit




Figure 3 - Keyboard (Cover Removed)

SECTION 574-321-705TC

- (2) Remove retaining rings from the space mechanism. Remove the L-levers, space keylever and tie link as a unit by rotating the space mechanism clockwise and forward.
- (3) Rotate the L-levers until keylevers and tie link are separated.
- (4) Release and remove the TP110436 spring on the TP315487 space bail.
- (5) Remove the four TP315459 downstop springs.
- (6) Remove the TP315445 latchlever spring and TP121923 nonrepeat lever spring.
- (7) Remove the downstop spring brackets.
- (8) Remove the codebars (snap fit on small end).
- (9) Remove the universal TP315444 tie link spring from the frame.
- (10) Remove the TP315401 universal codebar (snap fit on small end).
- (11) Remove trip arm.
- (12) Remove trip arm guide (snap fit).
- (13) Remove T-lever shafts and T-lever assembly.
- (14) Remove TP324391 downstop bar.
- (15) Remove tie links, including the TP315493 universal tie link, by rotating T-levers until links are free.
- (16) Remove TP119651 retaining rings and the T-levers on the left side as required.
- (17) Remove the TP119651 retaining rings, T-levers, and trip mechanism bushing on right side as required.
- (18) Remove retaining rings, TP315398 non-repeat lever, washer, and latch from trip mechanism bushing as required.
- (19) Remove TP315199 buffer upstop in front of frame.
- (20) Remove the four TP315405 leaf springs from the underside of the frame.
- (21) Remove the two TP315273 bushing strips from the frame.

- 2.11 To assemble the keyboard, reverse the disassembly procedure.

RESET MECHANISM

- 2.12 To remove the TP315100 reset mechanism, proceed as follows (Figures 4 and 5):

- (1) Remove the TP315296 H-plate retaining ring and slide the H-plate out of the slots in the TP315399 keyboard trip arm lever and reset bail plate.

- (2) Remove the keyboard (2.06).

- (3) Disconnect the push-on cable terminals from the tabs on the auxiliary contacts.

- (4) Unscrew the three reset mechanism frame mounting screws.

- (5) Remove the reset mechanism by sliding it out.

- 2.13 Remove the TP315319 auxiliary contact bracket assembly by unscrewing the TP112626 shaft nut and removing the assembly.

- 2.14 To remove the driven gear clutch-sleeve-cam assembly, proceed as follows:

- (1) Remove the TP2605 clutch stop arm spring.

- (2) Loosen the TP112626 shaft nuts on each end of the shaft.

- (3) Dislodge the gear backlash plate and contact bracket from their locating bosses.

- (4) Lift the assembly from the frame.

- 2.15 Remove the driving gear-shaft-bracket assembly by unscrewing the two bracket mounting screws and removing the assembly.

- 2.16 To assemble the reset mechanism, reverse the disassembly procedures. Check that the H-plate is properly engaged with the keyboard trip lever mechanism.

INTERMEDIATE GEAR ASSEMBLY

- 2.17 Remove the intermediate gear assembly by removing the three TP104898 mounting screws (Figure 4).

- 2.18 Replace the intermediate gear by securing the mounting screws.




Figure 4 - Keyboard Unit




Figure 5 - Reset Mechanism



37 KEYBOARD UNIT
DISASSEMBLY AND REASSEMBLY

CONTENTS	PAGE
1. GENERAL	1
2. DISASSEMBLY AND REASSEMBLY ..	1
CONTROL PANEL	1
KEYBOARD HOUSING AND COVER ..	2
KEYBOARD	2
RESET MECHANISM	4
INTERMEDIATE GEAR ASSEMBLY .	4

1. GENERAL

1.01 This section provides disassembly and reassembly information for the late design, 11-contact 37 keyboard unit (Figure 1). It is reissued to incorporate engineering changes and other comments received on Issue 1. Since only a limited distribution was made on Issue 1, marginal arrows have been omitted.

1.02 Photographs are used to identify the mechanisms and specific parts mentioned in the procedures. Refer to the appropriate parts section for drawings showing the location of all parts and mechanisms.

1.03 Refer to Section 570-005-800TC, Maintenance Tools, for information on the tools necessary to perform the disassembly and reassembly procedures.

1.04 References in the procedures to left or right, up or down, top or bottom, etc refer to the unit viewed with the keytops and controls facing the front (Figure 1).

CAUTION: REMOVE POWER BEFORE DISASSEMBLING THE UNIT.

1.05 Most maintenance, lubrication and adjustments can be accomplished simply by removing the subject component from the cabinet. If possible, disassembly should be

confined to subassemblies, which can, in some cases, be removed without disturbing adjustments. When reassembling the subassemblies, be sure to check all associated adjustments, clearances and spring tensions.

1.06 Retaining rings are made of spring steel and have a tendency to release suddenly when being removed. Loss of these retainers can be minimized as follows: Hold the retainer with the left hand to prevent it from rotating. Place the blade of a suitable screwdriver in one of the slots of the retainer. Rotate the screwdriver in a direction to increase the diameter of the retainer for removal.

1.07 Avoid loss of springs in disassembly by holding one spring loop with the left hand while gently removing the opposite loop with a spring hook. Do not stretch or distort springs in removing them.

2. DISASSEMBLY AND REASSEMBLY

CONTROL PANEL

2.01 To remove the control panel, remove the TP151630 screws from left and right sides and lift the panel out (Figures 2 and 4).




Figure 1 - 37 Keyboard Unit

SECTION 574-321-705TC

2.02 To replace the control panel, reverse the removal procedure.

KEYBOARD HOUSING AND COVER

2.03 To remove the TP324035 keyboard housing, remove the two TP151631 screws (one on each side) and slide the keyboard housing forward (Figures 2 and 4).

2.04 To remove the TP315190 cover, proceed as follows:

(1) Pull the tab on the front of the TP315190 cover forward and remove it from the post.

(2) Slide the TP315190 cover toward the front while rotating the cover up and over keytops.

2.05 To assemble the keyboard housing and cover, reverse the removal procedure.

KEYBOARD

2.06 To remove the keyboard from the base assembly, proceed as follows (Figures 2 to 5):

(1) Loosen the four keyboard mounting screws (two on each side).

Note: Support the keyboard to prevent its falling when these screws are removed.

(2) Support the keyboard and remove the screws.

(3) Slowly lift the keyboard up and to the right side to disengage the TP315296 H-plate on the reset mechanism (or remove the TP119653 retaining ring on the H-plate and move the H-plate to the left).

(4) Refer to 2.08 through 2.10 for keyboard disassembly instructions.

2.07 To replace the keyboard, proceed as follows:

(1) Mount the keyboard to the base pan.

(2) Observe that the TP315296 H-plate on the reset mechanism engages the keyboard trip lever mechanism. (Install the TP315296 retaining if it was removed.)

(3) Secure the keyboard in place with its four mounting screws.

2.08 To remove the keytops and keylevers, proceed as follows:

Note: Before removing the SHIFT or CONTROL keylevers, remove their respective springs from the end brackets.

(1) Remove TP315190 keyboard cover (2.04).

(2) Remove the keylevers as required.

(3) Remove the keytops as required.

2.09 To remove the TP315370 contact block and TP324407 cable assembly, proceed as follows:

(1) Remove TP315190 keyboard cover (2.04).

(2) Pull the tab on the front of the keytop guide forward and remove it from the post.

(3) Rotate the TP315190 cover toward the rear and remove it.

(4) Remove the TP315484 trip arm spring.

(5) Remove the TP324414 right end bracket assembly by squeezing the frame lightly in rear assembly area or by applying slight pressure with a screwdriver inserted in the frame hole.

(6) Remove the two TP180031 compression springs from the TP315370 contact block.

(7) Remove T-lever guide from right side of the unit.

(8) Remove the contact wires by detaching their springs.

(9) Remove the TP315370 contact block and TP324407 cable assembly.

2.10 If further disassembly is required, proceed as follows to completely disassemble the keyboard.

(1) With keytops, keylevers, contact block, cable assembly and left and right end brackets removed, remove the spring from the space mechanism.




Figure 2 - 37 Keyboard Unit




Figure 3 - Keyboard (Cover Removed)

SECTION 574-321-705TC

- (2) Remove retaining rings from the space mechanism. Remove the L-levers, space keylever and tie link as a unit by rotating the space mechanism clockwise and forward.
- (3) Rotate the L-levers until keylevers and tie link are separated.
- (4) Release and remove the TP110436 spring on the TP315487 space bail.
- (5) Remove the four TP315459 downstop springs.
- (6) Remove the TP315445 latchlever spring and TP121923 nonrepeat lever spring.
- (7) Remove the downstop spring brackets.
- (8) Remove the codebars (snap fit on small end).
- (9) Remove the universal TP315444 tie link spring from the frame.
- (10) Remove the TP315401 universal codebar (snap fit on small end).
- (11) Remove trip arm.
- (12) Remove trip arm guide (snap fit).
- (13) Remove T-lever shafts and T-lever assembly.
- (14) Remove TP324391 downstop bar.
- (15) Remove tie links, including the TP315493 universal tie link, by rotating T-levers until links are free.
- (16) Remove TP119651 retaining rings and the T-levers on the left side as required.
- (17) Remove the TP119651 retaining rings, T-levers, and trip mechanism bushing on right side as required.
- (18) Remove retaining rings, TP315398 non-repeat lever, washer, and latch from trip mechanism bushing as required.
- (19) Remove TP315199 buffer upstop in front of frame.
- (20) Remove the four TP315405 leaf springs from the underside of the frame.
- (21) Remove the two TP315273 bushing strips from the frame.

- 2.11 To assemble the keyboard, reverse the disassembly procedure.

RESET MECHANISM

- 2.12 To remove the TP315100 reset mechanism, proceed as follows (Figures 4 and 5):

- (1) Remove the TP315296 H-plate retaining ring and slide the H-plate out of the slots in the TP315399 keyboard trip arm lever and reset bail plate.

- (2) Remove the keyboard (2.06).

- (3) Disconnect the push-on cable terminals from the tabs on the auxiliary contacts.

- (4) Unscrew the three reset mechanism frame mounting screws.

- (5) Remove the reset mechanism by sliding it out.

- 2.13 Remove the TP315319 auxiliary contact bracket assembly by unscrewing the TP112626 shaft nut and removing the assembly.

- 2.14 To remove the driven gear clutch-sleeve-cam assembly, proceed as follows:

- (1) Remove the TP2605 clutch stop arm spring.

- (2) Loosen the TP112626 shaft nuts on each end of the shaft.

- (3) Dislodge the gear backlash plate and contact bracket from their locating bosses.

- (4) Lift the assembly from the frame.

- 2.15 Remove the driving gear-shaft-bracket assembly by unscrewing the two bracket mounting screws and removing the assembly.

- 2.16 To assemble the reset mechanism, reverse the disassembly procedures. Check that the H-plate is properly engaged with the keyboard trip lever mechanism.

INTERMEDIATE GEAR ASSEMBLY

- 2.17 Remove the intermediate gear assembly by removing the three TP104898 mounting screws (Figure 4).

- 2.18 Replace the intermediate gear by securing the mounting screws.




Figure 4 - Keyboard Unit




Figure 5 - Reset Mechanism



37 ANSWER-BACK UNIT

LUBRICATION

CONTENTS	PAGE
1. GENERAL	1
2. BASIC UNIT	2
Answer-back	2
Code drum and feed mechanism	3
Contact assembly and detent.	3

1. GENERAL

1.01 This section provides lubrication procedures for the early design 37 answer-back unit (Figure 1), and is reissued to incorporate changes in the lubrication requirements. Marginal arrows have been included to indicate these changes.

1.02 A figure of the mechanism is used to show the lubrication areas. The paragraph numbers on the figure refer to the specific lubrication points. Reference made to front or rear, left or right, or top or bottom applies to the answer-back unit in its normal operating position as viewed by the operator in front of the unit. In this position, the answer-back unit is resting on its base with the contact assembly in the front.

1.03 Lubricate the answer-back unit before placing it in service and just prior to putting it in storage.

1.04 After approximately four weeks of service, relubricate the unit to make certain that no points have been missed. Thereafter, lubricate the unit according to the following schedule:

- | | |
|---------|-------------------------|
| 100 wpm | 2000 hours or 6 months* |
| 150 wpm | 1500 hours or 6 months* |

*Whichever comes first.

1.05 The symbols O1, O2, O3, etc, refer to 1, 2, 3, etc, drops of oil. The following list of symbols apply to the lubrication instructions:

- | | |
|---|-----------------------------------|
| O | Oil KS7470 |
| D | Keep dry, no lubricant permitted. |
| L | Lubriplate 105 grease |

Note: Ordering information for lubricants and a complete list of tools and materials available to maintain this equipment is given in Section 570-005-800TC.

1.06 Overlubrication which would allow oil to drip or to be thrown on other parts should be avoided. Capillary action and vaporization tend to keep a thin film of oil on the mechanisms. This prevents rust and provides sufficient lubrication to many points.

Note: Maintenance pad TP124828 is available to protect furniture and floor coverings from oil, grease, and dirt while lubricating the unit.




Figure 1 - 37 Answer-Back Unit

SECTION 574-325-701TC

1.07 Oil should be applied by means of an oiler to points where it will adhere or where pressure is nominal. In lubricating small parts, a minimum amount of oil should be applied so that the oil remains on the part and does not run off. Excessive lubricants should be removed with a dry lint-free cloth. If the surface between the relay armature and magnet pole piece has oil or foreign matter, proceed as follows.

- (1) Place a piece of clean paper between the armature and pole piece.
- (2) Energize the magnet.
- (3) Pull the paper through the armature and pole piece and check to insure that lint or pieces of paper do not remain.

1.08 Use twill jean cloth KS2423 to clean gold-plated contacts. The code reading contacts should be cleaned after approximately 1000 hours of operation or 6 months of service, whichever occurs first. Use the following procedure:

- (1) Rotate the code drum to open the contacts,

- (2) drop a strip of twill jean between the contacts and the common bar, (3) close the contacts, (4) draw the twill jean part way through, and (5) reopen the contacts and withdraw the twill jean. This procedure will prevent small fibers from the edges of the twill jean strip from becoming lodged between the contacts.

Note: Do not use burnishers, files, etc, which will remove the gold plating.


1.09 Special care should be taken to prevent any lubricant from getting on the circuit board, electrical contacts, and wiring.

CAUTION 1: DO NOT USE GOLD-PLATED CONTACTS ALTERNATELY IN HIGH- AND LOW-LEVEL CIRCUITS BECAUSE HIGH-LEVEL OPERATION MAY DAMAGE THE GOLD PLATING AND IMPAIR THE OPERATION OF THE CONTACTS WHEN USED IN LOW-LEVEL CIRCUITS.

CAUTION 2: REMOVE POWER BEFORE LUBRICATING THE EQUIPMENT.


2. BASIC UNIT

2.01 Answer-Back




(Left Side View)

2.02 Code Drum and Feed Mechanism



2.03 Contact Assembly and Detent





37 ANSWER-BACK UNIT

LUBRICATION

CONTENTS	PAGE
1. GENERAL.	1
2. BASIC UNIT	2
Answer-back	2
Code drum and feed mechanism	3
Contact assembly and detent.	3

1. GENERAL

1.01 This section provides lubrication procedures for the early design 37 answer-back unit (Figure 1), and is reissued to incorporate changes in the lubrication requirements. Marginal arrows have been included to indicate these changes.

1.02 A figure of the mechanism is used to show the lubrication areas. The paragraph numbers on the figure refer to the specific lubrication points. Reference made to front or rear, left or right, or top or bottom applies to the answer-back unit in its normal operating position as viewed by the operator in front of the unit. In this position, the answer-back unit is resting on its base with the contact assembly in the front.

1.03 Lubricate the answer-back unit before placing it in service and just prior to putting it in storage.

1.04 After approximately four weeks of service, relubricate the unit to make certain that no points have been missed. Thereafter, lubricate the unit according to the following schedule:

- | | | |
|---------|-------------------------|---|
| 100 wpm | 2000 hours or 6 months* | ← |
| 150 wpm | 1500 hours or 6 months* | ← |

*Whichever comes first.

1.05 The symbols O1, O2, O3, etc, refer to 1, 2, 3, etc, drops of oil. The following list of symbols apply to the lubrication instructions:

- | | | |
|---|-----------------------------------|---|
| O | Oil KS7470 | ← |
| D | Keep dry, no lubricant permitted. | |
| L | Lubriplate 105 grease | ← |

Note: Ordering information for lubricants and a complete list of tools and materials available to maintain this equipment is given in Section 570-005-800TC.

1.06 Overlubrication which would allow oil to drip or to be thrown on other parts should be avoided. Capillary action and vaporization tend to keep a thin film of oil on the mechanisms. This prevents rust and provides sufficient lubrication to many points.

Note: Maintenance pad TP124828 is available to protect furniture and floor coverings from oil, grease, and dirt while lubricating the unit.




Figure 1 - 37 Answer-Back Unit

SECTION 574-325-701TC

1.07 Oil should be applied by means of an oiler to points where it will adhere or where pressure is nominal. In lubricating small parts, a minimum amount of oil should be applied so that the oil remains on the part and does not run off. Excessive lubricants should be removed with a dry lint-free cloth. If the surface between the relay armature and magnet pole piece has oil or foreign matter, proceed as follows.

- (1) Place a piece of clean paper between the armature and pole piece.
- (2) Energize the magnet.
- (3) Pull the paper through the armature and pole piece and check to insure that lint or pieces of paper do not remain.

1.08 Use twill jean cloth KS2423 to clean gold-plated contacts. The code reading contacts should be cleaned after approximately 1000 hours of operation or 6 months of service, whichever occurs first. Use the following procedure:
(1) Rotate the code drum to open the contacts,

(2) drop a strip of twill jean between the contacts and the common bar, (3) close the contacts, (4) draw the twill jean part way through, and (5) reopen the contacts and withdraw the twill jean. This procedure will prevent small fibers from the edges of the twill jean strip from becoming lodged between the contacts.

Note: Do not use burnishers, files, etc, which will remove the gold plating.


1.09 Special care should be taken to prevent any lubricant from getting on the circuit board, electrical contacts, and wiring.

CAUTION 1: DO NOT USE GOLD-PLATED CONTACTS ALTERNATELY IN HIGH- AND LOW-LEVEL CIRCUITS BECAUSE HIGH-LEVEL OPERATION MAY DAMAGE THE GOLD PLATING AND IMPAIR THE OPERATION OF THE CONTACTS WHEN USED IN LOW-LEVEL CIRCUITS.

CAUTION 2: REMOVE POWER BEFORE LUBRICATING THE EQUIPMENT.


2. BASIC UNIT

2.01 Answer-Back




(Left Side View)

2.02 Code Drum and Feed Mechanism



- | | | |
|----|--------------------|------------------|
| O1 | Tip | Feed Pawl |
| O1 | Hook (Each End) | Feed Bail Spring |
| O | Saturate Felt Wick | |
| O1 | Pivot | Feed Pawl |
| O1 | Hook (Each End) | Feed Pawl Spring |
| O | Saturate Felt Wick | |
| O1 | Bearing (Each End) | Code Drum |
| O1 | Hook (Each End) | Armature Spring |
| O | Saturate Felt Wick | |

2.03 Contact Assembly and Detent



- | | | |
|----|-----------------------------------|---------------------------------|
| O1 | End | Detent |
| D | Surfaces | Contact Wires (9) |
| D | Hook (Each End) | Contact Wire Springs (9) |
| O1 | Hooks (Each End) | Detent Spring |
| O1 | End | Detent |
| L | Thin Coat on Contact Pivot Points | Contact Wires and Terminals (9) |



37 ANSWER-BACK UNIT

LUBRICATION

	CONTENTS	PAGE	<u>Symbol</u>	<u>Meaning</u>
1.	GENERAL	1	O	Oil KS7470
2.	BASIC UNIT	2	G	Grease KS7471
	Answer-Back	2		
	Feed Mechanism	3		

Note: Ordering information for lubricants and a complete list of tools and materials available to maintain this equipment is given in Section 570-005-800TC.

1. GENERAL

1.01 This section provides lubrication procedures for the late design 37 answer-back unit (Figure 1). The late design unit can be recognized by the location of the drum feed mechanism at the end of the code drum. The drum feed mechanism on the early design answer-back unit is located in the middle of the code drum.

1.02 A photograph of the mechanism is used to show the lubrication area. The paragraph number on the figure refers to the specific lubrication points. Reference made to front or rear, left or right, top or bottom, etc, applies to the answer-back unit in its normal operating position as viewed by the operator in front of the unit. In this position, the answer-back unit is resting on its base with the contact assembly on the right side.

1.03 Lubricate the answer-back unit before placing it in service and just prior to putting it in storage.

1.04 After approximately 200 hours or four weeks of operation (whichever comes first), relubricate the unit. Thereafter, lubricate the unit according to the following schedule:

100 wpm 2,000 hours or 9 months*

150 wpm 1,500 hours or 6 months*

*Whichever comes first.

1.05 The symbols O1, O2, O3, etc, refer to 1, 2, 3, etc, drops of oil. The following list of symbols apply to the lubrication instructions:

1.06 Overlubrication which would allow oil to drip or to be thrown on other parts should be avoided. Capillary action and vaporization tend to keep a thin film of oil on the mechanisms. This prevents rust and provides sufficient lubrication to many points.

Note: Maintenance pad TP124828 is available to protect furniture and floor coverings from oil, grease, and dirt while lubricating the unit.




Figure 1 - Answer-Back Unit

1.07 Oil should be applied by means of an oiler to points where it will adhere or where pressure is nominal. In lubricating small parts, a minimum amount of oil should be applied, so that the oil remains on the part and does not run off. Excessive lubricants should be removed with a dry lint-free cloth. If the surface between the relay armature and magnet pole piece has oil or foreign matter, proceed as follows.

- (1) Place a piece of clean paper between the armature and pole piece.
- (2) Energize the magnet.
- (3) Pull the paper through the armature and pole piece and check to insure that lint or pieces of paper do not remain.

1.08 Use twill jean cloth KS2423 to clean gold-plated contacts. The code reading contacts should be cleaned after approximately 1000 hours of operation or 6

months of service, whichever occurs first. Use the following procedure: (1) deflect the tab on the contact assembly downward to open the contacts, (2) drop a strip of twill jean between the contacts, (3) close the contacts, (4) draw the twill jean part way through the contacts, and (5) reopen the contacts and withdraw the twill jean. This procedure will prevent small fibers from the edges of the twill jean strip from becoming lodged between the contacts.


Note: Do not use burnishers, files, etc, which will remove gold plating.

CAUTION 1: DO NOT USE GOLD-PLATED CONTACTS ALTERNATELY IN HIGH- AND LOW-LEVEL CIRCUITS BECAUSE HIGH-LEVEL OPERATION MAY DAMAGE THE GOLD PLATING AND IMPAIR THE USE OF THE CONTACTS IN LOW-LEVEL CIRCUITS.

CAUTION 2: REMOVE POWER BEFORE LUBRICATING THE EQUIPMENT.


2. BASIC UNIT

2.01 Answer-Back



(Right Front View)

2.02 Feed Mechanism



(Front View)



37 TYPING UNIT COVER AND PAN

LUBRICATION

CONTENTS	PAGE
1. GENERAL.....	1
2. BASIC UNIT.....	3
Balancing arm.....	5
Cover and pan.....	3
Cover hinges.....	3
Cover latches.....	4
Front lid latches.....	5
Rear lid hinges.....	4

1. GENERAL

1.01 This section provides lubrication procedures for the late design 37 typing unit cover and pan which has the front cover cut out for WECO 635R2 switches (Figure 1). It is reissued to incorporate minor engineering changes and comments received on Issue 1. Since only a limited distribution was made on Issue 1, marginal arrows have been omitted. For similar information on early design units which have the front cover cut out for Licon 76-type switches, see Section 574-326-701TC.

1.02 General areas of the cover and pan which require lubrication are shown by photographs. Specific points to receive lubrication are indicated by line drawings and descriptive text. The line drawings and descriptive text follow each photograph and are keyed to the photograph by paragraph numbers.

1.03 References made to the front, rear, left, or right apply to the cover in its normal operating position as viewed by the operator.

1.04 Lubricate the cover before placing it into service and just prior to putting it into storage.

1.05 After approximately 200 hours or four weeks of operation (whichever comes first), relubricate the cover to make certain that no points have been missed. Thereafter, lubri-

cate the cover according to the following schedule:

100 wpm	2000 hr or 9 mo*
150 wpm	1500 hr or 6 mo*

* Whichever occurs first.

1.06 The following symbols apply to the specific lubrication instructions given in each paragraph:

G Apply a thin coat of KS7471 grease.

O1 Apply one drop of KS7470 oil.

Note: Ordering information for the above lubricants and a complete list of tools and materials available to maintain this equipment is given in Section 570-005-800TC.

1.07 Oil should be applied by means of an oiler. Over lubrication which would allow oil to drip on other parts should be avoided. Capillary action and vaporization tend to keep a film of oil on the parts. This prevents rust and provides sufficient lubrication to many points.

Note: Protective pad TP124828 is available to protect furniture and floor coverings from oil, grease, and dirt while lubricating the cover.




Figure 1 - Typing Unit Cover and Pan

SECTION 574-326-704TC

1.08 The cover is hinged at the rear and can be opened for access to lubrication points. For instructions on separating the cover from the pan and other disassembly information, see Section 574-301-702TC.

Note: If the cover is removed for lubrication or other purposes and then set aside temporarily, be sure to place it in a location where it will not get damaged and where it will not be a hazard to other personnel in the area.

1.09 Clean the cover and pan before and after it is lubricated. Remove excess oil and/or grease which may have run onto surfaces


which do not require lubrication. Remove the excess lubricant with care so that old lubricant or dirt does not get between bearing surfaces.

1.10 When cleaning plastic parts such as the plastic window, use soap or detergent and water. Do not use solvents containing alcohol or chlorinated ingredients.


CAUTION: WHEN THE ASSEMBLY IS FUNCTIONALLY UTILIZED WITH A TYPING UNIT ETC, REMOVE POWER FROM EQUIPMENT BEFORE APPLYING ANY LUBRICANT.

2. BASIC UNIT

2.01 Cover and Pan (Cover Opened, Left Side View)




2.02 Cover Hinges (Left and Right)




SECTION 574-326-704TC

2.03 Cover Latches (Left and Right)




(Left Side View)

2.04 Rear Lid Hinges (Left and Right)




(Front View)

2.05 Front Lid Latches (Left and Right)



(Bottom View)

2.06 Balancing Arm



(Left Side View)



37 REPERFORATOR-TRANSMITTER (RT) CABINET

LUBRICATION

CONTENTS	PAGE
1. GENERAL	1
2. BASIC UNIT	3
Cabinet.	3
Reperforator gear mechanism	4
Tight tape assembly	4
Top latches	3
3. TAPE HANDLING DOORS	5
Lower left mercury switch assembly	7
Lower right mercury switch assembly	7
Tape handling door	5
Tape sensor latch assembly	6
Upper mercury switch assembly	6

1.05 After approximately 200 hours or four weeks of operation (whichever comes first), relubricate the cabinet to make certain no points have been missed. Thereafter, lubricate the cabinet according to the following schedule:

100 wpm	2000 hours or 9 months *
150 wpm	1500 hours or 6 months *

* Whichever occurs first.

1. GENERAL

1.01 This section provides lubrication procedures for the 37 reperforator-transmitter (RT) cabinet (Figure 1). It is reissued to incorporate minor engineering changes and comments received on Issue 1. Since only a limited distribution was made on Issue 1, marginal arrows have been omitted.

1.02 General areas of the cabinet which require lubrication are shown by photographs. Specific points to receive lubrication are indicated by line drawings and descriptive text. The line drawings and descriptive text follow each photograph and are keyed to the photograph by paragraph numbers.

1.03 References made to left or right and front or rear apply to the cabinet in its normal operating position as viewed by the operator facing the cabinet (Figure 1).

1.04 Lubricate the cabinet before placing it into service and just prior to putting it into storage.




Figure 1 - Reperforator-Transmitter (RT) Cabinet

SECTION 574-327-701TC

Note: Lubricate the reperforator (punch) motor in accordance with 570-220-701TC. The transmitter (reader) motor requires no lubrication except when disassembled. Then, the bearings should be repacked with TP195298 grease or equivalent.

1.06 The following symbol is used in the lubrication instructions to indicate the type and amount of lubricant:

O1 - Apply one drop of KS7470 oil

G - Apply KS7471 grease

Note: Ordering information for lubricants and a complete list of tools and materials available to maintain this equipment is given in Section 570-005-800TC.

1.07 Oil should be applied by means of an oiler. Overlubrication which would allow oil to drip on other parts should be avoided. Capillary action and vaporization tend to keep a film of oil on the parts. This prevents rust and provides sufficient lubrication to many points.

CAUTION: SPECIAL CARE SHOULD BE TAKEN TO PREVENT ANY LUBRICANT FROM GETTING BETWEEN ELECTRICAL CONTACTS.

Note: Protective pad TP124828 is available to protect furniture and floor coverings from oil, grease, and dirt while lubricating the cabinet.

1.08 Instructions for removing any components which are mounted within the cabinet can be found in Section 574-302-702TC.


1.09 Clean the cabinet before and after it is lubricated. Remove excess oil and/or grease which may have run onto surfaces which do not require lubrication. Remove the excess lubricant with care so that old lubricant or dirt does not get between bearing surfaces.

1.10 When cleaning plastic parts such as the plastic window of the reperforator cover, use soap or detergent and water. Do not use solvents containing alcohol or chlorinated ingredients.

CAUTION: WHEN THE CABINET IS FUNCTIONALLY UTILIZED WITH PUNCH AND READER, REMOVE POWER FROM EQUIPMENT BEFORE APPLYING ANY LUBRICANT.


2. BASIC UNIT

2.01 Cabinet



(Left Front View)

2.02 Top Latches (Left and Right Sides)




Bearing Surface
(2 Pivots)

Latch Pivots

(Right Side View)

SECTION 574-327-701TC

2.03 Tight Tape Assembly




Hooks - Each End Spring

Bearing Surfaces Tight Tape Bail Pivot

(Rear View)

2.04 Reperforator Gear Mechanism




Teeth,
Thick Coat

Reperforator
Gear

(Left Side View)

3. TAPE HANDLING DOORS

3.01 Tape Handling Door



(Rear View)



37 NONTYPING REPERFORATOR

LUBRICATION

CONTENTS	PAGE
1. GENERAL	1
2. BASIC UNIT	3
Auxiliary Timing Contacts	15
Backspace mechanism	7
Feed mechanism	6
Function cam-clutch trip mechanism	13
Main shaft mechanism	11
Manual interfering tape feed-out mechanism	15
Nontyping reperforator (right side view)	3
Nontyping reperforator (left front view)	12
Perforator mechanism	4, 5
Punch mechanism	6
Rocker arm	14
Rocker bail mechanism	14
Selector cam clutch	10
Selector cam lubricator and marking locklever	9
Selector locklevers and pushlevers	10
Selector range finder and levers	8
Tape depressor mechanism	13

1.03 References made to left or right, front or rear, and top or bottom apply to the reperforator in a normal operating position with the selector mechanism on the right and the function mechanism on the left.

1.04 Lubricate the reperforator before placing it into service and just prior to putting it into storage.

1.05 After approximately 200 hours or four weeks of operation (whichever comes first), relubricate the reperforator to make certain no points have been missed. Thereafter, lubricate the reperforator according to the following schedule:

<u>Operating Speed (WPM)</u>	<u>Lubrication Interval</u>
100	2000 hours or 9 months *
150	1500 hours or 6 months *

* Whichever occurs first.

1. GENERAL

1.01 This section provides lubrication procedures for the 37 nontyping reperforator (Figure 1). It is reissued to incorporate engineering changes and comments received on Issue 1. Since only a limited distribution was made on Issue 1, marginal arrows have been omitted.

1.02 General areas of the equipment are shown by photographs. Specific points to receive lubrication are indicated by line drawings and descriptive text. The line drawings and descriptive text follow each photograph and are keyed to the photographs by paragraph numbers.




Figure 1 - 37 Nontyping Reperforator

SECTION 574-329-701TC

1.06 The following symbols are used in the lubrication instructions to indicate the type of lubricant:

<u>Symbol</u>	<u>Meaning</u>
O	Apply KS7470 oil.
G	Apply KS7471 grease as specified.
D	Apply no lubricants. Keep dry.

Note: In general, the symbols indicate the type of lubricant. Quantity of lubricant is normally given with the text associated with specific lubrication instructions. An exception to this method is where the exact number of drops of oil is specified. For example, O1, O2, O3, etc refer to 1, 2, 3, etc drops of oil.

1.07 The following general instructions supplement the specific lubricating points illustrated on subsequent pages:

- Apply one drop of oil to all spring hooks.
- Apply a light film of oil to all cam surfaces.
- Apply a thick coat of grease to all gears.
- Saturage all felt washers, oilers, etc.
- Apply oil to all pivot points.
- Apply oil to all sliding surfaces.

Note: Ordering information for lubricants and a complete list of tools and materials available to maintain the reperformator is given in Section 570-005-800TC.

1.08 Oil should be applied by means of an oiler. Overlubrication which would allow oil to drip on other parts should be avoided.

Wipe off excess amounts of lubricant. Capillary action and vaporization tend to keep a film of oil on the parts. This prevents rusts and provides sufficient lubrication to many points.

CAUTION: SPECIAL CARE SHOULD BE TAKEN TO PREVENT ANY LUBRICANT FROM GETTING BETWEEN ELECTRICAL CONTACTS.

Note: Protective pad TP124828 is available to protect furniture and floor coverings from oil, grease and dirt while lubricating the reperformator.

1.09 Gold-plated contacts are used in this equipment. The recommended cleaning interval for gold-plated contacts in special low-level applications (less than 250 microwatts and having an average weekly use of 60 hours) should not exceed 90 days. This interval may be reduced dependent on the signal circuit configuration, usage, and environment.


1.10 Use twill jean cloth (KS2423) to clean gold-plated contacts. Do not use burnishers, files, etc which will remove the gold plating.

CAUTION: DO NOT USE GOLD-PLATED CONTACTS ALTERNATELY IN HIGH- AND LOW-LEVEL CIRCUITS BECAUSE HIGH-LEVEL OPERATION MAY DAMAGE THE GOLD PLATING AND IMPAIR THE CONTACTS USED IN LOW-LEVEL CIRCUITS.

CAUTION: REMOVE POWER BEFORE LUBRICATING THE EQUIPMENT.


2. BASIC UNIT

2.01 Nontyping Reperforator (Right Side View)




SECTION 574-329-701TC

2.02 Perforator Mechanism




(Right Front View)

2.03 Perforator Mechanism (continued)




(Right Front View)


2.04 Punch Mechanism



2.05 Feed Mechanism




2.06 Backspace Mechanism



(Right Side View)


2.07 Backspace Mechanism (continued)



(Right Side View)


SECTION 574-329-701TC

2.08 Selector Range Finder and Levers



(Right Side View)


2.09 Selector Cam Lubricator and Marking Locklever



O1	Contact Surface	Armature Extension
D	Contact Surface	Front Button
O1	Guide Slot	Marking Locklever
O1	Hooks (Each End)	Spring
O	Saturate Wick	Cam Lubricator Wick
O	Fill Reservoir	Cam Lubricator

(Right Side View)


2.10 Selector Locklevers and Pushlevers



(Right Front View)

- | | | |
|----|------------------------|---|
| O1 | Hooks
(Each End) | Springs (11) |
| O1 | Engaging
Surfaces | Pushlevers |
| O1 | Guide Slots | Start and Lock-
levers, Selector
and Pushlevers |
| O1 | Hooks
(Each End) | Springs (10) |
| O2 | Bearing
Guide Slots | Push and Selector
Levers Guide
Bearings |

2.11 Selector Cam Clutch




(Rear View)


- | | | |
|----|-----------------------|-----------------------|
| O | Saturate Felt
Wick | Selector Clutch |
| O4 | Internal
Mechanism | Selector Clutch |
| O2 | Oil Holes (2) | Cam Sleeve
Bearing |
| O2 | Camming
Surfaces | Selector Cams |
| O2 | Camming
Surfaces | Clutch Disc |

2.12 Main Shaft Mechanism


Note: If function cam needle bearings are disassembled at any time, repack bearings with grease (TP195298) or its equivalent.




2.13 Main Shaft Mechanism (continued)




2.14 Nontyping Reperforator (Left Front View)




2.15 Function Cam-Clutch Trip Mechanism



2.16 Tape Depressor Mechanism




2.17 Rocker Bail Mechanism



(Left Side View)

- | | | |
|----|-----------------------------------|---------------------|
| O | Saturate Felt Wick | Drive Link Wick |
| O2 | Rollers (2) | Rocker Bail Rollers |
| O2 | Guide Slot | Rocker Bail Guide |
| O | Saturate Felt Wick - Use Oil Hole | Rocker Bail Shaft |
| O2 | Pivot | Rocker Bail Shaft |


2.18 Rocker Arm




(Left Side View)

- | | | |
|----|--------------------|------------|
| O1 | Engaging Surface | Rocker Arm |
| O | Saturate Felt Wick | Rocker Arm |
| O1 | Hooks - Each End | Spring |
| O1 | Bearing Surface | Rocker Arm |

2.19 Manual Interfering Tape Feedout Mechanism



2.20 Auxiliary Timing Contacts





37 NONTYPING REPERFORATOR UNIT
DISASSEMBLY AND REASSEMBLY

CONTENTS	PAGE
1. GENERAL	1
2. DISASSEMBLY AND REASSEMBLY..	1
BACKSPACE MECHANISM	1
SELECTOR MECHANISM	2
MAIN SHAFT	2

1. GENERAL

1.01 This section provides disassembly and reassembly instructions for the 37 nontyping reperforator unit (Figure 1). It is reissued to incorporate engineering changes and comments received on Issue 1. Since only a limited distribution was made on Issue 1, marginal arrows have been omitted.

1.02 Photographs are used to identify the mechanisms and specific parts mentioned in the procedures. Refer to the appropriate parts section for drawings showing the location of all parts and mechanisms.

1.03 Refer to Section 570-005-800TC, Maintenance Tools, for information on the tools necessary to perform the disassembly and reassembly procedures.

1.04 References in the procedures to left or right, up or down, top or bottom, etc refer to the unit viewed in a normal operating position with the selector mechanism on the right and the function mechanism on the left.

CAUTION: REMOVE POWER BEFORE DISASSEMBLING THE UNIT.

1.05 Most maintenance, lubrication and adjustments can be accomplished simply by removing the subject component from the cabinet. If possible, disassembly should be confined to subassemblies, which can, in some cases, be removed without disturbing adjustments. When reassembling the subassemblies,

be sure to check all associated adjustments, clearances and spring tensions.

1.06 If a part that is mounted on shims is removed, the number of shims used at each of its mounting screws should be noted so that the same shim pile-up can be replaced when the part is remounted.

1.07 Retaining rings are made of spring steel and have a tendency to release suddenly when being removed. Loss of these retainers can be minimized as follows: Hold the retainer with the left hand to prevent it from rotating. Place the blade of a suitable screwdriver in one of the slots of the retainer. Rotate the screwdriver in a direction to increase the diameter of the retainer for removal.

1.08 Avoid loss of springs in disassembly by holding one spring loop with the left hand while gently removing the opposite loop with a spring hook. Do not stretch or distort springs in removing them.

2. DISASSEMBLY AND REASSEMBLY
BACKSPACE MECHANISM

2.01 To remove the backspace mechanism, proceed as follows (Figure 2):




Figure 1 - 37 Nontyping Reperforator Unit

SECTION 574-329-702TC

- (1) Unhook the TP84575 spring from the TP159958 drive link latch.
- (2) Loosen the TP151632 screw on the TP159960 eccentric and pull the TP159961 eccentric arm off the TP159963 hub.
- (3) Disengage the eccentric arm from its guide between the TP159958 latch and TP159955 drive link.
- (4) Remove the post from between the TP159954 adjusting link and the front punch frame. Then remove the link and latch assembly.
- (5) Remove the two TP156632 screws on the front of the punch frame and remove the magnet assembly.

2.02 To assemble the backspace mechanism, reverse the removal procedure.

SELECTOR MECHANISM

2.03 To remove the selector mechanism, proceed as follows (Figure 2):

- (1) Remove the selector clutch drum mounting nut, screw and washers. Remove the clutch drum.
- (2) Remove the selector clutch and cam sleeve assembly as follows:
 - (a) Latch the pushlever reset bail up and out of the notch in the lever guide slot.
 - (b) Push the mark lever to the left side and insert a pin in the hole provided on the lever extension so that the lever (and selecting levers) is held away from the cam by the marking locklever guide bracket.
 - (c) Hold the spacing locklever and start lever to the left side and slip the cam sleeve assembly off the shaft by rotating it in a counterclockwise direction.

- (3) Remove the function clutch latchlever spring, spring post, nut, and washer.
- (4) Remove the selector backplate screw and washer (rear of plate, inserted through the casting).
- (5) Remove the oil wick, wick holder screw and washer, and wick holder.
- (6) Remove the selector mechanism.


2.04 To replace the selector mechanism, reverse the removal procedure. To facilitate replacing the cam sleeve, reverse the procedure but continue to rotate the sleeve counterclockwise. When the sleeve is almost fully in place, pull the trip lever and selector clutch latchlever away from their cams.

MAIN SHAFT

2.05 To remove the main shaft after the selector mechanism (2.03) has been removed, proceed as follows (Figure 3):


- (1) Remove the retaining ring, spring washer and flat washer from the forward end of the main shaft.
- (2) Remove the screw and lockwasher from the TP150000 clutch drum.
- (3) Remove the screw and lockwasher from the TP173340 collar.
- (4) Remove the screw and lockwasher from the rear bearing clamp.
- (5) Pull the main shaft out toward the rear while removing the function clutch and collar.

2.06 To replace the main shaft, reverse the disassembly procedure.



(Right Side View)

Figure 2 - 37 Nontyping Reperforator



(Left Front View)

Figure 3 - 37 Nontyping Reperforator

37 TYPING REPERFORATOR
 LUBRICATION

CONTENTS	PAGE
1. GENERAL	1
2. BASIC UNIT	3
Axial positioning mechanism	11, 12
Clutch trip mechanism	14
Detent assemblies	12
Feed mechanism	6
Main shaft mechanism	8
Perforator mechanism	5
Printing mechanism	13
Punch mechanism	6
Pushbars	9
Range finder mechanism	8
Ribbon carrier mechanism	15
Ribbon feed mechanism	4
Rocker bail mechanism	13
Rotary positioning mechanism	7
Selecting mechanism	7
Transfer mechanism	9
Typing reperforator (left front view)	3
Typing reperforator (right rear view)	10
3. VARIABLE FEATURES	16
Manual backspace mechanism	16
Power drive backspace mechanism	16
Remote control interfering tape delete feed-out mechanism	17
Two-color ribbon contact mechanism	18
Two-color ribbon mechanism	18

1. GENERAL

1.01 This section provides lubrication procedures for the Model 37 Typing Reperforator.

1.02 Photographs are used to show the general areas of lubrication. The paragraph numbers shown on the figures refer to specific

lubrication areas. Each paragraph consists of one or more line drawings and descriptive text that cover precise lubrication points.

1.03 Lubricate the typing reperforator before placing it in service and just prior to putting it in storage.

1.04 The unit should be relubricated after 200 hours of operation or four weeks, whichever comes first. Thereafter, lubricate all mechanisms of the reperforator according to the following schedule:

<u>Operating Speed</u>	<u>Lubrication Interval</u>
100 wpm	1500 hours or 6 months*
150 wpm	1000 hours or 6 months*

*Whichever occurs first.

CAUTION: DISCONNECT ALL AC POWER CORDS BEFORE PERFORMING ANY PROCEDURE.




Figure 1 - 37 Typing Reperforator

SECTION 574-330-701TC

1.05 The following list of symbols applies to the specific lubrication instructions given in each paragraph.

Symbol

- O Oil with KS7470 oil as instructed.
- G Apply KS7471 grease.
- GO Apply a thin coat of a mixture containing equal parts of grease and oil.

Note: In general, the symbols indicate the type of lubricant. Quantity of lubricant is normally given with the text associated with specific lubrication instructions. An exception to this method is where the exact number of drops of oil is specified. For example, O1, O2, O3, etc, refer to 1, 2, 3, etc, drops of oil.

1.06 Oil should be applied by means of an oiler to points where it will adhere or where pressure is nominal. In lubricating small parts,

only a single drop of oil should be applied so that the oil remains on the part and does not run off.

Note: Care should be exercised to prevent lubricants from getting between armature and pole faces or between electrical contact points.


1.07 In general, oil should be used in such locations as hollow shafts, wicks, and in most locations where parts rub, slide, or move with respect to each other. Grease should be used on gear teeth and points of heavy pressure. Capillary action and vaporization tend to keep a film of oil on the mechanisms. This prevents rust and provides sufficient lubrication to many points.

1.08 Refer to Section 570-005-800TC covering tools used and also a description of various lubricants used on the typing reperforator.


1.09 Protective pad TP124828 should be used to protect furniture and floor coverings from grease, oil, and dirt while lubricating the unit.

2. BASIC UNIT


2.01 Typing Reperforator (Left Front View)



2.02 Ribbon Feed Mechanism




- O1 Hooks - Each End Spring
- O2 Pivot Point Feed Pawl
- O2 Pivot Check Pawl
- O2 Pivot Points (2) Reversing Arm
- GO Contacting Surface Drive Arm Adjustable Extension
- O Saturate Felt Oiler Drive Arm Roller




- O1 Hooks - Each End Springs (2)
- GO Teeth Ratchet Wheel (2)
- O2 Shaft Rollers (2)
- O2 Shaft, Felt Oilers Ratchet Wheel (2)
- O2 Pivot Detent
- GO Contacting Surfaces Detent
- O2 Upper and Lower Bushing Slide Lever
- O2 Pivot Drive Arm

2.03 Perforator Mechanism




(Left Front View)


2.04 Punch Mechanism




2.05 Feed Mechanism




2.06 Rotary Positioning Mechanism




2.07 Selecting Mechanism



2.08 Range Finder Mechanism




2.09 Main Shaft Mechanism




*Note: Do not lubricate when unit is equipped with a belt driven sprocket.


2.10 Transfer Mechanism




2.11 Pushbars




2.12 Typing Reperforator (Right Rear View)




2.13 Axial Positioning Mechanism




2.14 Axial Positioning Mechanism (continued)




2.15 Detent Assemblies




2.16 Printing Mechanism



2.17 Rocker Bail Mechanism




2.18 Clutch Trip Mechanism




(Right Front View)

2.19 Ribbon Carrier Mechanism




3. VARIABLE FEATURES


3.01 Manual Backspace Mechanism




3.02 Power Drive Backspace Mechanism




3.03 Remote Control Interfering Tape Delete Feed-Out Mechanism



3.04 Two-Color Ribbon Mechanism



3.05 Two-Color Ribbon Contact Mechanism



37 TYPING REPERFORATOR
DISASSEMBLY AND REASSEMBLY

CONTENTS	PAGE
1. GENERAL	1
2. DISASSEMBLY AND REASSEMBLY . .	1
SELECTOR MECHANISM	1
RIBBON FEED MECHANISM	4
PERFORATOR MECHANISM	4
TRANSFER MECHANISM	4
TYPING MECHANISM	4
ROCKER BAIL ASSEMBLY	4
MAIN SHAFT ASSEMBLY	4

1. GENERAL

1.01 This section provides the disassembly and reassembly procedures for the major components of the 37 typing reperforator (Figures 1 and 2).

CAUTION: REMOVE ALL POWER FROM SET OR UNIT BEFORE REMOVING ANY COMPONENTS.

1.02 References to left, right, front, rear, etc, consider the typing reperforator to be viewed from a position where the ribbon feed mechanism is at the top and the selector mechanism is to the viewer's right.

1.03 Disassembly and reassembly, as outlined in this section, covers the procedure for removing and replacing the principle subassemblies which make up the unit. If a further breakdown of the unit is required, refer to the detailed parts section; where it will help in determining their location, the numbers of the parts are given in the instructions.

1.04 If a part that is mounted on shims is removed, the number of shims used at each of its mounting screws should be noted so that the same shim pile-up can be replaced when the part is remounted.

1.05 Retaining rings are made of spring steel and have a tendency to release suddenly. To avoid the loss of these rings when removing them, proceed as follows:

- (a) Hold the retaining ring to prevent its rotating.
- (b) Place the blade of a screwdriver into one of the slots in the ring and turn the screwdriver to increase the diameter.
- (c) Ring will come off easily in fingers without flying.

1.06 All damaged, worn, or distorted parts should be replaced if encountered in the disassembly and reassembly procedures.


2. DISASSEMBLY AND REASSEMBLY

2.01 In removing a subassembly from the unit, the procedure followed and the location from which parts are removed must be carefully noted so that replacement can be done correctly. When replacing a component, be sure to check all associated adjustments, clearances and spring tensions.

2.02 Unplug the connecting cable at the rear of the unit. Remove the three casting mounting screws, lockwashers, flat washers and belt. Remove the typing reperforator from the base.


SELECTOR MECHANISM

2.03 Remove the screw, nut, and lockwasher that secure the TP150001 selector clutch drum to the main shaft. Place the TP306118 push lever reset bail in its raised position.



(Left and Front View)

Figure 1 - 37 Typing Reperforator



(Right Rear View)

Figure 2 - 37 Typing Reperforator

SECTION 574-330-702TC

2.04 Push the TP312924 mark locklever to the left and insert a pin in the hole provided on the lever extension so that the lever is held away from the cam by the TP306115 mark locklever guide bracket.

2.05 Hold the TP312974 space locklever and the TP306127 start lever to the left and slip the TP312935 cam sleeve assembly off the shaft while rotating it in a counterclockwise direction.

Note: To replace the cam sleeve reverse the above steps, but still rotate cam in a counterclockwise direction. When the sleeve is almost fully in place, pull the trip lever and selector clutch latchlever away from their respective cams to facilitate replacement.

2.06 Unhook the spring on the TP150355 function clutch latchlever. Remove the TP156472 spring post by removing its locknut and lockwasher. Remove the TP151442 selector backplate screw. Remove the TP153538 screw and its associated washer that mounts the left leg of the tape platform. The selector mechanism can now be taken off.

RIBBON FEED MECHANISM

2.07 Remove the ribbon. Remove the two mounting screws that mount the ribbon feed mechanism plate. Remove the ribbon feed mechanism.

PERFORATOR MECHANISM

2.08 Remove the spring from the TP192709 perforator drive link and the TP170211 rocker arm.

2.09 Remove the TP76422 trip lever spring. Remove the two TP151442 mounting screws and one TP1248 flat head screw that fasten the TP324314 rear plate to the main plate. Remove the perforator mechanism, being careful not to lose any of the spacers.

TRANSFER MECHANISM

2.10 Remove the TP151631 and TP151632 mounting screws (with lockwashers and flat washers) from the TP192820 transfer mounting bracket. Remove the transfer mechanism.

TYPING MECHANISM

2.11 Remove the TP324236 pushbar operating blade from the TP195235 rocker bail by removing its two screws, lockwashers, shims, and flat washers. Remove the TP159512 print hammer trip link after removing its TP119651 retaining ring and spring.

2.12 Remove the TP154638 accelerator spring from the print hammer accelerator. Remove one TP3870 and one TP324284 spring and a retaining ring from the TP156413 corrector drive link. Remove the TP159536 rotary rack idle gear, its eccentric shaft, mounting screw and lockwasher.

2.13 Remove the screw, lockwasher and flat washer that holds the TP324277 bellcrank pivot shaft to the main plate. Remove the screw and lockwasher that mount the TP159525 axial plate to the post. Remove the three screws, lockwashers, and flat washers that mount the typing assembly to the casting. The typing unit can now be removed.

ROCKER BAIL ASSEMBLY

2.14 Disconnect the TP156937 printing drive link by removing the retaining ring at its left end. Remove the TP3598 nut, lockwasher, flat washer, felt washer bushing, and TP151632 screw from the TP156871 operating blade mounting bail.

2.15 Remove the nut, lockwasher and TP334854 adjusting lever guide, then remove the TP156366 rocker bail shaft. The rocker bail can now be removed.

MAIN SHAFT ASSEMBLY

2.16 Remove the spring from the function clutch latchlever. Remove the retaining ring, spring washer, and flat washers from the forward end of the TP324235 main shaft.

2.17 Remove the screw and lockwasher from the TP150000 function clutch drum. Pull the main shaft out of the rear of the unit.

37 TYPING REPERFORATOR
DISASSEMBLY AND REASSEMBLY

CONTENTS	PAGE
1. GENERAL	1
2. DISASSEMBLY AND REASSEMBLY . .	1
SELECTOR MECHANISM	1
RIBBON FEED MECHANISM	4
PERFORATOR MECHANISM	4
TRANSFER MECHANISM	4
TYPING MECHANISM	4
ROCKER BAIL ASSEMBLY	4
MAIN SHAFT ASSEMBLY	4

1. GENERAL

1.01 This section provides the disassembly and reassembly procedures for the major components of the 37 typing reperforator (Figures 1 and 2).

CAUTION: REMOVE ALL POWER FROM SET OR UNIT BEFORE REMOVING ANY COMPONENTS.

1.02 References to left, right, front, rear, etc, consider the typing reperforator to be viewed from a position where the ribbon feed mechanism is at the top and the selector mechanism is to the viewer's right.

1.03 Disassembly and reassembly, as outlined in this section, covers the procedure for removing and replacing the principle subassemblies which make up the unit. If a further breakdown of the unit is required, refer to the detailed parts section; where it will help in determining their location, the numbers of the parts are given in the instructions.

1.04 If a part that is mounted on shims is removed, the number of shims used at each of its mounting screws should be noted so that the same shim pile-up can be replaced when the part is remounted.

1.05 Retaining rings are made of spring steel and have a tendency to release suddenly. To avoid the loss of these rings when removing them, proceed as follows:

- (a) Hold the retaining ring to prevent its rotating.
- (b) Place the blade of a screwdriver into one of the slots in the ring and turn the screwdriver to increase the diameter.
- (c) Ring will come off easily in fingers without flying.

1.06 All damaged, worn, or distorted parts should be replaced if encountered in the disassembly and reassembly procedures.


2. DISASSEMBLY AND REASSEMBLY

2.01 In removing a subassembly from the unit, the procedure followed and the location from which parts are removed must be carefully noted so that replacement can be done correctly. When replacing a component, be sure to check all associated adjustments, clearances and spring tensions.

2.02 Unplug the connecting cable at the rear of the unit. Remove the three casting mounting screws, lockwashers, flat washers and belt. Remove the typing reperforator from the base.


SELECTOR MECHANISM

2.03 Remove the screw, nut, and lockwasher that secure the TP150001 selector clutch drum to the main shaft. Place the TP306118 push lever reset bail in its raised position.



(Left and Front View)

Figure 1 - 37 Typing Reperforator



(Right Rear View)

Figure 2 - 37 Typing Reperforator

SECTION 574-330-702TC

2.04 Push the TP312924 mark locklever to the left and insert a pin in the hole provided on the lever extension so that the lever is held away from the cam by the TP306115 mark locklever guide bracket.

2.05 Hold the TP312974 space locklever and the TP306127 start lever to the left and slip the TP312935 cam sleeve assembly off the shaft while rotating it in a counterclockwise direction.

Note: To replace the cam sleeve reverse the above steps, but still rotate cam in a counterclockwise direction. When the sleeve is almost fully in place, pull the trip lever and selector clutch latchlever away from their respective cams to facilitate replacement.

2.06 Unhook the spring on the TP150355 function clutch latchlever. Remove the TP156472 spring post by removing its locknut and lockwasher. Remove the TP151442 selector backplate screw. Remove the TP153538 screw and its associated washer that mounts the left leg of the tape platform. The selector mechanism can now be taken off.

RIBBON FEED MECHANISM

2.07 Remove the ribbon. Remove the two mounting screws that mount the ribbon feed mechanism plate. Remove the ribbon feed mechanism.

PERFORATOR MECHANISM

2.08 Remove the spring from the TP192709 perforator drive link and the TP170211 rocker arm.

2.09 Remove the TP76422 trip lever spring. Remove the two TP151442 mounting screws and one TP1248 flat head screw that fasten the TP324314 rear plate to the main plate. Remove the perforator mechanism, being careful not to lose any of the spacers.

TRANSFER MECHANISM

2.10 Remove the TP151631 and TP151632 mounting screws (with lockwashers and flat washers) from the TP192820 transfer mounting bracket. Remove the transfer mechanism.

TYPING MECHANISM

2.11 Remove the TP324236 pushbar operating blade from the TP195235 rocker bail by removing its two screws, lockwashers, shims, and flat washers. Remove the TP159512 print hammer trip link after removing its TP119651 retaining ring and spring.

2.12 Remove the TP154638 accelerator spring from the print hammer accelerator. Remove one TP3870 and one TP324284 spring and a retaining ring from the TP156413 corrector drive link. Remove the TP159536 rotary rack idle gear, its eccentric shaft, mounting screw and lockwasher.

2.13 Remove the screw, lockwasher and flat washer that holds the TP324277 bellcrank pivot shaft to the main plate. Remove the screw and lockwasher that mount the TP159525 axial plate to the post. Remove the three screws, lockwashers, and flat washers that mount the typing assembly to the casting. The typing unit can now be removed.

ROCKER BAIL ASSEMBLY

2.14 Disconnect the TP156937 printing drive link by removing the retaining ring at its left end. Remove the TP3598 nut, lockwasher, flat washer, felt washer bushing, and TP151632 screw from the TP156871 operating blade mounting bail.

2.15 Remove the nut, lockwasher and TP334854 adjusting lever guide, then remove the TP156366 rocker bail shaft. The rocker bail can now be removed.

MAIN SHAFT ASSEMBLY

2.16 Remove the spring from the function clutch latchlever. Remove the retaining ring, spring washer, and flat washers from the forward end of the TP324235 main shaft.

2.17 Remove the screw and lockwasher from the TP150000 function clutch drum. Pull the main shaft out of the rear of the unit.

HIGH SPEED TAPE READER UNITS (CX)

LUBRICATION

CONTENTS	PAGE
1. GENERAL	1
2. BASIC UNIT	2
Cover plate plunger mechanism	3
Feed mechanism	6
Latching mechanism	8
Motor and main shaft assembly	9
Operation control mechanism	6
Sensing mechanism	7
Tape lid mechanism	3
Tape reader (bottom view)	8
Tape reader (front view)	2
Tape reader (top view)	5
Universal tape reading mechanism ..	4

1.05 After approximately 200 hours or four weeks of operation (whichever comes first), relubricate the reader to make certain no points have been missed. Thereafter, lubricate the reader according to the following schedule:

<u>Operating Speed (wpm)</u>	<u>Lubrication Interval*</u>
1000	250 hours or 6 weeks
750	500 hours or 12 weeks
500	1000 hours or 24 weeks
150	1500 hours or 6 months
100	2000 hours or 9 months

*Whichever occurs first.

1.06 The following symbols are used in the lubrication instructions to indicate the type of lubricant.

- O Apply KS7470 oil
- G Apply KS7471 grease as specified

Note: In general, the symbols indicate the type of lubricant. Quantity of lubricant is normally given in the lubrication instructions. An exception to this method is where the exact number of drops of oil is specified. For example, O1, O2, O3, etc refer to 1, 2, 3 etc drops of oil.

1. GENERAL

1.01 This section provides lubrication information for the high speed tape reader units (Figure 1). It is reissued to incorporate engineering changes and comments received on Issue 4. Since only a limited distribution was made on Issue 4, marginal arrows have been omitted.

1.02 General areas of the reader are shown by photographs. Specific points to receive lubrication are indicated by line drawings and descriptive text. The line drawings and descriptive text follow each photograph and are keyed to the photographs by paragraph numbers.

1.03 References made to left or right, front or rear, and top or bottom apply to the reader as viewed with the flywheel facing the viewer (Figure 1).

1.04 Lubricate the reader before placing it into service and just prior to putting it into storage.




Figure 1 - High Speed Tape Reader Unit

SECTION 592-801-701TC

1.07 Ordering information for lubricants and a complete list of tools and materials available to maintain the reader is given in Section 570-005-800TC.

1.08 Oil should be applied by means of an oiler. Overlubrication which would allow oil to drip on other parts should be avoided. Wipe off excess amounts of lubricant. Capillary action and vaporization tend to keep a film of oil on the parts. This prevents rust and provides sufficient lubrication to many points.


CAUTION: SPECIAL CARE SHOULD BE TAKEN TO PREVENT ANY LUBRICANT FROM GETTING BETWEEN ELECTRICAL CONTACTS.

Note: Protective pad TP124828 is available to protect furniture and floor coverings from oil, grease and dirt while lubricating the reader.


CAUTION: REMOVE POWER BEFORE LUBRICATING READER.

2. BASIC UNIT


2.01 Tape Reader (Front View)



2.02 Tape Lid Mechanism




2.03 Cover Plate Plunger Mechanism




SECTION 592-801-701TC


2.04 Universal Tape Reading Mechanism




2.05 Universal Tape Reading Mechanism (continued)




2.06 Tape Reader (Top View)



2.07 Operation Control Mechanism




2.08 Feed Mechanism




2.09 Sensing Mechanism

Note: Exercise care to prevent lubricant from finding its way to contact points.




(Left Front View)

2.10 Tape Reader (Bottom View)




2.11 Latching Mechanism



2.12 Motor and Main Shaft Assembly

Note: Typical application is illustrated. Lubricate standard coded motor units as instructed in Section 570-220-701TC. Refer to the appropriate sections for lubrication instructions on other motor units.





HIGH SPEED TAPE READER UNITS (CX)

DISASSEMBLY AND REASSEMBLY

CONTENTS	PAGE
1. GENERAL	1
2. DISASSEMBLY AND REASSEMBLY ..	1
DRIVEN GEAR OR SPROCKET	1
MAIN SHAFT	2
REAR PLATE ASSEMBLY	3
CODE CONTACT ASSEMBLY	4
TAPE-OUT CONTACT ASSEMBLY ..	4
START-STOP CONTACT ASSEMBLY	5
OPERATING MAGNET ASSEMBLY ..	5
COVERPLATE	6
TAPE GUIDEPLATE	6
TAPE GUIDES	6

1. GENERAL

1.01 This section provides disassembly and reassembly information for the high speed tape reader units (Figure 1). It is reissued to incorporate engineering changes and comments received on Issue 4. Since only a limited distribution was made on Issue 4, marginal arrows have been omitted.

1.02 This section provides specific disassembly and reassembly instructions for the high speed tape reader units (CX). Unless specified otherwise in the instructions, the procedures apply generally to all units.

1.03 Photographs are used to identify the mechanism and specific parts mentioned in the procedures. Refer to the appropriate

parts section for drawings showing the location of all parts and mechanisms.

1.04 Refer to Section 570-005-800TC, Maintenance Tools, for information on tools necessary to perform the disassembly and reassembly procedures.

1.05 References in the procedures to left or right, up or down, top or bottom, etc refer to the reader viewed with the flywheel facing the front (Figure 1).

1.06 While unsoldering leads from the terminals, the thermoplastic tubing over the leads might be damaged. If this happens, replace the tubing. Avoid using an excessive amount of solder and take care that no solder falls or becomes wedged between moving parts.

CAUTION: REMOVE POWER BEFORE DISASSEMBLING THE READER.

2. DISASSEMBLY AND REASSEMBLY

DRIVEN GEAR OR SPROCKET

2.01 The driven gear (Figure 2) or driven sprocket is removed from the TP171731 main shaft as follows:




Figure 1 - Tape Reader Unit




Figure 2 - Tape Reader Unit

(1) All readers except CX805: Remove the TP150089 screw, two TP125011 flat washers, two TP3640 lockwashers and the TP3599 nut that fastens the driven gear to the main shaft. (The TP150089 screw passes through the main shaft at the driven gear end.)

(2) CX805 reader: Remove the TP151685 screw, the TP125011 flat washer, and the TP3640 lockwasher that fastens the driven sprocket to the main shaft.

(3) Remove the TP112626 nut and TP2669 lockwasher from the main shaft.

2.02 To install the driven gear, reverse the steps in the removal procedure.

MAIN SHAFT

2.03 To remove the TP171731 main shaft, proceed as follows:

(1) Remove the driven gear or driven sprocket, whichever is applicable (2.01).

(2) Remove the TP151688 screw, the two TP125011 flat washers, the TP3640 lockwasher, and the TP3599 nut. (The TP151688 screw passes through the main shaft at the flywheel shoulder.)

(3) While holding the TP12782 flywheel firmly, remove the TP112626 nut, TP2669 lockwasher, and TP34432 flat washer (Figure 3).

Note 1: Some readers do not have a flywheel.

Note 2: The TP112626 nut clamps the bearing inner race in place when tightened.

(4) Remove the flywheel if so equipped.

(5) Remove the TP156501 screw, TP2191 lockwasher, and the TP156831 clamp from the front plate.

(6) Remove the TP151722 screw, the TP2191 lockwasher, and the TP156588 clamp from the rear plate (Figure 2).

(7) Guide the main shaft outward, toward the TP174125 rear plate, so that the TP130499 bearing is approximately one inch from the rear plate.

(8) If necessary, use a TP84020 bearing puller and remove the TP130499 rear bearing.




Figure 3 - Tape Reader Unit

(9) Carefully remove the main shaft from the front of the reader by rotating the shaft to assure that no cam followers are blocking the covers.

2.04 Install the main shaft by reversing the step of the removal procedure.

REAR PLATE ASSEMBLY

2.05 To remove the TP174125 rear plate assembly from the reader, proceed as follows:

- (1) Unhook four springs from the TP171735 spring bracket (Figure 2).
- (2) Remove the three TP3598 nuts and TP2191 lockwashers that secure the rear plate to the three TP171288 posts (Figure 2).

(3) Remove the TP151722 screw, TP2191 lockwasher, and TP156588 retaining ring from the TP171732 rear plate (Figure 2).

(4) Remove the TP156740 screw and TP2191 lockwasher that secure the rear plate to the TP171707 post.

(5) On units so equipped, remove the TP119649 retaining ring from the TP179514 shaft (Figure 2).

(6) Unhook the TP171313 spring from the TP171898 bracket to release the magnet and rear plate assembly from the reader.

(7) Check that the stop lever is not engaged with the TP171252 feed pawl.

(8) On units so equipped, unhook the TP179513 torsion spring from the rear plate (Figure 4).

(9) Remove the rear plate assembly from the reader. If it is necessary to remove it completely, remove the operating magnet




Figure 4 - Tape Reader Unit (Plates Removed)

assembly (2.13) and start-stop contact assembly (2.11) from the rear plate.

(4) Remove the code contact assembly from the reader.

2.06 To install the rear plate assembly on the reader, reverse the removal procedure.

2.08 To install the code contact assembly in the reader, reverse the disassembly procedure.

CODE CONTACT ASSEMBLY

TAPE-OUT CONTACT ASSEMBLY

2.07 To remove the code contact assembly from the reader, proceed as follows:

2.09 To remove the TP171255 (or TP179521) tape-out contact assembly from the reader, proceed as follows:

- (1) Remove the two TP156740 screws, two TP2191 lockwashers, and two TP7002 flat washers that secure the code contact assembly to the TP171288 post. See Figure 4.
- (2) It is now possible to move the code contact assembly about two inches outside of the reader.
- (3) Unsolder and disconnect the cable assembly leads from the code contact assembly terminals.

- (1) Unsolder and remove the cable assembly from the tape-out contact assembly (Figure 4).
- (2) Remove the two TP152893 screws, two TP3640 lockwashers, and two TP125011 flat washers from the TP171256 assembly mounting bracket.




Figure 5 - Tape Reader Unit

- (3) Remove the tape-out contact assembly from the reader.

2.10 To install the tape-out contact assembly, reverse the disassembly procedures.

START-STOP CONTACT ASSEMBLY

2.11 To remove the TP171237 start-stop assembly from the reader, proceed as follows:

- (1) Unsolder and disconnect the leads from the TP171237 start-stop contact assembly (Figure 4).
- (2) Remove the two TP152893 screws, two TP3640 lockwashers, and two TP125011 flat washers that secure the bracket to the rear plate.
- (3) Remove the TP171237 start-stop contact assembly from the reader.

- 2.12 To install the start-stop contact assembly, reverse the disassembly procedures.

OPERATING MAGNET ASSEMBLY

2.13 To remove the operating magnet assembly from the reader, proceed as follows:

- (1) Unsolder and disconnect the two color-coded leads (white, black, yellow and black, yellow) from the magnet terminals.
- (2) Disconnect the TP171313 armature spring from the TP170749 armature extension. See Figure 5.
- (3) Remove the TP156740 screw, TP2191 lockwasher, TP7002 flat washer, and TP150964 shoulder screw which secure the magnet bracket to the rear plate.
- (4) Remove the operating magnet assembly with its bracket from the reader.

SECTION 592-801-702TC

2.14 To install the operating magnet assembly in the reader, reverse the removal procedure.

COVERPLATE

2.15 To remove the coverplate, lift its left side and carefully pull it off the left side of the reader (Figure 2 and 3).

2.16 To install the coverplate, reverse the removal procedure.

TAPE GUIDEPLATE

2.17 To remove the tape guideplate, proceed as follows:

- (1) Loosen the four TP152893 screws securing the tape guideplate brackets to the front and rear plates (Figure 2).
- (2) Gently lift the tape guideplate off the reader.

2.18 To install the tape guideplate, place the tape guideplate on the reader so the mounting brackets just begin to engage their screws. Do not try to force the tape guide down completely.

2.19 Turn the reader to view the left side. Use a TP151959 spring hook and pull back each sensing finger from the underside of the tape guideplate and position them in their respective guide slots. Push the tape guideplate down until the mounting brackets are fully engaged with their screws.

CAUTION: DO NOT BEND OR DEFORM SENSING PINS.

TAPE GUIDES

2.20 To remove any of the four adjustable tape guides (TP179516 or TP179517), remove the associated nut, flat washer and spring (Figure 3).

2.21 To install the tape guide, reverse the removal procedure.