



KEYTOPS
FOR
MODELS 37, CDT AND "DATASPEED®" PRINTER
TERMINALS

Models 37, CDT and DATASPEED Printer Terminal keytops are gray plastic with white characters, unless otherwise specified.


STYLE A




STYLE AA




STYLE B




STYLE C




STYLE F




STYLE G




STYLE H




STYLE K




STYLE L




STYLE M




STYLE S




STYLE T




STYLE U




STYLE V




STYLE W




STYLE X



STYLE Y



STYLE Z



SECTION 570-020-801

STYLE G

Keytop Description	Part Number	Keytop Description	Part Number	Keytop Description	Part Number
A	313020	N RED	313034	2	313057
A SOH	313117	N	313055	2	①313095
		N SO	313127	3 #	313003
				3	313058
B	313033			3	①313096
B STX	313126	O BLACK	313018	4 \$	313004
		O SI	313115	4	313059
				4	①313097
C	313031			5 %	313005
C SP-8	313093	P	313019	5	313060
C ETX	313125	P DLE	313116	5	①313098
ϕ	313140			6 &	313006
D	313022	Q	313010	6	①313099
D END	313050	Q DC1	313108	7	313007
D EOT	313119			7	313062
				7	①313100
E	313012	R	313013	7 /	313129
E WRU	313051	R DC2	313111	7 !	313142
E	313110			8 (313008
E ENQRY	313132	S	313021	8	313063
E ENQ	313139	S DC3	313118	8	①313101
E /				9)	313009
F	313023			9	313064
F SP-1	313087	T	313014	9	①313102
F ACK	313120	T DC4	313112	0	313049
				0	①313103
G	313024	U	313016	<	313036
G BELL	313052	U NAK	313114	>	313037
G SP-2	313088			=	313038
				-	313039
				~	313040
H	313025	V	313032	^	313042
H SP-3	313089	V SP-7	313092	*	313043
		V SYNC	313125	{	313044
		V SYN	313135	}	313045
				;	313046
I	313017			/	313047
		W	313011	,	313048
		W ETB	313109	(BLANK)	313065
I	313026			.	313066
				>	313067
K	313027	X	313030	<	313068
K TAB	313053	X CANCL	313123	@	313078
K	313090	X CAN	313134	@	313079
K SP-4	313121			\$	313080
K VTAB	313133			?	313081
K VT		Y	313015	,	313082
		Y EM	313113	,	313083
				!	313084
L	313028			*	①313086
L PAGE	313054	Z	313029	<	313104
L SP-5	313091	Z SUB	313122	>	313105
L FF	313136			:FS	313106
				-US	313107
M	313035	1 !	313001	@	313128
		1	313056	⌈	313130
		1	①313094	\	313141
		2 "	313002	@	313143

①Indicates charcoal gray character

See page 1 for keytop style illustrations

<u>STYLE G (Continued)</u>		<u>STYLE S</u>	
Keytop Description	Part Number	Keytop Description	Part Number
:FS	313144	<u>STYLE S</u>	
US	313145	CONTRL	314835
<u>STYLE A</u>		<u>STYLE T</u>	
PREFIX	314805	LINE SPACE	314837
(BLANK)	314813	NEW LINE	314839
ESCAPE	314844	LINE FEED	314862
<u>STYLE AA</u>		<u>STYLE U</u>	
ESCAPE	314857	SHIFT LOCK	314840
SHIFT LOCK	314860	US DELETE	314858
<u>STYLE B</u>		<u>STYLE V</u>	
TAB →	314806	RETURN	314841
(BLANK)	314814	O	314855
TAB	314838	SHIFT	314861
<u>STYLE C</u>		<u>STYLE W</u>	
\	314807	1	314823
(BLANK)	314815] } GS	314842
SHIFT	314836	^ ^/RS	314843
<u>STYLE F</u>		7	314850
SHIFT LOCK	314800	BACKSPACE	314853
(BLANK)	314812	CTRL	314854
NULL	314834	<u>STYLE X</u>	
<u>STYLE H</u>		2	314824
BACKSPACE	314803	3	314825
(BLANK)	314811	8	314851
<u>STYLE K</u>		9	314852
RETURN	314801	<u>STYLE Y</u>	
(BLANK)	314816	SHIFT	314856
NEW LINE	314859	<u>STYLE Z</u>	
<u>STYLE L</u>		4	314826
NEW LINE	314802	5	314827
(BLANK)	314810	6	314849
<u>STYLE M</u>			
DELETE	314804		
SHIFT	314808		
CONTRL	314809		

See page 1 for keytop style illustrations

SECTION 570-020-801

NUMERICAL INDEX

Part Number	Page Number	Part Number	Page Number	Part Number	Page Number	Part Number	Page Number	Part Number	Page Number
313001		313078		313125		313139		314823	
thru		thru		thru		thru		thru	
313040	2	313084	2	313130	2	313145	2	314827	3
313042		313086		313132		314800		314834	
thru		thru		thru		thru		thru	
313068	2	313123	2	313136	2	314816	3	314844	3
								314849	
								thru	
								314862	3