

INSTRUCTION MANUAL FOR TELETYPE MODEL 15 AND
19 PRINTER AND MODEL 14 REFERFORATOR SET

Contents

Photograph 401210-46	Model 15 Printer Set (Sending-Receiving)
Photograph 410127-44	Model 15 Printer Set (Receiving Only) Model 15 Printer Set
Specification S-5381, Issue 1	General Description Model 15 Printer Set
Photograph 411018-36	Model 19 Set (Front View)
Photograph 411018-37	Model 19 Set (Rear View)
Specification S-5380, Issue 2	General Description Model 19 Set

Model 15 Page Printer and Perforator Transmitter

Specification S-5017, Issue 2	Installation
Bulletin 144, Issue 1	Description - Printer
Bulletin 133, Issue 4	Adjustments - Printer
Bulletin 1094, Issue 1	Parts Catalog - Printer
Bulletin 166, Issue 1	Description and Adjustments - Perforator Transmitter
Bulletin 1090, Issue 2	Parts Catalog - Perforator Transmitter
Drawing W.D. 1986	Wiring Diagram

Line Relay

Bulletin 120, Issue 6	Description, Adjustments and Wiring Diagram
Bulletin 1044, Issue 4	Parts Catalog

Model 14 Transmitter Distributor

Bulletin 141, Issue 3	Description and Adjustments
Bulletin 1109, Issue 1	Parts Catalog
Drawing W.D. 2084	Wiring Diagram

TELETYPE INSTRUCTION MANUAL NO. 29
Issue 1, Page 2
October, 1942

Contents

Lubrication

Specification S-5288, Issue 1 Supplies and Directions for Use

Model 14 Reperforator

Bulletin 1080, Issue 1 Parts Catalog

Metal Tables

Specification S-5187, Issue 2 Instructions for Use of
Portable Reperforator Tables

Drawing W.D. 2031 Model 15 Printer Table
Wiring Diagram

Drawing W.D. 1795 Schematic) Wiring Diagrams

Motor Power Arrangements

Specification S-5270, Issue 4 . . . Model 15 Set) Instructions for Operation of
AC Governed Motor Units on
Specification S-5273, Issue 2 . . . Model 19 Set) 25 Cycles

Rectifier Specifications

S-5237, Issue 2 (REC-10, 50-60 Cycle)) Model 15 Set)
S-5316, Issue 3 (REC-20, 25 Cycle)) Description, Adjustments,
S-5269, Issue 3 (REC-13, 60 Cycle)) Parts Catalog and
S-5299, Issue 1 (REC-14, 25 Cycle)) Wiring Diagram
Model 19 Set)