

ADDITIONS TO  
BULLETIN NO. 1094 (ISSUE 2)  
PARTS - TYPE BAR PAGE PRINTER (MODEL 15)

This correction sheet covers ordering information for the various parts used on certain types of Model 15 printer bases that are not listed in the bulletin.

Page 13

The resistor, located on top of the base at the extreme left side, may be ordered as 103746 resistor - 5 ohms. This resistor is mounted by means of an 81596 screw, 2669 lock washer, 3438 washer and two 81836 washers - bakelite.

Page 14

The switch bracket (assem.) located on top of the 74395 relay guard, may be ordered as 107269 switch bracket (assem.) and consists of a 107213 bracket and a 95320 toggle switch (with 91683 nut-hex., 91684 nut-ring and two wire leads). This switch bracket (assem.) is mounted by means of two 6745 screws, two 2669 lock washers and two 3438 washers.