

EXHAUST AND AIR INTAKE
TO MAINTAIN THE ENGINE AT THE CORRECT TEMPERATURE &
PREVENT OVERHEATING OF THE ENGINE

THE EXHAUST SYSTEM IS A CRUCIAL COMPONENT OF THE
ENGINE AND MUST BE MAINTAINED AT ALL TIMES.

EXHAUST AND AIR INTAKE
SYSTEM



EXHAUST AND AIR INTAKE SYSTEM

