

INSTRUCTIONS FOR INSTALLING THE 334883 (FOR
FRICTION FEED UNITS) OR 334884 (FOR SPROCKET
FEED UNITS) MODIFICATION KIT TO PROVIDE NEW
LINE FEATURE ON MODEL 35 TYPING UNITS

1. GENERAL

- 1.01 The 334883 new line modification kit provides the carriage return function on receipt of a line feed signal. A disabling option is provided with each kit which restores normal CR-LF operation. The 334883 modification kit is for use on Model 35 typing units with friction feed.
- 1.02 The 334884 kit provides additional features shown in the Table below.

Table

<u>FUNCTION</u>	<u>SIGNAL</u>
CARRIAGE RETURN	FORM FEED
CARRIAGE RETURN	VERTICAL TAB

- 1.03 A disabling option is provided with each kit which disables CR on LF and CR on VT, but does not disable CR on FF. The 334884 modification kit is for use on Model 35 typing units with sprocket feed.
- 1.04 When the new line feature is used, the Model 35 units require at least one fill character after new line. However, additional fill characters will be determined by systems requirements.
- 1.05 The modification kits consist of:

<u>Qty</u>	<u>Part No.</u>	<u>Description</u>	<u>Qty</u>	<u>Part No.</u>	<u>Description</u>
1	4703	Spring	1	157240	Spring
1	72522	Wick	1	157274	Clip
1	90517	Spring	1	192471 (only 334883)	Bar
1	152298	Lever	1	192477 (only 334884)	Bar
1	152653	Pawl	1	198472 (only 334884)	Bar
1	154613	Latch			

SPECIFICATION 50698S

1.06 For part numbers referred to, other than the parts in the kits, see Teletype Parts Bulletin 1187B. Standard adjusting, lubrication, and installation procedures are to be found in Teletype Bulletin 280B.

2. INSTALLATION

KIT 334883 — FRICITION FEED UNITS

- 2.01 Remove the stunt box from the typing unit in accordance with Teletype Bulletin 280B. Bell System, refer to the standardized information.
- 2.02 Remove the 195459 CR function bar from slot 5 and retain. Retain the associated parts.
- 2.03 Install the 192471 LF function bar in slot 5 using the retained parts. Add the 157274 clip for normal operation.
- 2.04 Install the 152298 lever, 195459 function bar, 152653 pawl, 154613 latch, 157240 spring, 90517 spring, 72522 wick, and 4703 spring in slot 4.
- 2.05 Reinstall the stunt box in the typing unit.

KIT 334884 — SPROCKET FEED UNITS

- 2.06 Remove the stunt box from the typing unit in accordance with Teletype Bulletin 280B. Bell System, refer to the standardized information.
- 2.07 Remove the 192459 CR function bar from slot 5 and discard. Retain the associated parts.
- 2.08 Install the 198472 LF-VT function bar in slot 5 using the retained parts. Add the 157274 clip for normal operation.
- 2.09 Install the 192477 CR-FF function bar, 152298 lever, 152653 pawl, 154613 latch, 157240 spring, 90517 spring, 72522 wick and 4703 spring in slot 4.
- 2.10 Reinstall the stunt box in the typing unit.

*

*

*