

INSTRUCTIONS FOR INSTALLING 407777 RIBBON CARTRIDGE SET
ON A MODEL 40 80- OR 132-COLUMN TRACTOR FEED PRINTER

1. GENERAL

1.01 The 407777 ribbon cartridge consists of the following parts:

<u>Qty</u>	<u>Description</u>
1	Ribbon
2	Cartridge
1	Disposable Glove

Note: Place latches in their open position (vertical) and remove used cartridges (if present).

2. INSTALLATION

2.01 Place the right and left detent in the number "1" position.

2.02 Remove the lid from the new cartridges and install one on the right and one on the left bushing with latch. Place the latches in their closed position (horizontal). To install ribbon, see the instructions on the top of the printer and use enclosed disposable glove.

